

# Operator's Manual

# ZAXIS

**130-6N**

**160LC-6N·180LC-6N**

**210-6N·210LC-6N**

**250LC-6N**

**300LC-6N**

**350LC-6N·380LC-6N**

**Hydraulic Excavator**

Serial No.

ZX130-6N	140001 and up
ZX160LC-6N	240001 and up
ZX180LC-6N	540001 and up
ZX210-6N, 210LC-6N	340001 and up
ZX250LC-6N	440001 and up
ZX300LC-6N	840001 and up
ZX350LC-6N	940001 and up
ZX380LC-6N	640001 and up

ZX130-6N•160LC-6N•180LC-6N•210-6N•210LC-6N•250LC-6N•300LC-6N•350LC-6N•380LC-6N HYDRAULIC EXCAVATOR OPERATOR'S MANUAL ENMDC1-NA3-4

 Hitachi Construction Machinery Co., Ltd.

URL:<http://www.hitachi-c-m.com>



This book is printed on recycled paper.

PRINTED IN JAPAN (K) 2020, 11

## INTRODUCTION

**Read this manual** carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or machine damage.

**This standard specification machine** can be operated under the following conditions without being modified.  
Atmospheric Temperature: -20 °C to 40 °C (-4 °F to 104 °F)  
Altitude: 0 m to 2000 m (0 ft to 6600 ft)

In case the machine is used under conditions other than described above, consult your authorized dealer.

**This manual should be considered** a permanent part of your machine and should remain with the machine when you sell it.

**This machine is of metric** design. Measurements in this manual are metric. Use only metric hardware and tools as specified.

**Right-hand and left-hand** sides are determined by facing in the direction of forward travel.

**Write product identification numbers** in the Machine Numbers section. Accurately record all the numbers to help in tracing the machine should it be stolen. Your dealer also needs these numbers when you order parts. If this manual is kept on the machine, also file the identification numbers in a secure place off the machine.

Be sure to use fuel that complies with JIS K-2204, EN-590 or ASTM D-975 which contains 15 ppm or lower sulfur. Also use fuel that complies with solid contamination level of class 18/16/13 of ISO4406-1999 (solid contamination includes dust). If the fuel specified above is not used, exhaust gas that exceeds the regulation values may be discharged, causing serious problem on the engine. Consult your authorized dealer.

**Warranty** is provided as a part of Hitachi's support program for customers who operate and maintain their equipment as described in this manual. The warranty is explained on the warranty certificate which you should have received from your dealer.

This warranty provides you the assurance that Hitachi will back its products where defects appear within the warranty period. In some circumstances, Hitachi also provides field improvements, often without charge to the customer, even if the product is out of warranty.

**Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied.**

Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.

Only qualified, experienced operators officially licensed (according to local law) should be allowed to operate the machine. Moreover, only officially licensed personnel should be allowed to inspect and service the machine.

**PRIOR TO OPERATING THIS MACHINE, INCLUDING COMMUNICATION SYSTEM, IN A COUNTRY OTHER THAN A COUNTRY OF ITS INTENDED USE, IT MAY BE NECESSARY TO MAKE MODIFICATIONS TO IT SO THAT IT COMPLIES WITH THE LOCAL REGULATORY STANDARDS (INCLUDING SAFETY STANDARDS) AND LEGAL REQUIREMENTS OF THAT PARTICULAR COUNTRY. PLEASE DO NOT EXPORT OR OPERATE THIS MACHINE OUTSIDE OF THE COUNTRY OF ITS INTENDED USE UNTIL SUCH COMPLIANCE HAS BEEN CONFIRMED. PLEASE CONTACT HITACHI CONSTRUCTION MACHINERY CO., LTD. OR ANY OF OUR AUTHORIZED DISTRIBUTOR OR DEALER IF YOU HAVE ANY QUESTIONS CONCERNING COMPLIANCE.**

**In this manual, urea water is indicated as DEF/ AdBlue®.**

**"DEF" stands for the Diesel Exhaust Fluid.**

**AdBlue® is a registered trademark of the Verband der Automobilindustrie e.V. (VDA).**

**Jubilee® is a registered trademark of the L Robinson & Co (Gillingham) Limited.**

**Hycolin® is a registered trademark of the USUI CO., LTD.**

### CALIFORNIA Proposition 65 Warning

**Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.**

All information, illustrations and specifications in this manual are based on the latest product information available at the time of publication. The right is reserved to make changes at any time without notice.

# INDEX

MACHINE NUMBERS

SAFETY

SAFETY SIGNS

NAME OF COMPONENTS

GETTING ON/OFF THE MACHINE

OPERATOR'S STATION

BREAK-IN

OPERATING THE ENGINE

DRIVING THE MACHINE

OPERATING THE MACHINE

TRANSPORTING

MAINTENANCE

MAINTENANCE UNDER SPECIAL ENVIRONMENTAL CONDITIONS

STORAGE

TROUBLESHOOTING

SPECIFICATIONS

OPTIONAL ATTACHMENTS AND DEVICES

INDEX



# CONTENTS

<b>MACHINE NUMBERS .....</b>	<b>1</b>	Avoid Applying Heat to Lines Containing Flammable Fluids.....	S-35
<b>SAFETY .....</b>	<b>S-1</b>	Precautions for Handling Accumulator and Gas Damper .....	S-35
Recognize Safety Information .....	S-1	Remove Paint Before Welding or Heating .....	S-36
Understand Signal Words.....	S-1	Beware of Asbestos and Silica Dust and Other Contamination .....	S-36
Follow Safety Instructions.....	S-2	Prevent Battery Explosions .....	S-37
Prepare for Emergencies.....	S-3	Service Air Conditioning System Safely .....	S-37
Wear Protective Clothing.....	S-3	Handle Chemical Products Safely.....	S-38
Protect Against Noise .....	S-4	Dispose of Waste Properly.....	S-38
Inspect Machine .....	S-4	Never Ride Attachment.....	S-39
General Precautions for the Cab.....	S-5	Notes on Aftertreatment Device .....	S-39
Use Handholds and Steps .....	S-6	Precautions for Communication Terminal.....	S-39
Adjust the Operator's Seat.....	S-6	Notes on Protection of Operator's Station when the Machine Rolls Over .....	S-40
Ensure Safety Before Rising from or Leaving Operator's Seat .....	S-7	<b>SAFETY SIGNS .....</b>	<b>S-41</b>
Fasten Your Seat Belt.....	S-7	<b>NAME OF COMPONENTS .....</b>	<b>1-1</b>
Move and Operate Machine Safely.....	S-8	Name of Components .....	1-1
Operate Only from Operator's Seat .....	S-8	<b>GETTING ON AND OFF THE MACHINE .....</b>	<b>1-2</b>
Jump Starting .....	S-9	<b>OPERATOR'S STATION.....</b>	<b>1-3</b>
Keep Riders off Machine .....	S-9	About Aftertreatment Device .....	1-3
Precautions for Operations .....	S-10	Cab Features.....	1-6
Investigate Job Site Beforehand .....	S-11	Multi Function Monitor .....	1-7
Install OPG Guard .....	S-12	Default Setting .....	1-8
Restriction of Attachment Installation .....	S-12	Basic Screen.....	1-9
Provide Signals for Jobs Involving Multiple Machines....	S-13	How to Use Screens .....	1-10
Confirm Direction of Machine to Be Driven.....	S-13	Displaying Basic Screen .....	1-10
Drive Machine Safely.....	S-14	Hour Meter .....	1-13
Avoid Injury from Rollaway Accidents.....	S-16	Clock.....	1-13
Avoid Injury from Back-Over and Swing Accidents .....	S-17	Fuel Gauge .....	1-13
Keep People Clear from Working Area .....	S-18	DEF/AdBlue® Gauge.....	1-14
Never Position the Bucket Over Anyone.....	S-18	DEF/AdBlue® Level Alarm .....	1-14
Avoid Undercutting.....	S-19	Coolant Temperature Gauge .....	1-15
Avoid Tipping.....	S-19	Operating Status Icon Display.....	1-15
Never Undercut a High Bank.....	S-20	Security Functions (Optional) .....	1-16
Dig with Caution.....	S-20	Input Password .....	1-16
Operate with Caution .....	S-20	Extending Password Duration Time .....	1-17
Avoid Power Lines.....	S-21	Alarm Occurrence Screen.....	1-18
Precautions for Lightning.....	S-21	Remedy .....	1-20
Object Handling .....	S-22	Urea SCR System Remedy .....	1-23
Protect Against Flying Debris and Falling Object.....	S-23	Aftertreatment Device.....	1-25
Park Machine Safely.....	S-24	Aftertreatment Device Condition Display .....	1-25
Handle Fluids Safely—Avoid Fires.....	S-24	Aftertreatment Device Manual Regeneration Request .....	1-26
Transport Safely .....	S-25	Manual Regeneration Procedure .....	1-27
Practice Safe Maintenance.....	S-26	Main Menu.....	1-28
Warn Others of Service Work .....	S-27	Engine Output Restriction Suspend.....	1-29
Support Machine Properly.....	S-27	Urea SCR System Troubleshooting.....	1-31
Stay Clear of Moving Parts .....	S-28	Air Conditioner.....	1-33
Prevent Parts from Flying .....	S-28	Circulation Air Mode.....	1-33
Avoid Injury from Attachment Falling Accident .....	S-29	Air Conditioner ON/OFF .....	1-33
Prevent Burns.....	S-29	Radio .....	1-34
Replace Rubber Hoses Periodically.....	S-30	Work Mode .....	1-35
Avoid High-Pressure Fluids .....	S-30		
Prevent Fires.....	S-31		
Evacuating in Case of Fire.....	S-33		
Beware of Exhaust Fumes.....	S-33		
Precautions for Welding and Grinding .....	S-34		
Avoid Heating Near Pressurized Fluid Lines .....	S-35		

## CONTENTS

Attachment Selection .....	1-35	Travel Alarm Deactivation Switch (Optional).....	1-103
Mail (Optional).....	1-36	Rear Light Switch (Optional) .....	1-103
Setting Menu .....	1-38	Electrical Control Main Switch (Optional) .....	1-103
Date and Time.....	1-39	ON/OFF Operation Switch (Optional).....	1-103
Time Adjustment .....	1-39	Key Switch.....	1-104
Date Adjustment.....	1-41	Power Boost Switch .....	1-104
Display Mode Setting.....	1-43	Horn Switch.....	1-104
Attachment Adjustment.....	1-45	Electrical Control Main Switch (Optional).....	1-105
Flow Rate Adjustment.....	1-45	ON/OFF Operation Switch (Optional) .....	1-106
Priority (arm roll-out).....	1-47	AUX Function Lever 3 .....	1-106
Priority (arm roll-in) (Except ZX350LC-6N, 380LC-6N).....	1-49	Cigar Lighter.....	1-107
Attachment Name Input.....	1-51	Using Cigar Lighter.....	1-107
Auto Shut-Down.....	1-53	Cab Light Switch.....	1-108
Auto Shut-Down: ON/OFF .....	1-53	Installing Fire Extinguisher (Optional) .....	1-108
Auto Shut-Down: Setting Time.....	1-54	Pilot Control Shut-Off Lever .....	1-109
Aftertreatment Device Regeneration Inhibited .....	1-55	Engine Stop Switch.....	1-109
Setting Procedure .....	1-55	Fuse Box.....	1-110
Password Change (Optional).....	1-57	Auto Air Conditioner .....	1-111
Sub Meter .....	1-61	Features:.....	1-111
Rear View Camera Monitor .....	1-63	Name of Components.....	1-112
Rear View Camera ON/OFF .....	1-63	Controller Part Name and Function .....	1-113
Brightness Adjustment.....	1-65	Cab Heater Operation .....	1-115
Language Settings.....	1-67	Cooling Operation.....	1-116
Lists of Display Language.....	1-69	Defroster Operation.....	1-117
Unit Selection .....	1-70	Cool Head/Warm Feet Operation.....	1-117
Display Item Selection (Rear View Camera OFF) .....	1-72	Tips for Optimal Air Conditioner Usage .....	1-118
Main Menu Sequence Change .....	1-74	For Rapid Cooling .....	1-118
Information Menu .....	1-76	When Windows Become Misty.....	1-118
Operation .....	1-77	Off-Season Air Conditioner Maintenance .....	1-118
Fuel Consumption .....	1-77	AM/FM Radio Operation .....	1-119
Breaker Operation .....	1-79	Controls on the Radio.....	1-119
Attachment Operation.....	1-81	Tuning Procedure .....	1-119
Travel Operation.....	1-83	Station Presetting Procedure.....	1-120
Actual operation .....	1-85	Station Auto-Presetting Procedure .....	1-121
Maintenance .....	1-87	TONE Control.....	1-122
Remaining Time and Maintenance Interval .....	1-89	Audio Input (Optional) .....	1-123
Troubleshooting .....	1-91	Cab Door Release Lever .....	1-124
Monitoring.....	1-93	Opening/Closing and Removing Cab	
Switch Panel.....	1-95	Inside Window .....	1-125
Return to Previous Screen Switch (Monitor) .....	1-96	Opening Upper Front Window .....	1-126
Return to Basic Screen Switch (Monitor) .....	1-96	Removing and Storing Lower Front Window .....	1-127
Selector Knob (Monitor).....	1-96	Opening Side Window.....	1-128
Temperature Control Switch/Mode Switch (Air Conditioner) .....	1-96	Opening/Closing Overhead Window.....	1-129
AUTO/OFF Switch/Fan Switch (Air Conditioner).....	1-96	Opening/Closing Overhead Window (Clear Hatch: If Equipped).....	1-130
AM/FM Selector/Tuning Switch (Radio).....	1-97	Emergency Exit .....	1-131
Power Switch/Volume Control Knob (Radio).....	1-97	Adjusting Operator's Seat .....	1-132
Engine Control Dial .....	1-97	Seat Height and Angle Adjustment .....	1-132
Auto-Idle Switch.....	1-98	Console and Seat Fore-aft Adjustment.....	1-132
Travel Mode Switch .....	1-98	Seat Fore-Aft Adjustment .....	1-132
Power Mode Switch .....	1-99	Backrest Adjustment .....	1-132
Work Light Switch.....	1-99	Armrest Adjustment .....	1-133
Wiper/Washer Switch .....	1-100	Adjusting Operator's Seat .....	1-134
Numeric Keypad.....	1-101	Seat Height and Angle Adjustment .....	1-134
Switch Panel (for Optional Equipments).....	1-102	Console and Seat Fore-aft Adjustment.....	1-134
		Seat Fore-Aft Adjustment .....	1-134

## CONTENTS

Suspension Adjustment .....	1-134	Auto-Idle ON/OFF .....	5-6
Backrest Adjustment .....	1-135	Auto Shut-Down .....	5-7
Armrest Adjustment .....	1-135	Aftertreatment Device Manual Regeneration .....	5-10
Adjusting Operator's Seat (Optional) .....	1-136	Work Mode .....	5-12
Seat Height and Angle Adjustment .....	1-136	Power Boost Switch .....	5-15
Console and Seat Fore-aft Adjustment .....	1-136	Power Mode .....	5-16
Seat Fore-Aft Adjustment .....	1-136	Operating Backhoe .....	5-17
Suspension Adjustment .....	1-136	Shovel .....	5-18
Backrest Adjustment .....	1-137	Grading Operation .....	5-19
Armrest Adjustment .....	1-137	Do Not Strike the Ground with Bucket Teeth .....	5-20
Adjusting Operator's Seat (Optional) .....	1-138	Avoid Hammer Work .....	5-20
Adjusting Seat Height .....	1-138	Avoid Abusive Operation .....	5-21
Console and Seat Fore-aft Adjustment .....	1-138	Never Move an Object Sideways with the Bucket .....	5-21
Seat Fore-Aft Adjustment .....	1-138	Do Not Use Wide Track Shoes on Rough Ground .....	5-22
Suspension Adjustment .....	1-139	Shackle Hole Usage .....	5-23
Fore-Aft Position Adjustment of Seat Surface .....	1-139	Pilot Accumulator Functions .....	5-24
Angle Adjustment of Seat Surface .....	1-139	How to Lower Boom in Case of Emergency and When Engine Stops .....	5-25
Backrest Adjustment .....	1-139	Precautions for After Operations .....	5-26
Armrest Adjustment .....	1-139	<b>TRANSPORTING .....</b>	<b>6-1</b>
Console Height Adjustment .....	1-140	Transporting by Road .....	6-1
Adjusting Procedures .....	1-140	Loading/Unloading on a Trailer .....	6-2
Installation and Adjustment of Mirrors .....	1-141	Fastening Machine for Transporting .....	6-5
Seat Belt .....	1-142	Unloading .....	6-5
Battery Disconnect Switch .....	1-143	Lifting Machine .....	6-7
Switch Operation .....	1-143	<b>MAINTENANCE .....</b>	<b>7-1</b>
<b>BREAK-IN .....</b>	<b>2-1</b>	Correct Maintenance and Inspection Procedures .....	7-1
Observe Engine Operation Closely .....	2-1	Layout .....	7-3
Every 8 Hours or Daily .....	2-1	Check the Hour Meter Regularly .....	7-4
After the First 50 Hours .....	2-1	Maintenance Guide Table .....	7-5
After the First 100 Hours .....	2-1	Preparations for Inspection and Maintenance .....	7-7
<b>OPERATING THE ENGINE .....</b>	<b>3-1</b>	Hood and Access Covers .....	7-8
Inspect Machine Daily Before Starting .....	3-1	Maintenance Guide .....	7-11
Before Starting Engine .....	3-2	Periodic Replacement of Parts .....	7-16
Starting the Engine .....	3-3	Kind of Oils .....	7-17
Check Instruments After Starting .....	3-9	Recommended Engine Oil .....	7-17
Using Booster Batteries .....	3-10	List of Consumable Parts .....	7-20
Stopping the Engine .....	3-12	A. Greasing .....	7-28
Engine Auto-Stop in Extremely Low Temperature .....	3-13	Front Joint Pins .....	7-28
<b>DRIVING THE MACHINE .....</b>	<b>4-1</b>	Swing Bearing .....	7-30
Travel Levers and Pedals .....	4-1	Swing Internal Gear .....	7-31
Travel Mode Switch .....	4-3	B. Engine .....	7-32
Travel Alarm (Optional) .....	4-3	Check Engine Oil Level .....	7-32
Operating on Soft Ground .....	4-4	Change Engine Oil .....	7-34
Raise One Track Using Boom and Arm .....	4-4	Replace Engine Oil Filter .....	7-34
Towing Machine a Short Distance .....	4-5	Check and Clean Around the Engine .....	7-37
Operating in Water or Mud .....	4-6	Replace Oil Separator Element (ZX130-6N, 160LC-6N, 180LC-6N) .....	7-37
Parking the Machine on Slopes .....	4-7	C. Transmission .....	7-38
Parking the Machine .....	4-7	Pump Transmission (Except ZX130-6N) .....	7-38
<b>OPERATING THE MACHINE .....</b>	<b>5-1</b>	Swing Reduction Gear .....	7-39
Control Lever (ISO Pattern) .....	5-1	Travel Reduction Gear .....	7-40
Pilot Control Shut-Off Lever .....	5-2	D. Hydraulic System .....	7-42
Warming-Up Operation .....	5-3	Inspection and Maintenance of Hydraulic Equipment .....	7-42
Engine Speed Control .....	5-4	Check Hydraulic Oil Level .....	7-46
Auto-Idle .....	5-5		

# CONTENTS

Change Hydraulic Oil.....	7-47	Tightening and Retightening Torque of	
Bleed Air from the Hydraulic System.....	7-49	Nuts and Bolts.....	7-114
Suction Filter Cleaning.....	7-50	J. Aftertreatment Device.....	7-136
Replace Full-Flow Filter.....	7-51	Check and Clean Aftertreatment Device.....	7-136
Replace Pilot Oil Filter.....	7-52	K. Urea SCR System.....	7-137
Replace Air Breather Element.....	7-53	Check DEF/AdBlue®.....	7-139
Check Hoses and Lines.....	7-54	Refill DEF/AdBlue®.....	7-139
E. Fuel System.....	7-58	Extendable Filler Neck.....	7-141
Recommended Fuel.....	7-58	Clean Filler Port Strainer.....	7-142
Drain Fuel Tank Sump.....	7-60	Change DEF/AdBlue®.....	7-143
Drain Fuel Pre-Filter.....	7-61	Replace DEF/AdBlue® Supply Module Main Filter.....	7-144
Replace Fuel Main Filter Element.....	7-64	Replace DEF/AdBlue® Tank Water Supply	
Replace Fuel Pre-Filter Element.....	7-66	Inlet Filter.....	7-146
Replace Fuel Solenoid Pump Filter Element.....	7-68	Replace the DEF/AdBlue® back flow line filter.....	7-147
Procedures.....	7-68		
Check Fuel Hoses.....	7-70	<b>MAINTENANCE UNDER SPECIAL ENVIRONMENTAL</b>	
F. Air Cleaner.....	7-71	<b>CONDITIONS..... 9-1</b>	
Clean and Replace Air Cleaner Element (Outer).....	7-71	<b>STORAGE..... 10-1</b>	
Replace Air Cleaner Element (Inner).....	7-73	Storing the Machine.....	10-1
G. Cooling System.....	7-74	<b>TROUBLESHOOTING..... 11-1</b>	
Check Coolant Level.....	7-75	<b>SPECIFICATIONS..... 12-1</b>	
Check and Adjust Fan Belt Tension.....	7-77	Specifications.....	12-1
Change Coolant.....	7-79	ZX130-6N.....	12-1
Clean Radiator/Oil Cooler/Inter Cooler Core.....	7-81	Working Ranges (Grouser shoe).....	12-2
Clean Oil Cooler, Radiator and Inter Cooler		ZX130-6N.....	12-2
Front Screen.....	7-83	Shoe Types and Applications.....	12-3
Clean Air Conditioner Condenser.....	7-83	ZX130-6N.....	12-3
Clean Fuel Oil Cooler.....	7-83	Bucket Types and Applications.....	12-4
Drain Intercooler (only ZX130-6N).....	7-84	ZX130-6N.....	12-4
H. Electrical System.....	7-85	Specifications.....	12-5
Battery.....	7-86	ZX160LC-6N.....	12-5
Replace Battery.....	7-89	Working Ranges (Grouser shoe).....	12-6
Check Electrolyte Specific Gravity.....	7-90	ZX160LC-6N.....	12-6
Replacing Fuses.....	7-91	Shoe Types and Applications.....	12-7
Fuse Box.....	7-92	ZX160LC-6N.....	12-7
I. Miscellaneous.....	7-94	Bucket Types and Applications.....	12-8
Check and Replace Bucket Teeth.....	7-94	ZX160LC-6N.....	12-8
Change Bucket.....	7-100	Specifications.....	12-9
Convert Bucket Connection Into Face Shovel.....	7-101	ZX180LC-6N.....	12-9
Adjust Bucket Linkage.....	7-102	Working Ranges (Grouser shoe).....	12-10
Remove Travel Levers.....	7-103	ZX180LC-6N.....	12-10
Check and Replace Seat Belt.....	7-103	Shoe Types and Applications.....	12-11
Check Windshield Washer Fluid Level.....	7-104	ZX180LC-6N.....	12-11
Check Track Sag.....	7-105	Bucket Types and Applications.....	12-12
Clean and Replace Air Conditioner Filter.....	7-108	ZX180LC-6N.....	12-12
Check Air Conditioner.....	7-110	Specifications.....	12-13
Clean Cab Floor.....	7-112	ZX210-6N, 210LC-6N.....	12-13
Retighten Cylinder Head Bolt.....	7-113	Working Ranges (Grouser Shoe).....	12-14
Inspect and Adjust Valve Clearance.....	7-113	ZX210-6N, 210LC-6N.....	12-14
Measure Engine Compression Pressure.....	7-113	Shoe Types and Applications.....	12-15
Check Starter and Alternator.....	7-113	ZX210LC-6N.....	12-15
Check and Replace EGR Device.....	7-113	Bucket Types and Applications.....	12-16
EGR Cooler Cleaning.....	7-113	ZX210-6N, 210LC-6N.....	12-16
Check Turbo Charger.....	7-113	Specifications.....	12-17
Check and Clean Injector.....	7-114	ZX250LC-6N.....	12-17
Check Gas Damper.....	7-114		



## CONTENTS

---

Working Ranges.....	12-18	Change Hydraulic Oil and Replace Full-Flow Filter Element .....	13-23
ZX250LC-6N .....	12-18	Precautions for Crusher Operation .....	13-24
Shoe Types and Applications .....	12-19	Attachment.....	13-27
ZX250LC-6N .....	12-19	Allowable Weight Limits of Installed Attachment ....	13-27
Bucket Types and Applications .....	12-20	Attachment Connection Parts .....	13-29
ZX250LC-6N .....	12-20	Precautions for Arm Roll-In/Bucket Roll-In Combined Operation .....	13-30
Specifications.....	12-21	<b>INDEX.....</b>	<b>14-1</b>
ZX300LC-6N .....	12-21		
Working Ranges.....	12-22		
ZX300LC-6N .....	12-22		
Shoe Types and Applications .....	12-23		
ZX300LC-6N .....	12-23		
Bucket Types and Applications .....	12-24		
ZX300LC-6N .....	12-24		
Specifications.....	12-25		
ZX350LC-6N .....	12-25		
Working Ranges (Grouser Shoe) .....	12-26		
ZX350LC-6N .....	12-26		
Shoe Types and Applications .....	12-27		
ZX350LC-6N .....	12-27		
Bucket Types and Applications .....	12-28		
ZX350LC-6N .....	12-28		
Specifications.....	12-29		
ZX380LC-6N .....	12-29		
Working Ranges (Grouser Shoe) .....	12-30		
ZX380LC-6N .....	12-30		
Shoe Types and Applications .....	12-31		
ZX380LC-6N .....	12-31		
Bucket Types and Applications .....	12-32		
ZX380LC-6N .....	12-32		
<b>OPTIONAL ATTACHMENTS AND DEVICES.....</b>	<b>13-1</b>		
Using Pad Crawler Shoe .....	13-1		
Traveling and Other Cautions.....	13-2		
Transporting.....	13-3		
Precautions for Transporting Machines with Pad Crawler Shoes .....	13-3		
Long Arm Operation --- If Equipped.....	13-6		
Blade Lever .....	13-7		
Avoid Hitting Blade with Front-End Attachment.....	13-8		
Blade Maintenance .....	13-9		
Specifications.....	13-10		
ZX130-6N with Blade.....	13-10		
Working Ranges.....	13-11		
ZX130-6N with Blade.....	13-11		
Shoe Types and Applications .....	13-12		
ZX130-6N with Blade.....	13-12		
Bucket Teeth (Transverse-Type-Pin-Used Type) .....	13-13		
Attachment Pedal (Hydraulic Breaker) (Optional) .....	13-14		
Attachment Pedal (Hydraulic Crusher) (Optional).....	13-15		
Hydraulic Breaker, Hydraulic Crusher and Quick Coupler.....	13-16		
Piping for Breaker and Crusher .....	13-17		
Operational Procedures for Stop Valves and Selector Valve. ....	13-17		
Secondary Relief Pressure Adjustment .....	13-18		
Precautions for Breaker Operation.....	13-19		

---




# MACHINE NUMBERS


The manufacturing Nos. explained in this group is the individual number (serial No.) given to each machine and main components. These numbers are requested when inquiring any information on the machine and/or components. Fill these serial Nos. in the blank spaces in this group to immediately make them available upon request.

## Machine

TYPE : \_\_\_\_\_  
 PRODUCT IDENTIFICATION NUMBER : \_\_\_\_\_



M157-00-001




M157-12-008

## Product Identification Number



NOTE:

\*HCMDC150000030001\*  
 Marks to indicate the start and end of the PIN  
 PRODUCT IDENTIFICATION NUMBER (PIN)




M178-00-002

## Engine

TYPE : \_\_\_\_\_

MFG. NO. : \_\_\_\_\_



MDAA-00-001


## MACHINE NUMBERS

---

### SCR (Selective Catalytic Reduction) Catalyst


TYPE : \_\_\_\_\_

MFG. NO. : \_\_\_\_\_




ZX130-6N, 160LC-6N, 180LC-6N

MDC1-00-002



ZX210-6N, 210LC-6N, 250LC-6N

MDC1-00-001



ZX300LC-6N, 350LC-6N, 380LC-6N

MDC1-01-510

# MACHINE NUMBERS


## DOC (Diesel Oxidation Catalyst)

TYPE : \_\_\_\_\_

MFG. NO. : \_\_\_\_\_


TYPE : \_\_\_\_\_

MFG. NO. : \_\_\_\_\_




ZX130-6N, 160LC-6N, 180LC-6N

MDC1-00-002



ZX210-6N, 210LC-6N, 250LC-6N

MDC1-00-001



ZX300LC-6N, 350LC-6N, 380LC-6N

MDC1-01-510


# MACHINE NUMBERS

## Travel Motor

TYPE : \_\_\_\_\_

MFG. NO. : (L) \_\_\_\_\_

MFG. NO. : (R) \_\_\_\_\_




M178-07-047

## Swing Motor

TYPE : \_\_\_\_\_

MFG. NO. : \_\_\_\_\_




M178-07-086

# MACHINE NUMBERS

## Hydraulic Pump


TYPE : \_\_\_\_\_

MFG. NO. : \_\_\_\_\_




ZX130-6N

MDAA-07-072



ZX160LC-6N, 180LC-6N

M157-00-004



ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N,  
350LC-6N, 380LC-6N

MDAA-00-003





## SAFETY

---

### Recognize Safety Information

- These are the **SAFETY ALERT SYMBOLS**.
  - When you see these symbols on your machine or in this manual, be alert to the potential for personal injury.
  - Follow recommended precautions and safe operating practices.




SA-688

### Understand Signal Words

- On machine safety signs, signal words designating the degree or level of hazard - DANGER, WARNING, or CAUTION - are used with the safety alert symbol.
  - **DANGER** indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
  - **WARNING** indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
  - **CAUTION** indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.
  - **DANGER or WARNING safety signs** are located near specific hazards. General precautions are listed on **CAUTION safety signs**.
  - Some safety signs are occasionally used on this machine that do not use any of the designated signal words mentioned above after the safety alert symbol.



- To avoid confusing machine protection with personal safety messages, a signal word IMPORTANT indicates a situation which, if not avoided, could result in damage to the machine.
-  NOTE: Indicates an additional explanation for a piece of information.


SA-1223

## SAFETY

---

### Follow Safety Instructions

- Carefully read and follow all safety signs on the machine and all safety messages in this manual.
- Safety signs should be installed, maintained and replaced when necessary.
  - If a safety sign or this manual is damaged or missing, order a replacement from your authorized dealer in the same way you order other replacement parts (be sure to state machine model and serial number when ordering).
- Learn how to operate the machine and its controls correctly and safely.
- Allow only trained, qualified, authorized personnel to operate the machine.
- Keep your machine in proper working condition.
  - Unauthorized modifications of the machine may impair its function and/or safety and affect machine life.
  - Do not modify any machine parts without authorization. Failure to do so may deteriorate the safety, function, and/or service life of the part. In addition, personal accident, machine trouble, and/or damage to material caused by unauthorized modifications will void Hitachi Warranty Policy.
  - Never attempt to modify or disassemble the inlet/exhaust parts and the aftertreatment device. Avoid shocks to the element of the aftertreatment device, such as striking or dropping objects onto the element. Failure to do so may affect the exhaust gas purifying device, possibly damaging it or lowering its performance.
  - Do not use attachments and/or optional parts or equipment not authorized by Hitachi. Failure to do so may deteriorate the safety, function, and/or service life of the machine. In addition, personal accident, machine trouble, and/or damage to material caused by using unauthorized attachments and/or optional parts or equipment will void Hitachi Warranty Policy.
- The safety messages in this SAFETY chapter are intended to illustrate basic safety procedures of machines. However it is impossible for these safety messages to cover every hazardous situation you may encounter. If you have any questions, you should first consult your supervisor and/or your authorized dealer before operating or performing maintenance work on the machine.



SA-003

## SAFETY

---

### Prepare for Emergencies

- Be prepared for a fire or an accident.
  - Keep a first aid kit and fire extinguisher on hand.
  - Thoroughly read and understand the label attached on the fire extinguisher to use it properly.
  - To ensure that a fire extinguisher can be always used when necessary, check and service the fire extinguisher at the recommended intervals as specified in the fire extinguisher manual.
  - Establish emergency procedure guidelines to cope with fires and accidents.
  - Keep emergency numbers for doctors, ambulance service, hospital, and fire department posted near your telephone.



SA-437

---

### Wear Protective Clothing

- Wear close fitting clothing and safety equipment appropriate to the job.

You may need:

- A hard hat
- Safety shoes
- Safety glasses, goggles, or face shield
- Heavy gloves
- Hearing protection
- Reflective clothing
- Wet weather gear
- Respirator or filter mask

Be sure to wear the correct equipment and clothing for the job. Do not take any chances.

- Avoid wearing loose clothing, jewelry, or other items that can catch on control levers or other parts of the machine.
- Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating the machine.



SA-438

## SAFETY

---

### Protect Against Noise

- Prolonged exposure to loud noise can cause impairment or loss of hearing.
  - Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortably loud noises.



SA-434

---

### Inspect Machine

- Inspect your machine carefully each day or shift by walking around it before you start it to avoid personal injury.
  - In the walk-around inspection be sure to cover all points described in the "Inspect Machine Daily Before Starting" section in the operator's manual.



SA-435

## SAFETY

---

### General Precautions for the Cab


- Before entering the cab, thoroughly remove all dirt and/or oil such as mud, grease, soil or stones from the soles of your work boots. If any controls such as a pedal is operated while with dirt and/or oil on the soles of the operator's work boots, the operator's foot may slip off the pedal, possibly resulting in a personal accident.
- Do not mess up around the operator's seat with parts, tools, soil, stones, obstacles that may fold up or turn over, cans or lunch box. The levers or pedals become inoperable if obstacle jams in operation stroke of the travel levers/pedals, pilot control shut-off lever or control levers, which may result in serious injury or death.
- Avoid storing transparent bottles in the cab. Do not attach any transparent type window decorations on the windowpanes as they may focus sunlight, possibly starting a fire.
- Refrain from listening to the radio, or using music headphones or mobile telephones in the cab while operating the machine.
- Keep all flammable materials and/or explosives away from the machine.
- After using the ashtray, always cover it to extinguish the match and/or tobacco.
- Do not leave cigarette lighters in the cab. When the temperature in the cab increases, the lighter may explode.
- Correctly lay the floor mat specific to the machine. If another floor mat is used, it may be displaced and contact with the travel pedals during operation, resulting in serious injury or death.

## SAFETY

---

### Use Handholds and Steps

- Falling is one of the major causes of personal injury.
  - When you get on and off the machine, always face the machine and maintain a three-point contact with the steps and handrails.
  - Do not use any controls as hand-holds.
  - Never jump on or off the machine. Never mount or dismount a moving machine.
  - Before getting on or off the machine, check the condition of the steps and handrails for sticking or slippery material like grease or mud. Thoroughly remove such material if stuck. In addition, repair the damage to the steps and/or handrails. Retighten loose bolts.
  - Never get on and off the machine with tools in your hands.



SA-439

---

### Adjust the Operator's Seat

- A seat which is poorly adjusted for the individual operator, or the work to be undertaken, may quickly fatigue the operator leading to misoperation.
  - The seat should be adjusted whenever the operator of the machine changes.
  - The operator should be able to fully depress the pedals and to correctly operate the control levers with his back against the seat back.
  - If not, move the seat forward or backward, and check again.
  - Adjust the rear view mirror position so that the best rear visibility is obtained from the operator's seat. If the mirror is broken, immediately replace it with a new one.



SA-378

## SAFETY

---

### Ensure Safety Before Rising from or Leaving Operator's Seat

- Before rising from the operator's seat to open/close either side window or to adjust the seat position, be sure to first lower the front attachment to the ground and then move the pilot control shut-off lever to the LOCK position. Failure to do so may allow the machine to unexpectedly move when a body part unintentionally comes in contact with a control lever and/or pedal, possibly resulting in serious personal injury or death.
- Before leaving the machine, be sure to first lower the front attachment to the ground and then move the pilot control shut-off lever to the LOCK position. Turn the key switch OFF to stop the engine.
- Before leaving the machine, close all windows, doors, and access covers and lock them.

---

### Fasten Your Seat Belt

- If the machine should overturn, the operator may become injured and/or thrown from the cab. Additionally the operator may be crushed by the overturning machine, resulting in serious injury or death.
  - Prior to operating the machine, thoroughly examine webbing, buckle and attaching hardware. If any item is damaged or worn, replace the seat belt or component before operating the machine.
  - Be sure to remain seated with the seat belt securely fastened at all times when the machine is in operation to minimize the chance of injury from an accident.
  - We recommend that the seat belt is replaced every three years regardless of its apparent condition.



SA-237

## SAFETY

---

### Move and Operate Machine Safely

- Bystanders can be run over.
  - Take extra care not to run over bystanders. Confirm the location of bystanders before moving, swinging, or operating the machine.
  - Always keep the travel alarm and horn in working condition (if equipped). It warns people when the machine starts to move.
  - Use a signal person when moving, swinging, or operating the machine in congested areas. Coordinate hand signals before starting the machine.
  - Use appropriate illumination. Check that all lights are operable before operating the machine. If any faulty illumination is present, immediately repair it.
  - Ensure the cab door, windows, doors and covers are securely locked.
  - Check the mirrors and the monitor in the cab for problems.  
If there is, replace the problem part (s) or clean the mirror, camera lens and the monitor display.  
Refer to Rear View Monitor section for information on cleaning the camera lens and the monitor display.



SA-426

---

### Operate Only from Operator's Seat

- Inappropriate engine starting procedures may cause the machine to runaway, possibly resulting in serious injury or death.
  - Start the engine only when seated in the operator's seat.
  - Never start the engine while standing on the track or ground.
  - Do not start engine by shorting across starter terminals.
  - Before starting the engine, confirm that all control levers are in neutral.
  - Before starting the engine, confirm the safety around the machine and sound the horn to alert bystanders.



SA-444



## SAFETY

---

### Jump Starting

- Battery gas can explode, resulting in serious injury.
  - If the engine must be jump started, be sure to follow the instructions shown in the “OPERATING THE ENGINE” chapter in the operator’s manual.
  - The operator must be in the operator’s seat so that the machine will be under control when the engine starts. Jump starting is a two-person operation.
  - Never use a frozen battery.
  - Failure to follow correct jump starting procedures could result in a battery explosion or a runaway machine.



SA-032

---

### Keep Riders off Machine

- Riders on machine are subject to injury such as being struck by foreign objects and being thrown off the machine.
  - Only the operator should be on the machine. Keep riders off.
  - Riders also obstruct the operator’s view, resulting in the machine being operated in an unsafe manner.




SA-379

## SAFETY

---

### Precautions for Operations

- Investigate the work site before starting operations.
    - Be sure to wear close fitting clothing and safety equipment appropriate for the job, such as a hard hat, etc. when operating the machine.
    - Keep bystanders and obstacles clear of the area of machine operation.
- Keep persons other than the operator away from areas where there is danger, such as from flying objects. Always be aware of the surroundings while operating. When working in a small area surrounded by obstacles, take care not to hit the upperstructure against obstacles.
- When loading onto trucks, bring the bucket over the truck beds from the rear side. Take care not to swing the bucket over the cab or over any person.



M178-05-007

## SAFETY

---

### Investigate Job Site Beforehand

- When working at the edge of an excavation or on a road shoulder, the machine could tip over, possibly resulting in serious injury or death.
  - Investigate the configuration and ground conditions of the job site beforehand to prevent the machine from falling and to prevent the ground, stockpiles or banks from collapsing.
  - Make a work plan. Use machines appropriate to the work and job site.
  - Reinforce ground, edges and road shoulders as necessary. Keep the machine well back from the edges of excavations and road shoulders.
  - When working on an incline or on a road shoulder, employ a signal person as required.
  - Confirm that your machine is equipped with a FOPS cab before working in areas where the possibility of falling stones or debris exist.
  - When the ground footing is weak, reinforce the ground before starting work.
  - When working on frozen ground, be extremely alert. As ambient temperatures rise, footing becomes loose and slippery.
  - Beware the possibility of fire when operating the machine near flammable materials such as dry grass.




SA-380

## SAFETY

---

- Make sure the worksite has sufficient strength to firmly support the machine.  
When working close to an excavation or at road shoulders, operate the machine with the tracks positioned perpendicular to the cliff face with travel motors at the rear, so that the machine can more easily evacuate if the cliff face collapses.
- If working on the bottom of a cliff or a high bank is required, be sure to investigate the area first and confirm that no danger of the cliff or bank collapsing exists. If any possibility of cliff or bank collapsing exists, do not work on the area.
- Soft ground may collapse when the machine is operated on it, possibly causing the machine to tip over. When working on soft ground is required, be sure to reinforce the ground first using steel plates strong and firm enough to easily support the machine.
- Note that there is always a possibility of machine tipping over when working on rough terrain or on slopes. Prevent machine tipping over from occurring. When operating on rough terrain or on slopes:
  - Reduce the engine speed.
  - Select slow travel speed mode.
  - Operate the machine slowly and be cautious with machine movements.




M104-05-016

---

### Install OPG Guard

In case the machine is operated in areas where the possibilities of falling stones or debris exist, equip Hitachi OPG guard. Consult your authorized dealer for installing the OPG guard. In order not to impair operator protective structure: Replace damaged OPG guard. Never attempt to repair or modify the guard.

OPG: Operator Protective Guard



SA-490

---

### Restriction of Attachment Installation

Do not install an attachment which exceeds the specified weight for the machine structure.

## SAFETY

---

### Provide Signals for Jobs Involving Multiple Machines

- For jobs involving multiple machines, provide signals commonly known by all personnel involved. Also, appoint a signal person to coordinate the job site. Make sure that all personnel obey the signal person's directions.




SA-481

---

### Confirm Direction of Machine to Be Driven

- Incorrect travel pedal/lever operation may result in serious injury or death.
  - Before driving the machine, confirm the position of the undercarriage in relation to the operator's position. If the travel motors are located in front of the cab, the machine will move in reverse when travel pedals/levers are operated facing forwards.




SA-491


## SAFETY

### Drive Machine Safely


- Before driving the machine, always confirm that the travel levers/pedals direction corresponds to the direction you wish to drive.
  - Be sure to detour around any obstructions.
  - Avoid traveling over obstructions. Soil, fragments of rocks, and/or metal pieces may scatter around the machine. Do not allow personnel to stay around the machine while traveling.
- Driving on a slope may cause the machine to slip or overturn, possibly resulting in serious injury or death.
  - Never attempt to ascend or descend 35 degrees or steeper slopes.
  - Be sure to fasten the seat belt.
  - When driving up or down a slope, keep the bucket facing the direction of travel, approximately 0.2 to 0.3 m (see A on the right) above the ground.
  - If the machine starts to skid or becomes unstable, immediately lower the bucket to the ground and stop.
  - Driving across the face of a slope or steering on a slope may cause the machine to skid or turnover. If the direction must be changed, move the machine to level ground, then, change the direction to ensure safe operation.




SA-657



SA-658



SA-441




SA-590

## SAFETY

- Avoid swinging the upperstructure on slopes. Never attempt to swing the upperstructure downhill. The machine may tip over. If swinging uphill is unavoidable, carefully operate the upperstructure and boom at slow speed.
- If the engine stalls on a slope, immediately lower the bucket to the ground. Return the control levers to neutral. Then, restart the engine.
- Be sure to thoroughly warm up the machine before ascending steep slopes. If hydraulic oil has not warmed up sufficiently, sufficient performance may not be obtained.
- Use a signal person when moving, swinging or operating the machine in congested areas. Coordinate hand signals before starting the machine.
- Before moving machine, determine which way to move travel pedals/levers for the direction you want to go. When the travel motors are in the rear, pushing down on the front of the travel pedals or pushing the levers forward moves the machine forward, towards the idlers. An arrow-mark seal is stuck on the inside surface of the side frame to indicate the machine front direction.
- Select a travel route that is as flat as possible. Steer the machine as straight as possible, making small gradual changes in direction.
- Before traveling on them, check the strengths of bridges and road shoulders, and reinforce if necessary.
- Use wood plates in order not to damage the road surface. Be careful of steering when operating on asphalt roads in summer.
- When crossing train tracks, use wood plates in order not to damage them.
- Do not make contact with electric wires or bridges.
- When crossing a river, measure the depth of the river using the bucket, and cross slowly. Do not cross the river when the depth of the river is deeper than the upper edge of the upper roller.
- When traveling on rough terrain, reduce engine speed. Select slow travel speed. Slower speed will reduce possible damage to the machine.
- Avoid operations that may damage the track and undercarriage components.
- During freezing weather, always clean snow and ice from track shoes before loading and unloading the machine, to prevent the machine from slipping.



M104-05-008



M178-03-001



SA-011

## SAFETY


---

### Avoid Injury from Rollaway Accidents


- Death or serious injury may result if you attempt to mount or stop a moving machine.

To avoid rollaways:

- Select level ground when possible to park the machine.
- Do not park the machine on a gradient.
- Lower the bucket and/or other work tools to the ground.
- Turn the auto-idle switch OFF.
- Run the engine at slow idle speed without load for 5 minutes to cool down the engine.
- Stop the engine and remove the key from the key switch.
- Pull the pilot control shut-off lever to LOCK position.
- Block both tracks and lower the bucket to the ground. Thrust the bucket teeth into the ground if you must park on a gradient.
- Position the machine to prevent rolling.
- Park at a reasonable distance from other machines.



SA-391



SA-2273



## SAFETY

---

### Avoid Injury from Back-Over and Swing Accidents


- If any person is present near the machine when backing or swinging the upperstructure, the machine may hit or run over that person, resulting in serious injury or death.

To avoid back-over and swing accidents:


- Always look around BEFORE YOU BACK UP AND SWING THE MACHINE. BE SURE THAT ALL BYSTANDERS ARE CLEAR.
- Keep the travel alarm in working condition (if equipped). ALWAYS BE ALERT FOR BYSTANDERS MOVING INTO THE WORK AREA. USE THE HORN OR OTHER SIGNAL TO WARN BYSTANDERS BEFORE MOVING MACHINE.
- USE A SIGNAL PERSON WHEN BACKING UP IF YOUR VIEW IS OBSTRUCTED. ALWAYS KEEP THE SIGNAL PERSON IN VIEW.

Use hand signals, which conform to your local regulations, when work conditions require a signal person.

- No machine motions shall be made unless signals are clearly understood by both signal person and operator.
- Learn the meanings of all flags, signs, and markings used on the job and confirm who has the responsibility for signaling.
- Keep windows, mirrors, and lights clean and in good condition.
- Dust, heavy rain, fog, etc., can reduce visibility. As visibility decreases, reduce speed and use proper lighting.
- Read and understand all operating instructions in the operator's manual.



SA-383




SA-384

## SAFETY

---

### Keep People Clear from Working Area

- People around the operating machine may be hit severely by the swinging front attachment or counterweight, be caught in other objects, and/or be struck by flying objects, resulting in serious injury or death.
- Set up barriers and/or put a "NO ADMISSION" sign at the machine operating site and areas exposed by flying objects to prevent anyone from entering the work area.
- Before operating the machine, set up barriers to the sides and rear area of the bucket swing radius to prevent anyone from entering the work area.



SA-386

### Never Position the Bucket Over Anyone

- Never lift, move, or swing the bucket above anyone or above the truck cab. Serious injury or machine damage may result due to bucket load spill or due to collision with the bucket.




SA-487

## SAFETY

### Avoid Undercutting

- In order to retreat from the edge of an excavation if the footing should collapse, always position the undercarriage perpendicular to the edge of the excavation with the travel motors at the rear.
- If the footing starts to collapse and if retreat is not possible, do not panic. Often, the machine can be secured by lowering the front attachment, in such cases.



SA-488


### Avoid Tipping

**DO NOT ATTEMPT TO JUMP CLEAR OF TIPPING MACHINE  
--- SERIOUS OR FATAL CRUSHING INJURIES WILL RESULT**


**MACHINE WILL TIP OVER FASTER THAN YOU CAN JUMP  
FREE**

**FASTEN YOUR SEAT BELT**

- The danger of tipping is always present when operating on a grade, possibly resulting in serious injury or death. To avoid tipping:
- Be extra careful before operating on a gradient.
  - Prepare machine operating area flat.
  - Keep the bucket low to the ground and close to the machine.
  - Reduce operating speeds to avoid tipping or slipping.
  - Avoid changing direction when traveling on grades.
  - NEVER attempt to travel across a grade steeper than 15 degrees if crossing the grade is unavoidable.
  - Reduce swing speed as necessary when swinging loads.
- Be careful when working on frozen ground.
  - Temperature increases will cause the ground to become soft and make ground travel unstable.



SA-012



SA-440

## SAFETY

---

### Never Undercut a High Bank


- The edges could collapse or a land slide could occur causing serious injury or death.



SA-489

### Dig with Caution

- Accidental severing of underground cables or gas lines may cause an explosion and/or fire, possibly resulting in serious injury or death.
  - Before digging check the location of cables, gas lines, and water lines.
  - Keep the minimum distance required, by law, from cables, gas lines, and water lines.
  - If a fiber optic cable should be accidentally severed, do not look into the end. Doing so may result in serious eye injury.
  - Contact your local "diggers hot line" if available in your area, and/or the utility companies directly. Have them mark all underground utilities.



SA-382

### Operate with Caution

- If the front attachment or any other part of the machine hits against an overhead obstacle, such as a bridge, both the machine and the overhead obstacle will be damaged, and personal injury may result as well.
  - Take care to avoid hitting overhead obstacles with the boom or arm.




SA-389

## SAFETY

---

### Avoid Power Lines

- Serious injury or death can result if the machine or front attachments are not kept a safe distance from electric lines.
- When operating near an electric line, never move any part of the machine or load to within 3 m plus twice the line insulator length of overhead wires.
- Check and comply with any local regulations that may apply.
- Wet ground will expand the area that could cause any person on it to be affected by electric shock. Keep all bystanders or co-workers away from the site.



SA-381

### Precautions for Lightning

- Lightning may strike the machine.

If lightning comes close, immediately stop the operation, and take the following action.

- When you are around the machine or operating cab-less machine, evacuate to a safe place far away from the machine.
- When you are in the cab, stay in the cab until lightning has passed and safety is assured. Close the cab doors and windows. Lower the bucket to the ground, and stop the engine. Put your hands on your lap to avoid contact with any metal surfaces. Never go out of the cab.

If lightning strikes the machine or near the machine, check all of the machine safety devices for any failure after lightning has passed and safety is assured. If any trouble is found, operate the machine only after repairing it.




SA-2715

## SAFETY

---

### Object Handling

- If a lifted load should fall, any person nearby may be struck by the falling load or may be crushed underneath it, resulting in serious injury or death.
  - When using the machine for craning operations, be sure to comply with all local regulations.
  - Do not use damaged chains or frayed cables, slings, or ropes.
  - Before craning, position the upperstructure with the travel motors at the rear.
  - Move the load slowly and carefully. Never move it suddenly.
  - Keep all persons well away from the load.
  - Never move a load over a person's head.
  - Do not allow anyone to approach the load until it is safely and securely situated on supporting blocks or on the ground.
  - Never attach a sling or chain to the bucket teeth. They may come off, causing the load to fall.




SA-014

## SAFETY

---

### Protect Against Flying Debris and Falling Object

- During hammer operation, debris from earth, rock or metal may fly in all directions, resulting in a serious personal injury or death.
  - When driving the connecting pins in or out, wear goggles or safety glasses, hard hat and face shield.



SA-432

- During machine operation, debris from earth, rock or metal may fly off from the track and bucket, resulting in a serious personal injury or death.
  - Ensure nobody presents in or around the work area while machine is operating.



SA-344

- Falling of accumulated earth or dirt onto people may result in a serious personal injury or death.
  - Before performing maintenance or inspection under carriage, remove accumulated debris.



SA-527

## SAFETY

---

### Park Machine Safely

To avoid accidents:

- Park the machine on a firm, level surface.
- Lower the bucket to the ground.
- Turn auto-idle switch OFF.
- Run engine at slow idle speed without load for 5 minutes.
- Turn key switch to OFF to stop engine.
- Remove the key from the key switch.
- Pull the pilot control shut-off lever to the LOCK position.
- Close windows, roof vent, and cab door.
- Lock all access doors and compartments.



SA-390

### Handle Fluids Safely—Avoid Fires

- Handle fuel with care; it is highly flammable. If fuel ignites, an explosion and/or a fire may occur, possibly resulting in serious injury or death.
  - Do not refuel the machine while smoking or when near open flame or sparks.
  - Always stop the engine before refueling the machine.
  - Fill the fuel tank outdoors.
- All fuels, most lubricants, and some coolants are flammable.
  - Store flammable fluids well away from fire hazards.
  - Do not incinerate or puncture pressurized containers.
  - Do not store oily rags; they can ignite and burn spontaneously.
  - Securely tighten the fuel and oil filler caps.



SA-018



SA-019



## SAFETY

---

### Transport Safely

- Take care the machine may turn over when loading or unloading the machine onto or off of a truck or trailer.
  - Observe the related regulations and rules for safe transportation.
  - Select an appropriate truck or trailer for the machine to be transported.
  - Be sure to use a signal person.
  - Always follow the following precautions for loading or unloading:
    1. Select solid and level ground.
    2. Always use a ramp or deck strong enough to support the machine weight.
    3. Turn auto-idle switch OFF.
    4. Always select the slow speed mode with the travel mode switch.
    5. Never load or unload the machine onto or off a truck or trailer using the front attachment functions when driving up or down the ramp.
    6. Never steer the machine while on the ramp. If the traveling direction must be changed while on the ramp, unload the machine from the ramp, reposition the machine on the ground, then try loading again.
    7. At the top end of the ramp where it meets the flatbed, there is a sudden bump. Take care when traveling over it.
    8. Place blocks in front of and behind the tires. Securely fasten the machine to the truck or trailer deck with wire ropes.



SA-395

Be sure to further follow the details described in the "TRANSPORTING" section.

## SAFETY

---

### Practice Safe Maintenance

To avoid accidents:

- Understand service procedures before starting work.
- Keep the work area clean and dry.
- Do not spray water or steam inside cab.
- Never lubricate or service the machine while it is moving.
- Keep hands, feet and clothing away from power-driven parts.

Before servicing the machine:

1. Park the machine on a firm, level surface.
2. Lower the bucket to the ground.
3. Turn the auto-idle switch off.
4. Run the engine at slow idle speed without load for 5 minutes.
5. Turn the key switch to OFF to stop engine.
6. Relieve the pressure in the hydraulic system by moving the control levers several times.
7. Remove the key from the key switch.
8. Attach a "Do Not Operate" tag on the control lever.
9. Pull the pilot control shut-off lever to the LOCK position.
10. Allow the engine to cool.

- If a maintenance procedure must be performed with the engine running, do not leave the machine unattended.
- If the machine must be raised, maintain a 90 to 110° angle between the boom and arm. Securely support any machine elements that must be raised for service work.
- Inspect certain parts periodically and repair or replace as necessary. Refer to the section discussing that part in the "MAINTENANCE" chapter of this manual.
- Keep all parts in good condition and properly installed.
- Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.
- When cleaning parts, always use nonflammable detergent oil. Never use highly flammable oil such as fuel oil and gasoline to clean parts or surfaces.
- Turn the battery disconnect switch to OFF before adjusting the electrical systems or performing welding on the machine.



SA-028



SA-527

## SAFETY

---

- Sufficiently illuminate the work site. Use a maintenance work light when working under or inside the machine.
- Always use a work light protected with a guard. If the light bulb is broken, spilled fuel, oil, antifreeze fluid, or window washer fluid may catch fire.



SA-037

---

### Warn Others of Service Work

- Unexpected machine movement can cause serious injury.
  - Before performing any work on the machine, attach a “Do Not Operate” tag on the control lever. This tag is available from your authorized dealer.



SS3076175

---

### Support Machine Properly

- Never attempt to work on the machine without securing the machine first.
  - Always lower the attachment to the ground before you work on the machine.
  - If you must work on a lifted machine or attachment, securely support the machine or attachment. Do not support the machine on cinder blocks, hollow tires, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack.




SA-527

## SAFETY


---

### Stay Clear of Moving Parts

- Entanglement in moving parts can cause serious injury.
  - To prevent accidents, care should be taken to ensure that hands, feet, clothing, jewelry and hair do not become entangled when working around rotating parts.



SA-026



SA-2294

---

### Prevent Parts from Flying

- Grease in the track adjuster is under high pressure. Failure to follow the precautions below may result in serious injury, blindness, or death.
  - Do not attempt to remove GREASE FITTING or VALVE ASSEMBLY.
  - Do not attempt to remove the valve stop plate.
  - As pieces may fly off, be sure to keep body and face away from valve.
  - Never attempt to disassemble the track adjuster. Inadvertent disassembling of the track adjuster may cause the parts such as a spring to fly off, possibly resulting in severe personal injury or death.
- Travel reduction gears are under pressure.
  - As pieces may fly off, be sure to keep body and face away from AIR RELEASE PLUG to avoid injury.
  - GEAR OIL is hot. Wait for GEAR OIL to cool, then gradually loosen AIR RELEASE PLUG to release pressure.




SA-344

## SAFETY

---

### Avoid Injury from Attachment Falling Accident

- Stored attachments such as buckets, hydraulic hammers, and blades can fall and cause serious injury or death.
  - To avoid possible personal injury from attachment falling accident, use a platform when replacing an attachment.
  - Securely store attachments such as a bucket, blade, breaker and other parts to prevent falling.
  - Keep children and bystanders away from attachment storage areas.



SA-034

---

### Prevent Burns

Hot spraying fluids:

- After operation, engine coolant is hot and under pressure. Hot water or steam is contained in the engine, expansion tank and heater lines. Skin contact with escaping hot water or steam can cause severe burns.
  - Avoid possible injury from hot spraying water. DO NOT remove the expansion tank cap until the engine is cool. When opening, turn the cap slowly to the stop. Allow all pressure to be released before removing the cap.
  - The hydraulic oil tank is pressurized. Again, be sure to release all pressure before removing the cap.



SA-039

Hot fluids and surfaces:

- Engine oil, gear oil and hydraulic oil also become hot during operation. The engine, hoses, lines and other parts become hot as well.
  - Wait for the oil and components to cool before starting any maintenance or inspection work.



SA-225

## SAFETY

### Replace Rubber Hoses Periodically

- Rubber hoses that contain flammable fluids under pressure may break due to aging, fatigue, and abrasion. It is very difficult to gauge the extent of deterioration due to aging, fatigue, and abrasion of rubber hoses by inspection alone.
  - Periodically replace the rubber hoses. (See the page of "Periodic replacement of parts" in the operator's manual.)
- Failure to periodically replace rubber hoses may cause a fire, fluid injection into skin, or the front attachment to fall on a person nearby, which may result in severe burns, gangrene, or otherwise serious injury or death.




SA-019

### Avoid High-Pressure Fluids


- Fluids such as diesel fuel or hydraulic oil under pressure can penetrate the skin or eyes causing serious injury, blindness or death.
  - Avoid this hazard by relieving pressure before disconnecting hydraulic or other lines.
  - Tighten all connections before applying pressure.
  - Search for leaks with a piece of cardboard; take care to protect hands and body from high-pressure fluids. Wear a face shield or goggles for eye protection.
  - If an accident occurs, see a doctor familiar with this type of injury immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result.



SA-031



SA-292



SA-044

## SAFETY

---

### Prevent Fires

Check for Oil Leaks:

- Fuel, hydraulic oil and lubricant leaks can lead to fires.
  - Check for oil leaks due to missing or loose clamps, kinked hoses, lines or hoses that rub against each other, damage to the oil cooler, and loose oil cooler flange bolts.
  - Tighten, repair or replace any missing, loose or damaged clamps, lines, hoses, oil cooler and oil cooler flange bolts.
  - Do not bend or strike high-pressure lines.
  - Never install bent or damaged lines, pipes, or hoses.
  - Replace fuel hoses and hydraulic hoses periodically even if there is no abnormality in their external appearance.



SA-019

Check for Shorts:

- Short circuits can cause fires.
  - Clean and tighten all electrical connections.
  - Check before each shift or after eight (8) to ten (10) hours operation for loose, kinked, hardened or frayed electrical cables and wires.
  - Check before each shift or after eight (8) to ten (10) hours operation for missing or damaged terminal caps.
  - **DO NOT OPERATE MACHINE** if cable or wires are loose, kinked, etc.
  - Never attempt to modify electric wirings.

## SAFETY

---

### Clean up Flammable Materials:

- Spilled fuel and oil, trash, grease, debris, accumulated coal dust, and other flammable materials may cause fires.
  - Prevent fires by inspecting and cleaning the machine daily, and by removing adhered oil or accumulated flammable materials immediately. Check and clean high temperature parts such as the exhaust outlet and muffler earlier than the normal interval.
  - Do not wrap high temperature parts such as a muffler or exhaust pipe with oil absorbents.
  - Do not store oily cloths as they are vulnerable to catching fire.
  - Keep flammable materials away from open flames.
  - Do not ignite or crush a pressurized or sealed container.
  - Wire screens may be provided on openings on the engine compartment covers to prevent flammable materials such as dead leaves from entering. However, flammable materials which have passed through the wire screen may cause fires. Check and clean the machine every day and immediately remove accumulated flammable materials.

### Check Key Switch:

- If a fire breaks out, failure to stop the engine will escalate the fire, hampering fire fighting.
  - Always check key switch function before operating the machine every day:
    1. Start the engine and run it at slow idle.
    2. Turn the key switch to the OFF position to confirm that the engine stops.
  - If any abnormalities are found, be sure to repair them before operating the machine.

### Check Heat Shields:

- Damaged or missing heat shields may lead to fires.
  - Damaged or missing heat shields must be repaired or replaced before operating the machine.
  - If hydraulic hoses are broken while the engine cover is open, splattered oil on the high temperature parts such as muffler may cause fire. Always close the engine cover while operating the machine.



## SAFETY

### Evacuating in Case of Fire

- If a fire breaks out, evacuate the machine in the following way:
  - Stop the engine by turning the key switch to the OFF position if there is time.
  - Use a fire extinguisher if there is time.
  - Exit the machine.
- In an emergency, if the cab door or front window can not be opened, break the front or rear window pane with the emergency evacuation hammer to escape from the cab. Refer to the explanation pages on the Emergency Evacuation Method.




SA-393



SS-1510

### Beware of Exhaust Fumes

- Prevent asphyxiation. Engine exhaust fumes can cause sickness or death.
  - If you must operate in a building, be sure there is adequate ventilation. Either use an exhaust pipe extension to remove the exhaust fumes or open doors and windows to bring enough outside air into the area.
  - White smoke may be generated during the aftertreatment device regeneration. Do not attempt to do aftertreatment device manual regeneration in a badly ventilated indoors.



SA-016

## SAFETY

---

### Precautions for Welding and Grinding

- Welding may generate gas and/or small fires.
  - Be sure to perform welding in a well ventilated and prepared area. Store flammable materials in a safe place before starting welding.
  - Only qualified personnel should perform welding. Never allow an unqualified person to perform welding.
  - Turn the battery disconnect switch to the OFF position before performing welding on the machine.
- Grinding on the machine may create fire hazards. Store flammable materials in a safe place before starting grinding.
- After finishing welding and grinding, recheck that there are no abnormalities such as the area surrounding the welded area still smoldering.



SA-818

## SAFETY

---

### Avoid Heating Near Pressurized Fluid Lines

- Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders.
- Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials.
- Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area. Install temporary fire-resistant guards to protect hoses or other materials before engaging in welding, soldering, etc.



SA-030

### Avoid Applying Heat to Lines Containing Flammable Fluids

- Do not weld or flame cut pipes or tubes that contain flammable fluids.
- Clean pipes and tubes thoroughly with non-flammable solvent before welding or flame cutting.

---

### Precautions for Handling Accumulator and Gas Damper

High-pressure nitrogen gas is sealed in the accumulator and the gas damper. Inappropriate handling may cause explosion, possibly resulting in serious injury or death.

Strictly comply with the following items:

- Do not disassemble the unit.
- Keep the units away from open flames and fire.
- Do not bore a hole, do not cut by torch.
- Avoid giving shocks by hitting or rolling the unit.
- Before disposing of the unit, sealed gas must be released. Consult your authorized dealer.

## SAFETY

---

### Remove Paint Before Welding or Heating

- Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch. If inhaled, these fumes may cause sickness.
  - Avoid potentially toxic fumes and dust.
  - Do all such work outside or in a well-ventilated area. Dispose of paint and solvent properly.
  - Remove paint before welding or heating:
    1. If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
    2. If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable materials from area. Allow fumes to disperse at least 15 minutes before welding or heating.



SA-029

### Beware of Asbestos and Silica Dust and Other Contamination

- Take care not to inhale dust produced in the work site. Inhalation of asbestos fibers may be the cause of lung cancer. Inhalation of silica dust or other contaminations may cause sickness.
  - Depending on the work site conditions, the risk of inhaling asbestos fiber, silica dust or other contaminations may exist. Spray water to prevent asbestos fibers, silica dust or other contaminations from becoming airborne. Do not use compressed air.
  - When operating the machine in a work site where asbestos fibers, silica dust or other contaminations might be present, be sure to operate the machine upwind, and wear a mask rated to prevent the inhalation of asbestos, silica dust or other contaminations.
  - Keep bystanders out of the work site during operation.
  - Asbestos fibers might be present in imitation parts. Use only genuine Hitachi Parts.



SA-029

## SAFETY

---

### Prevent Battery Explosions

- Battery gas can explode.
  - Keep sparks, lighted matches, and flame away from the top of battery.
  - Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.
  - Do not charge a frozen battery; it may explode. Warm the battery to 16 °C ( 60 °F ) first.
  - Do not continue to use or charge the battery when electrolyte level is lower than specified. Explosion of the battery may result.
  - Loose terminals may produce sparks. Securely tighten all terminals.
  - Connect terminals to the correct electrical poles. Failure to do so may cause damage to the electrical parts or fire.
- Battery electrolyte is poisonous. If the battery should explode, battery electrolyte may be splashed into eyes, possibly resulting in blindness.
  - Be sure to wear eye protection when checking electrolyte specific gravity.



SA-032

---

### Service Air Conditioning System Safely

- If spilled onto skin, refrigerant may cause a cold contact burn.
  - Refer to the instructions described on the container for proper use when handling the refrigerant.
  - Use a recovery and recycling system to avoid leaking refrigerant into the atmosphere.
  - Never touch the refrigerant.



SA-405

## SAFETY

---

### Handle Chemical Products Safely

- Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with your machine include such items as lubricants, coolants, paints, and adhesives.
  - Safety Data Sheet (SDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.
  - Check the SDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and use recommended equipment.
  - See your authorized dealer for SDS's (available only in English) on chemical products used with your machine.




SA-2579

---

### Dispose of Waste Properly

- Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with Hitachi equipment includes such items as oil, fuel, coolant, DEF/AdBlue®, brake fluid, filters, and batteries.
  - Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.
  - Do not pour waste onto the ground, down a drain, or into any water source.
  - Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.
  - Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your authorized dealer.



SA-226

## SAFETY

---

### Never Ride Attachment

Never allow anyone to ride on attachments or the load. This is an extremely dangerous practice.

---

### Notes on Aftertreatment Device

#### About Aftertreatment Device

The aftertreatment device removes particulate matter (PM) and NOx (Nitrogen Oxide) from the exhaust gas. Follow the instructions below to prevent the aftertreatment device from being damaged.

**⚠ WARNING: Exhaust gas from the aftertreatment device, muffler, exhaust piping and tail piping becomes hot during and right after engine running and regeneration of aftertreatment device. Keep away from the exhaust system or hot gas from the exhaust piping during regeneration. Be careful to avoid skin contact with exhaust gas. It may cause severe burns.**

- White smoke may be generated during aftertreatment device regeneration. Do not attempt to perform aftertreatment device manual regeneration in a badly ventilated area.
- Do not touch water coming directly out of the aftertreatment device. The water is mildly-acidic by oxidation catalyst mounted in the aftertreatment device. If filter water spills on your skin, immediately flush it out with clean water.

---

### Precautions for Communication Terminal


Electrical wave transmitted from the communication terminal may cause malfunction of other electronic devices. Inquire to the device manufacturer for information on electrical wave disturbance when using an electronic device near the communication terminal.

## SAFETY

### Notes on Protection of Operator's Station when the Machine Rolls Over

The cab corresponds to the structure to protect the operator by absorbing impact energy when the machine rolls over (Roll-Over Protective Structure (ROPS)).

However, when modifying the machine or installing a special attachment causing the machine mass to exceed the maximum operating mass described in the ROPS certification, the cab cannot fulfill its protective function, possibly causing serious injury or death.




SS-3636

In order to safeguard the protective structure, follow the instructions below.

- Consult your authorized dealer before welding parts or drilling a hole on the cab, which possibly reduces the cab strength.
- Be sure to always fasten the seat belt when operating the machine. If the machine rolls over without operator fastening the seat belt, the operator may become injured, may be thrown out from the cab and/or may become crushed under the machine even though the cab has the protective structure.

The ROPS certification is valid under the following conditions.

- The machine mass is lower than the maximum operating mass described in the ROPS certification.
- The ROPS is properly installed.
- No modification is made to the ROPS.
- The ROPS is free from damage.




SS-3671



## SAFETY SIGNS

All safety signs and their locations affixed on the machine are illustrated in this group. Make sure of the contents described in the safety signs through reading actual ones affixed on the machine to ensure safe machine operation. Always keep the safety signs clean. In case a safety sign is broken or lost, immediately, obtain a new replacement and affix it again in position on the machine. Use the part No. indicated under the right corner of each safety sign illustration when placing an order of it to the Hitachi dealer.




SS-3738

## SAFETY SIGNS

1.

### WARNING!


Prior to operation, maintenance, disassembling, and transportation of the machine, be sure to read and understand the Operator's Manual.



SS-1616

2.

Sign indicates an electrocution hazard if machine is brought too near electric power lines.  
Keep a safe distance from electric power lines.



SS-862

3.

Sign indicates a hazard from falling window.  
After raising window, be sure to lock it in place with lock pins.




SS-863

## SAFETY SIGNS

4.


When moving the seat height/tilt lever downward, press the lever grip with a palm from the top side. Do not grasp the lever grip to operate the lever, possibly resulting in pinch of your fingers into the seat stand.



SS-955

5.


If the machine should overturn, the operator may become injured and/or throw from the cab and/or crushed by the overturning machine.



SS3088058

6.

Do not extend your hands or head from the window. Your hands or head may come in contact with the boom.



SS-859

7.

Be careful to avoid skin contact with bight temperature part during operation or immediately after stopping the machine. Otherwise burns may result.



SSYA00036144

## SAFETY SIGNS

8.

Sign indicates a hazard of being hit by the working device of the machine.

Keep away from machine during operation.



SS3092349

9.

Sign indicates a hazard of a flying plug from track adjuster that could cause injury.

Read manual before adjusting track for safe and proper handling.



SS-408

10.

Sign indicates a burn hazard from spurting hot water or oil if radiator or hydraulic oil tank is uncapped while hot.

Allow radiator or hydraulic oil tank to cool before removing cap.



SS-864

## SAFETY SIGNS

11.

Sign indicates a hazard of falling.  
Do not stand on this place.



SS3092351

12.


Sign indicates a crush hazard by rotation of upper structure of the machine.  
Keep away from swinging area of machine.



SS-024

13.

Sign indicates a burn hazard from spurting hot water or oil if radiator or hydraulic oil tank is uncapped while hot.  
Allow radiator or hydraulic oil tank to cool before removing cap.




SS-3594

## SAFETY SIGNS

14.


Sign indicates a hazard of rotating parts, such as fan.  
Turn off before inspection and maintenance.



SSYA00009455

15.

Sign indicates a hazard of rotating parts, such as fan.  
Turn off before inspection and maintenance.



SSYA00008686

16.

Sign indicates a hazard of rotating parts, such as belt.  
Turn off before inspection and maintenance.




SS4459534

## SAFETY SIGNS


17.

Sign indicates an explosion hazard.  
Keep fire and open flames away from this area.  
Skin contact with electrolyte will cause burns. Splashed electrolyte into eyes will cause blindness. Take care not to touch electrolyte.



SS-411

18.



SS4467093-2

19.

**WARNING**  
IT CONTAINS NITROGEN UNDER HIGH PRESSURE.  
DON'T ALLOW FIRE OR HEAT NEAR IT. DON'T TRY TO DISASSEMBLE IT.  
WEAR EYE PROTECTION AND CAREFULLY DRILL A HOLE AT THE POINT  
MARKED ⊗ TO RELEASE GAS PRESSURE BEFORE DISPOSAL.

SS-3212







## NAME OF COMPONENTS

### Name of Components

- 1- Bucket
- 2- Bucket Cylinder
- 3- Arm
- 4- Arm Cylinder
- 5- Boom Cylinder
- 6- Boom
- 7- Fuel Tank
- 8- Hydraulic Oil Tank
- 9- Engine
- 10- Aftertreatment Device
- 11- Counterweight
- 12- Travel Device
- 13- Track
- 14- Front Idler
- 15- Cab
- 16- DEF/AdBlue® Tank
- 17- Expansion Tank
- 18- Battery Disconnect Switch



MDC1-07-056

 **NOTE:** A typical model is shown in the right. Some parts may differ depending on the model of the machine.


## GETTING ON AND OFF THE MACHINE

### Getting ON and OFF the Machine


Footholds (1) and handrails (2) are provided around the machine for safe entry and exit to the cab. They also allow for safe inspection and maintenance. Never jump on or off the machine, it is very dangerous.

#### **WARNING:**

- When lifting the cab/main body or transporting the machine, never attach wire to footholds (1)
- Door handle (3) is not a handrail. Do not use door handle (3) as a handrail when getting on and off the machine.
- Do not hold control levers (4) or pilot control shut-off lever (5) when getting on and off the machine.



MDA-01-329



MDC1-01-540

## OPERATOR'S STATION

---

### About Aftertreatment Device

The aftertreatment device removes particulate matter (PM) and nitrogen oxide (NOx) from the exhaust gas. Follow the instructions below to prevent the aftertreatment from being damaged.

#### WARNING:

- **Exhaust gas from the aftertreatment device, muffler, exhaust piping and tail piping becomes hot during and just after engine running and regeneration of aftertreatment device. Pay attention not to let your skin contact any part of exhaust system or hot gas from the exhaust piping, as it may cause severe burns.**
- **If flammable materials such as dead leaves or paper scraps are around the aftertreatment device, they may cause a fire.**
- **To avoid burns, stop the engine and make sure the engine has sufficiently cooled down before performing maintenance.**

#### IMPORTANT:

- **Be sure to use fuel that complies with JIS K-2204, EN-590 or ASTM D-975 that contains 15 ppm or lower sulfur. If the fuel described above is not used, exhaust gas that exceeds regulation values may be discharged and serious engine problems may occur.**
- **Refill DEF/AdBlue® which meets Japanese Industrial Standards (JIS) or International Organization for Standardization (ISO). If improper liquid (diesel oil, kerosene or gasoline) is refilled in the DEF/AdBlue® tank, fire or system failure may result.**
- **Use only genuine Hitachi engine oil. Using engine oil other than Hitachi genuine oil may result in malfunction of the aftertreatment device.**
- **Do not mix poor quality diesel fuel, drainage agents, fuel additives, gasoline, kerosene, alcohol, or any other type of lubricating oil with specified diesel fuel. Improper fuel usage may deteriorate performance of fuel filters, can cause problems in the lubricated parts of the injector. It can also affect the engine parts and aftertreatment device, leading to malfunction.**

## OPERATOR'S STATION

---

- **Do not modify the machine without authorization. Never attempt to modify the air inlet and exhaust parts such as the air duct, aftertreatment device and the exhaust piping. Also never attempt to disassemble the aftertreatment device. Avoid giving shocks on the aftertreatment device by striking elements with other objects or dropping the device. Failure to do so may affect the aftertreatment device, possibly damaging it or lowering its performance.**
- **White smoke may be generated during the aftertreatment device regeneration. Do not attempt to perform a manual regeneration in a poorly ventilated area.**
- **Consult your authorized dealer for checking or repairing the aftertreatment device.**

 NOTE:

- *White deposits may accumulate inside the aftertreatment device. The aftertreatment device is automatically regenerated to remove accumulated white deposits at regular intervals. It is called auto-regeneration. The auto-regeneration may start during operation of the machine; you can continue to operate the machine. (Refer to the page 1-25)*
- *Do not stop the engine during regeneration unless absolutely necessary.*
- *The auto-regeneration may be terminated depending on the machine operating condition.*
- *Usually, auto-regeneration starts 30 hours after the previous regeneration (either auto or manual).*

## OPERATOR'S STATION




---

- *If auto regeneration did not complete, and 38 hours have passed since the previous regeneration, an aftertreatment device regeneration request will blink on the monitor. (Refer to the page 1-26) Perform manual regeneration following the specified procedure. (Refer to the page 1-27)*
- *When the machine is operated without performing manual regeneration, the aftertreatment device may be damaged. Immediately move the machine to a safe area and perform manual regeneration.*
- *If approximately 48 hours have passed without regeneration being carried out, the engine trouble alarm will be displayed on the monitor (Refer to the page 1-26). Consult your authorized Hitachi dealer.*
- *Both auto and manual regenerations restore aftertreatment device function. It is not a malfunction.*
- *White smoke may be emitted for several minutes after the engine starts, this is not a malfunction.*

## OPERATOR'S STATION

### Cab Features

- 1- Left Control Lever/Horn Switch
- 2- Left Travel Pedal
- 3- Left Travel Lever
- 4- Right Travel Lever
- 5- Right Travel Pedal
- 6- Right Control Lever/Power Boost Switch
- 7- Multi Function Monitor Panel
- 8- Switch Panel
- 9- Key Switch
- 10- Regeneration Switch
- 11- Operator's Seat
- 12- Cab Door Release Lever
- 13- Pilot Control Shut-Off Lever
- 14- Glove Compartment
- 15- Fuse Box
- 16- Cigar Lighter
- 17- Switch Panel (for Optional Equipments)  
Glove Compartment (without Optional Equipment)
- 18- Glove Compartment (Hot and Cool Box)
- 19- Engine Stop Switch



# OPERATOR'S STATION

## Multi Function Monitor


### Feature

The multi function monitor displays various meters, indicators, radio and air conditioner, numeric keypad lock function, rearview camera image, work mode selection and maintenance screen.

### Screen Configuration

The multi function monitor consists of the following screens.

There are 9 menus, and a further 17 sub menus.



## OPERATOR'S STATION

### Default Setting

Function	Item	Default
Auto Shut-Down	ON/OFF of Auto Shut-down	OFF
	Setting Time	1 min
Aftertreatment Device Regeneration Inhibited	Regeneration Inhibited	OFF


 NOTE: Typical functions are shown in the table. Check the initial values of other functions on each monitor screen.



# OPERATOR'S STATION

## Basic Screen

- 1- Work Mode Display
- 2- Aftertreatment Device Display
- 3- Power Mode Display
- 4- Hour Meter, Clock
- 5- Auxiliary
- 6- Auxiliary
- 7- Preheat Display
- 8- Seat Belt Display
- 9- Fuel Gauge
- 10- Sub Meter Display
- 11- Radio Display
- 12- Air Conditioner Display
- 13- Coolant Temperature Gauge
- 14- Auxiliary
- 15- Auxiliary
- 16- Travel Mode Display
- 17- Auto Shut-Down Display
- 18- Auto-Idle Display
- 19- DEF/AdBlue® Gauge



MDC1-01-020

# OPERATOR'S STATION

## How to Use Screens

### Displaying Basic Screen


**IMPORTANT:** Start the engine after the basic screen is displayed.

When the key switch is turned to the ACC or ON position, the starting screen displays for about 2 seconds. When the key switch is kept in ACC position, only hour meter, clock and radio will be displayed. When the key switch is turned from ACC to ON position, the basic screen will be displayed.



Starting Screen


MDAA-01-003EN



Basic Screen

MDC1-01-001

**IMPORTANT:** When the key switch is turned to ON position, the alternator alarm will be displayed on the basic screen. Until the alternator starts generating power after the engine starts, the alternator alarm is displayed on the basic screen.




Alternator Alarm

MDC1-01-042

# OPERATOR'S STATION

- Display of Meters  
Items to be displayed  
4- Hour Meter, Clock  
9- Fuel Gauge  
13- Coolant Temperature Gauge  
19- DEF/AdBlue® Gauge
- Work Mode Display  
The attachments being used are displayed.



MDC1-01-001

## Digging Mode



## Attachment Mode

### Breaker



### Pulverizer



### Crusher



### Vibrating Hammer



### Grapple




### Clamshell




### Thumb




### Tilting Rotator



### Tilting Bucket




### Others



## OPERATOR'S STATION


- Aftertreatment Device Display (2)  
Displays condition of the aftertreatment device.
- Power Mode Display (3)  
Displays the power mode selected from the switch panel.
- Preheat Display (7)  
While the current is being supplied to the glow plug, indicator (7) is displayed.
- Seat Belt Display (8)  
Turns ON when the key switch is in the ON position, and turns OFF 5 seconds after the engine starts.
- Sub Meter Display (10)  
Fuel consumption or breaker hour meter is displayed.
- Radio Display (11)  
Displays the radio panel.
- Air Conditioner Display (12)  
Displays the air conditioner panel.
- Travel Mode Display (16)  
Displays the travel mode selected from the switch panel.
- Auto Shut-Down Display (17)  
Display auto shut-down display (17) when auto shut-down is turned ON from the menu screen.  
When the key switch is turned ON while auto shut-down is enabled, auto shut-down display (17) blinks for 10 seconds.



MDC1-01-286

## OPERATOR'S STATION


- **Auto-Idle Display (18)**  
When the auto-idle is selected from the switch panel, auto-idle display (18) displays.  
When the key switch is turned ON while the auto-idle switch is also ON, auto-idle display (18) blinks for 10 seconds.



MDC1-01-286

### Hour Meter

The total accumulated operating hours since the machine started working, are displayed in hours (h).  
One digit after the decimal point indicates tenths of an hour (6 minutes).




MDAA-01-021EN

### Clock

Indicates the current time.  
24-h/12-h display can be selected.  
(Refer to "Date and Time" for switching the display mode.)

### Fuel Gauge

The remaining fuel amount is indicated by the needle.  
Refuel before the needle reaches "E".



MDAA-01-276

## OPERATOR'S STATION

### DEF/AdBlue® Gauge

The remaining DEF/AdBlue® amount is indicated on the segment display.




When DEF/AdBlue® level becomes low, the last segment turns yellow. If the segment display turns yellow, immediately refill DEF/AdBlue®.



**IMPORTANT: Display of the DEF/AdBlue® gauge changes depending on the DEF/AdBlue® level. If the engine runs with a low level of DEF/AdBlue®, the engine power will gradually be reduced. If the gauge turns yellow, immediately refill DEF/AdBlue®.**

MDC1-01-509


### DEF/AdBlue® Level Alarm

Screen Display	Display of Segments	Buzzer	Content of Alarm
	The last segment turns yellow.	Once	DEF/AdBlue® level is low. Refill DEF/AdBlue® as soon as possible.
	The last segment turns red.	Intermittent sound	DEF/AdBlue® level is low. The engine output power derates gradually. Refill DEF/AdBlue® as soon as possible.
	All segments turn OFF.	Continuous sound	No DEF/AdBlue®. The engine can start, but the machine can not be operated. The machine can not be operated until refilling DEF/AdBlue®.

## OPERATOR'S STATION

### Coolant Temperature Gauge


The engine coolant temperature is indicated with a needle. Normally the needle is around the center of the scale during operation.



M1U1-01-047

### Operating Status Icon Display

Displays icons indicating the current status of each of following items: Attachment (1) and aftertreatment device display (2) selected from the work mode selection screen; power mode (3), preheat indicator (4), travel mode (5), auto shut-down (6) ON, auto-idle (7) ON selected from the switch panel.



MDAA-01-023

## OPERATOR'S STATION


### Security Functions (Optional)

#### Input Password

#### IMPORTANT:

- When required to activate the numeric keypad function, consult your authorized dealer.
- If the password is forgotten, the machine must be modified. Be extremely careful not to forget the password.

1. Turn the key switch ON. After the starting screen is displayed, the password input screen will be displayed.
2. Input a password by using the numeric keypad.
3. The monitor unit matches the input password to the registered one. If they match, the basic screen displays. The engine is ready to run. If an incorrect password is input 3 times, a buzzer sounds for 30 seconds. During that time, the buzzer does not stop even if the key switch is turned ON/OFF.


 **NOTE:** If you make a mistake while entering the password, push the CLEAR key in order to erase the entered characters.

4. After 30 seconds, if the key switch is turned to the ON position, the starting screen displays and the password input screen displays again. Then the password can be input again.
5. If an incorrect password is input again, the buzzer sounds for a further 30 seconds.




Starting Screen

MDAA-01-003EN




Password Input Screen

MDAA-01-085EN



MDAA-01-086EN



Basic Screen

MDC1-01-001




## OPERATOR'S STATION

### Extending Password Duration Time

**IMPORTANT:** This operation is applicable only to machines that require a password.

By using the password duration screen, password duration time can be set. When restarting the machine, a password need not be input within the specified timeframe.

1. When turning the key switch from ON to ACC position, the monitor unit displays the password duration screen for 10 seconds.





MDAA-01-087EN

Password Duration Screen (Key Switch: OFF)

2. While the password duration screen is still displayed, rotate selector knob (1) to highlight the relevant time. Pushing selector knob (1) sets the password duration time.

- Duration time    0 minute
- Duration time    30 minute
- Duration time    60 minute
- Duration time    90 minute
- Duration time    120 minute

 **NOTE:** If the password duration time is not set explicitly, a duration of 0 is assumed.




MDCD-01-026

3. If turning the key switch to the ON position within the password duration time, the monitor unit displays the basic screen after the starting screen.



Starting Screen

MDAA-01-003EN




MDC1-01-001


# OPERATOR'S STATION

## Alarm Occurrence Screen

In case any abnormality occurs, alarm marks (1) are displayed on the basic screen.  
If six or more alarms are generated, alarm marks (1) can be scrolled by rotating switch (2).



MDC1-01-316



MDCD-01-026

## OPERATOR'S STATION


Follow the procedure below to display detailed information for an alarm.

Push selector knob (1) on basic screen (2) to display main menu (3).


Rotate selector knob (1) to select alarm list (4), and push selector knob (1).

Rotate selector knob (1) to select a required alarm from alarm list (5), and push selector knob (1).

Detailed information of the selected alarm will be displayed.




MDC1-01-004



MDCD-01-026


**NOTE:**

- Main menu (3) displays alarm list (4) only when an alarm occurs.




MDAA-01-077EN

- Alarm list (5) contains only currently generated alarms.












MDCD-01-006EN




MDCD-01-007EN











## OPERATOR'S STATION

### Remedy

Display	Alarm Name	Content of Alarm
	DEF/AdBlue® Alarm	DEF/AdBlue® Level Is Low Or Urea SCR System Is Abnormal. Refill DEF/AdBlue® If Level Is Low. Consult Your Authorized Hitachi Dealer For System Malfunction.
	Engine Output Restriction	Engine Output Is Restricted.
	Aftertreatment Device Regeneration Request (Blinking) (Yellow)	Aftertreatment Device Regeneration Is Needed. Set Pilot Control Shut-off Lever To The LOCK Position. Run The Engine At Slow Idle Speed. Turn The Manual Regeneration Switch To The Regeneration Position.
	Aftertreatment Device Regeneration Inhibited Alarm (Lighting) (Yellow)	As The Regeneration Inhibition Has Been Set, Manual Regeneration Cannot Be Performed. Move The Machine To A Safe Area, Release The Regeneration Inhibition, And Perform Manual Regeneration.
	Aftertreatment Device Auto-Regeneration Inhibited Alarm (Lighting) (Yellow)	As The Regeneration Inhibition Has Been Set, Auto Regeneration Cannot Be Performed. Move The Machine To A Safe Area And Release The Regeneration Inhibition.
	Engine Oil Level Alarm	Check Engine Oil Level And Add Oil If Required.
	Coolant Level Alarm	Check Coolant Level And Add Coolant If Required.
	Overheat Alarm**	Coolant Temperature Is Abnormally High. Stop Operation. Run The Engine At Slow Idle To Cool Coolant Temperature.
	Hydraulic Oil Overheat Alarm (Only ZX350LC-6N, 380LC-6N)	Hydraulic Oil Temperature Is Abnormally High. Stop Operation, Check Hydraulic Oil Level And Check For Any Oil Leaks From Hydraulic Circuit.









 **NOTE:** \*\*Alarm mark is displayed and buzzer will sound. Turn engine control dial to the slow idle position, and buzzer will stop.

## OPERATOR'S STATION

Display	Alarm Name	Content of Alarm
	Engine Trouble Alarm	Engine Or Accessory Are Abnormal. Contact Your Nearest Authorized Dealer.
	Engine Oil Pressure Alarm*	Engine Oil Pressure Is Low. Immediately Stop Engine. Check Engine Oil System And Oil Level.
	Engine Start Disabled	Engine Cannot Start If Pilot Shut-Off Lever Is In The UNLOCK Position.
	Engine Start Disabled	Engine Cannot Start If Engine Shut-Off Switch Is In The OFF Position.
	Boost Temperature Alarm	Engine Intake Air Temperature Is Abnormally High. Stop Operation And Check For Clogged Intercooler And/Or Disconnected Intake Airline.
	Exhaust Temperature Alarm	Exhaust Temperature Is Abnormally High. Stop Operation. Check The Exhaust Piping.
	Aftertreatment Device Regeneration System Abnormal	Aftertreatment Device Regeneration System Is Abnormal. Consult Your Authorized Hitachi Dealer.
	Hydraulic Oil Cooling System Alarm (Only ZX350LC-6N, 380LC-6N)	Hydraulic Oil Cooling System Is Abnormal. Contact Your Nearest Authorized Dealer.
	Alternator Alarm	Electrical System Is Abnormal. Check Alternator And Battery Systems.
	Fuel Level Alarm	Fuel Level Is Low.

 NOTE: \*Alarm mark is displayed and buzzer will sound.

## OPERATOR'S STATION












Display	Alarm Name	Content of Alarm
	Fuel Temperature Alarm	Fuel Temperature Is Abnormally High. Stop Operation And Check For Any Abnormality Such As Clogged Fuel Cooler.
	Hydraulic Oil Filter Restriction Alarm (Optional)	Hydraulic Oil Filter Is Clogged. Replace Hydraulic Oil Filter Element.
	Air Cleaner Restriction Alarm	Air Cleaner Is Clogged. Clean Or Replace Air Cleaner Element.
	Water Separator Alarm	Water Separator Is Full. Drain Water.
	Fuel Filter Restriction Alarm*	Fuel Filter Is Clogged. Replace Fuel Filter Element.
	System Failure Alarm	Machine Network System Is Abnormal. Contact Your Nearest Authorized Dealer.
	Electric Lever Alarm	Electric Lever System Is Abnormal. Contact Your Nearest Authorized Dealer.
	Pilot Control Shut-Off Lever Alarm	Pilot Control Shut-Off Lever System Is Abnormal. Contact Your Nearest Authorized Dealer.

 **NOTE:**

- The hydraulic oil filter alarm lights only when the high performance element (optional) is used.
- \*If the indicator comes ON immediately after replacing the fuel filter, air mixed in the system during replacement may be the cause. Be sure to bleed air from the fuel system when replacing the fuel filter. (When air is bled, the indicator will go OFF.)

## OPERATOR'S STATION


### Urea SCR System Remedy

Display	Alarm Name	Content of Alarm
 <div style="border: 1px solid black; padding: 2px; display: inline-block;"> <b>REFILL</b> DEF/AdBlue         </div>	DEF/AdBlue® Level Alarm*	DEF/AdBlue® Level Is Low. Refill DEF/AdBlue®.
 <div style="border: 1px solid black; padding: 2px; display: inline-block;"> <b>REFILL</b> DEF/AdBlue         </div> 	DEF/AdBlue® Level Alarm*	DEF/AdBlue® Is Insufficient. Refill DEF/AdBlue®. DEF Tank Empty. Engine Output Is Restricted.
 <div style="border: 1px solid black; padding: 2px; display: inline-block;"> <b>REFILL</b> DEF/AdBlue         </div> <div style="background-color: black; color: white; padding: 2px; display: inline-block; margin-left: 10px;"> <b>No Power</b> </div>	DEF/AdBlue® Level Alarm*	DEF/AdBlue® Tank Is Empty. Refill DEF/AdBlue®. Engine Output And Speed Are Restricted.
 <div style="background-color: black; color: white; padding: 2px; display: inline-block;"> <b>Exh. System</b> </div> 	Urea SCR System Malfunction*	Urea SCR System Is Broken.
 <div style="background-color: black; color: white; padding: 2px; display: inline-block;"> <b>Exh. System</b> </div>  	Urea SCR System Malfunction*	Urea SCR System Is Broken. Engine Output Is Restricted.
 <div style="background-color: black; color: white; padding: 2px; display: inline-block;"> <b>No Power</b> <b>Exh. System</b> </div> 	Urea SCR System Malfunction*	Urea SCR System Is Broken. Engine Output And Speed Are Restricted.

 **NOTE:** \*Alarm mark is displayed and buzzer will sound.


## OPERATOR'S STATION

- **Fuel Sensor Error Display**  
If the fuel sensor is faulty, the color of the fuel mark changes and the needle disappears. If the harness between the fuel sensor and the controller unit is broken, the needle disappears.
- **Coolant Temperature Sensor Error Display**  
If the coolant temperature sensor is faulty, the color of the temperature mark changes and the needle disappears. If the harness between the temperature sensor and the controller unit is broken, the needle disappears.



MDC1-01-024

- **Engine Speed Control Display**  
Engine warming-up operation due to low coolant temperature. The engine speed can not be changed during this operation. While the engine speed is controlled, mark (2) is displayed on monitor (1). When the control completes, mark (2) goes OFF and the engine speed becomes adjustable.



MDC1-01-355



## OPERATOR'S STATION

### Aftertreatment Device

#### Aftertreatment Device Condition Display

Aftertreatment Device Display (1) displays the condition of the aftertreatment device.



This mark indicates that the exhaust temperature is high during the aftertreatment device regeneration. It is lit while auto or manual regeneration is in process.



#### NOTE:

- The auto-regeneration is performed 30 hours after the previous regeneration. The auto-regeneration may start during operation of the machine; you can continue to operate the machine. The engine sound and/or the machine response to the operation of control levers may change when performing the auto-regeneration; this is not a malfunction.
- Do not stop the engine during regeneration unless absolutely necessary.


When the manual regeneration switch is pushed during the auto-regeneration process, the message "Minimal Exhaust Restriction. Exhaust Filter Cleaning Not Available." will be displayed on monitor (2).

Depending on the operating conditions of the machine, the regeneration may not be completed. In this case, an aftertreatment device regeneration request will be displayed on monitor (2). Immediately perform manual regeneration following the procedure.



This mark indicates that the aftertreatment device regeneration is inhibited. Regeneration will not be performed while this mark is lit.

**IMPORTANT: Set aftertreatment device regeneration to the inhibited position while operating the machine in an environment with materials that could be flammable. (Refer to the page 1-55)**



MDC1-01-001

## OPERATOR'S STATION

### Aftertreatment Device Manual Regeneration Request

The aftertreatment device needs regeneration. Usually, regeneration is performed automatically. However, manual regeneration is required depending on the conditions. The marks described below may be indicated on monitor (1).




(Blinking,  
Yellow)

This mark indicates that the aftertreatment device manual regeneration is required. Perform manual regeneration by following the specified procedure.



(Lighting,  
Yellow)

This mark indicates that the aftertreatment device regeneration is inhibited. Displayed when the manual regeneration request arises while aftertreatment device regeneration is inhibited. Move the machine to a safe place. Perform manual regeneration following the specified procedure.



MDC1-01-005

### IMPORTANT:

- **Manual regeneration performed when the aftertreatment device regeneration request is displayed restores aftertreatment device function. This is not a malfunction.**
- **If the machine is continuously operated despite the aftertreatment device regeneration request is displayed, an engine trouble alarm will be displayed. Consult your authorized dealer.**


## OPERATOR'S STATION

### Manual Regeneration Procedure


When manual regeneration is needed, screen (1) as shown in the right will be displayed. When this screen (1) is displayed, you need to perform manual regeneration. Before starting manual regeneration, be sure to check the following.

If the rear view camera is equipped on the machine and the camera is enabled, screen (1) is displayed only when the pilot control shut-off lever is in LOCK position.

- No person is present around the machine.
  - Keep flammable materials away from the muffler.
  - Fuel level alarm is not lit.
  - DEF/AdBlue® level alarm does not light.
1. Park the machine in a safe place. Lower the front attachment onto the ground.
  2. Pull the pilot control shut-off lever to the LOCK position.
  3. Set the engine control dial to slow idle.
  4. Push aftertreatment device regeneration switch (2).
  5. When pushing aftertreatment device regeneration switch (2), screen (3) as shown in the right will be displayed and the manual regeneration starts. A bar graph on screen (3) shows the progress of the regeneration process.




MDC1-01-005




MDAA-01-330

**IMPORTANT: The manual regeneration does not start unless the pilot control shut-off lever is in the LOCK position and the engine control dial is in slow idle. When touching the pilot control shut-off lever or the engine control dial during manual regeneration, the regeneration process is aborted. When the process is aborted, start over again.**


6. When the manual regeneration is complete, the message "Regeneration Has Completed." is displayed. If "Regeneration Has Failed." message is displayed, start over the manual regeneration process once again. Failure of the regeneration process may happen in conditions other than those mentioned above (such as a malfunction of a sensor that affects regeneration, or at low ambient temperature).



MDC1-01-006



MDC1-01-083EN




MDC1-01-084EN

# OPERATOR'S STATION


## Main Menu

Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3). Main Menu screen (3) contains the items as shown in the figure right. Engine Output Restriction Is Temporary Released, Urea SCR System Troubleshooting and Alarm List will be displayed only when the engine output is limited, Urea SCR system is malfunctioning or an alarm is generated, respectively. The mail (optional) menu will not be displayed unless it is set beforehand.


**NOTE:** The monitor automatically changes to Basic Screen (1) when it is not operated for 15 seconds or longer. If setting is terminated halfway, please restart the setting again.




MDC1-01-001



MDCD-01-026



MDAA-01-077EN



MDAA-01-190EN


# OPERATOR'S STATION

## Engine Output Restriction Suspend

When a lack of DEF/AdBlue® or Urea SCR system malfunction occurs, alarm mark (1) will be displayed on the basic screen and engine output/speed will be limited.

### IMPORTANT:

- This function can be performed only one time at one engine output limit.
- This is only a temporary release operation. Refill DEF/AdBlue® or repair Urea SCR system as soon as possible. Consult your authorized dealer to repair the system.




MDC1-01-519EN

MDC1-01-520EN


The engine output limit function can be temporarily released when evacuation is unavoidable during machine operation. Follow the below procedure.

1. Push selector knob (2) on the Basic Screen to display Main Menu (3).
2. Rotate selector knob (2) to highlight Engine Output Restriction Suspend (4).

**NOTE:** Engine output restriction suspend (4) is displayed on main menu (3) only when the engine output and speed is restricted.




MDCD-01-026



MDC1-01-521EN


## OPERATOR'S STATION

3. Push selector knob (2) to display Engine Output Restriction Suspend screen (5).



MDCD-01-026

4. Rotate selector knob (2) to highlight ✓ (6), and push selector knob (2) to display Engine Output Restriction Suspend screen (8).




MDC1-01-522EN

5. Rotate selector knob (2) to highlight ✓ (7), then screen (9) is displayed and the engine output is temporarily released.




**NOTE:**

- The temporary release time is a maximum of 30 minutes.
- The engine output limit will be enabled after 30 minutes.



MDC1-01-523EN




MDC1-01-524EN

## OPERATOR'S STATION

### Urea SCR System Troubleshooting


In case any abnormality occurs, alarm marks (1) are displayed on the Basic Screen. Follow the procedure below to display detailed information for an alarm.

1. Push selector knob (2) on the Basic Screen to display Main Menu screen (3).




MDC1-01-514EN

2. Rotate selector knob (2) to highlight Urea SCR System Troubleshooting (4) and push selector knob (2).




MDCD-01-026

3. Urea SCR System Troubleshooting screen (5) will be displayed and Urea SCR System Troubleshooting starts. Bar graph (6) on the screen indicates progress of the troubleshooting process.



MDC1-01-515EN




MDC1-01-516EN

## OPERATOR'S STATION

- When the troubleshooting is finished, fault code (7) is displayed. Consult your authorized dealer to repair the system.

 **NOTE:**

- The main menu displays information about the Urea SCR System Troubleshooting is only displayed when the Urea SCR system alarm is generated.
- Up to 20 fault codes are displayed in chronological order.



MDC1-01-517EN




# OPERATOR'S STATION

## Air Conditioner


Most air conditioner functions are operated by using switches (3) and (4), however air vent selection and turning A/C ON and OFF are performed from the air conditioner setting screen in the menu. (Refer to the page 1-111)

### Circulation Air Mode


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (5).
2. Rotate selector knob (2) to highlight Air Conditioner (6).
3. Push selector knob (2) to display Air Conditioner screen (7).
4. Rotate selector knob (2) to highlight  (8) mark.
5. Push selector knob (2) to set the circulation air mode.
6. Push selector knob (2) again to switch the fresh air mode.

### Air Conditioner ON/OFF


1. Rotate selector knob (2) to highlight A/C (9).
2. Push selector knob (2) to turn the air compressor ON.
3. Push selector knob (2) again to turn the air compressor OFF.

 **NOTE:** When the function is ON, the mark "■" is displayed in green. When the function is OFF, the mark "■" is displayed in gray.


**IMPORTANT:** If mark (10) is displayed on the air conditioner display, communication between the air conditioner and the monitor is abnormal. Consult your authorized dealer.




MDC1-01-001



MDCD-01-026



MDAA-01-089EN



MDAA-01-091EN



MDAA-01-226


## OPERATOR'S STATION

### Radio

Most radio functions are operated by using switches (3) and (4), however memory channel setting, seek function, TONE adjustment, and AUTO PRESET are done at the radio screen in the main menu.

1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (5).
2. Rotate selector knob (2) to highlight Radio (6).
3. Push selector knob (2) to display the radio screen.


(Refer to the page 1-119)




MDC1-01-001

**IMPORTANT:** If mark (7) is displayed on the radio display, communication between the radio and the monitor is abnormal. Consult your authorized dealer.

While the radio is ON, pressing the numeric keypad 1 to 8 will change the radio station to the respective memorized channel. (Refer to the page 1-101 and 1-120)



MDCD-01-026



MDAA-01-092EN



MDAA-01-227

# OPERATOR'S STATION


## Work Mode


**IMPORTANT:** Before changing the work mode, stop the machine, lower the working device such as a bucket on the ground and pull the pilot control shut-off lever to the LOCK position.

Front attachment is selected in Work Mode screen (5) under the Work Mode menu in the main menu.


### Attachment Selection

1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Work Mode (4).
3. Push selector knob (2) to display Work Mode screen (5).
4. Rotate selector knob (2) to highlight the desired front attachment.  
(In the example on the right, Bucket (6) is highlighted.)
5. Push selector knob (2) to enable the changes.


 **NOTE:** When the attachment pedal is operated while the work mode is set to the digging mode, work mode display (7) on the monitor screen starts flashing.




MDC1-01-001



MDCD-01-026



MDAA-01-100EN




MDAA-01-101EN

## OPERATOR'S STATION


### Mail (Optional)

**IMPORTANT:** This function is available only to a machine equipped with a communication terminal. When using the mail function, consult your nearest Hitachi dealer.


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
  2. Rotate selector knob (2) to highlight Mail (4).
  3. Push selector knob (2) to display Mail screen (5).
  4. Rotate selector knob (2) to highlight desired request.
  5. Push selector knob (2) to send mail information to the communication terminal.
- General Request
  - Fuel Replenishment Request
  - Service Maintenance Request
  - Forwarding Request




MDC1-01-001



MDCD-01-026




MDAA-01-109EN



MDAA-01-110EN

## OPERATOR'S STATION

6. While mail information is sent to the communication terminal, the message "Wait." is displayed on the screen.



MDAA-01-111EN


7. When the communication terminal completes receiving mail information, the message "Request Is Accepted." is displayed on the screen.

Push the return to previous screen switch to return to the Mail screen.


8. Then, a mail is sent from the communication terminal to the central server.

### NOTE:

- Depending on the machine's operating environment, the mail may not be sent.
- When the communication terminal could not receive the mail, the message "Failed." is displayed on the screen.



MDAA-01-112EN




MDAA-01-113EN

## OPERATOR'S STATION


### Setting Menu

Setting menu consists of date and time setting, attachment adjustment, attachment name, auto shut-down setting, change password, selecting sub meter, brightness adjustment of rear view camera monitor and screen.


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Setting Menu (4).
3. Push selector knob (2) to display Setting Menu screen (5).




MDC1-01-001



MDCD-01-026



MDAA-01-114EN



MDC1-01-115EN


# OPERATOR'S STATION

## Date and Time


Time, date and display mode can be set on this screen. Year-month-day format and 24h/12h display mode are selected in the display setting.

### Time Adjustment


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Setting Menu (4).
3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate selector knob (2) to highlight Date and Time (6).




MDC1-01-001



MDCD-01-026




MDAA-01-114EN



MDC1-01-115EN


## OPERATOR'S STATION

5. Push selector knob (2) to display Date and Time screen (7).




MDCD-01-026

6. Rotate selector knob (2) to highlight Time Setting (8).
7. Push selector knob (2) to display Time Setting screen (9).




MDAA-01-117EN

8. Rotate selector knob (2) to highlight Hour or Minute (10) and push selector knob (2).
9. Rotate selector knob (2) to adjust the clock. Rotate clockwise to adjust the number upwards, and counterclockwise to decrease it.
10. Push selector knob (2) to end the Time setting procedure.
11. Rotate selector knob (2) to highlight ✓ (11). Push selector knob (2) to make the change.



MDAA-01-118EN




MDAA-01-121EN




## OPERATOR'S STATION

### Date Adjustment


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Setting Menu (4).
3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate selector knob (2) to highlight Date and Time (6).




MDC1-01-001



MDCD-01-026




MDAA-01-114EN



MDC1-01-115EN


## OPERATOR'S STATION

5. Push selector knob (2) to display Date and Time screen (7).




MDCD-01-026

6. Rotate selector knob (2) to highlight Date Setting (8).
7. Push selector knob (2) to display Date Setting screen (9).




MDAA-01-122EN

8. Rotate selector knob (2) to highlight Year, Month or Day (10) and push selector knob (2).
9. Rotate selector knob (2) to adjust the clock. Rotate clockwise to adjust the number upwards, and counterclockwise to decrease it.
10. Push selector knob (2) to end the date setting procedure.
11. Rotate selector knob (2) to highlight ✓ (11). Push selector knob (2) to make the change.



MDC1-01-123EN




MDAA-01-127EN


# OPERATOR'S STATION

## Display Mode Setting


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Setting Menu (4).
3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate selector knob (2) to highlight Date and Time (6).




MDC1-01-001



MDCD-01-026




MDAA-01-114EN



MDC1-01-115EN


## OPERATOR'S STATION

5. Push selector knob (2) to display Date and Time screen (7).



MDCD-01-026


6. Rotate selector knob (2) to highlight Display Form (8).



MDAA-01-228EN

7. Push selector knob (2) to display Display Form screen (9).
8. Rotate selector knob (2) to highlight Time or Date (10) and push selector knob (2).

Time : Each time selector knob (2) is pushed, the time format is changed as follows: 12 h → 24 h → 12 h.  
 Date : Each time selector knob (2) is pushed, the date format is changed as follows: YYYY/MM/DD → MM/DD/YYYY → DD/MM/YYYY → YYYY/MM/DD.



MDAA-01-229EN



MDAA-01-230EN



MDAA-01-231EN



MDAA-01-232EN



MDAA-01-233EN



MDAA-01-234EN

# OPERATOR'S STATION


## Attachment Adjustment

On the Attachment Adjustment screen, the supply flow rate to an attachment, the operational priority for combined operation of an attachment, and arm roll-in/arm roll-out can be adjusted.


Attachment adjustment can be done when the work mode is set to an attachment other than bucket. Select an attachment other than the bucket on the work mode screen. (Refer to "Work Mode")

### Flow Rate Adjustment


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Setting Menu (4).
3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate selector knob (2) to highlight Attachment Adjustment (6).




MDC1-01-001



MDCD-01-026




MDAA-01-114EN



MDC1-01-128EN


## OPERATOR'S STATION

- Push selector knob (2) to display Attachment Adjust screen (7).




- Rotate selector knob (2) to highlight Pump Flow Rate (8).

MDCD-01-026



MDAA-01-129EN

- Push selector knob (2) to display Pump Flow Rate screen (9).
- Rotate selector knob (2) clockwise or counterclockwise to adjust the pump flow rate.




MDAA-01-130EN

## OPERATOR'S STATION


### Priority (arm roll-out)

Select an attachment other than the bucket on the work mode screen. (Refer to the page 1-35)


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Setting Menu (4).
3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate selector knob (2) to highlight Attachment Adjustment (6).




MDC1-01-001



MDCD-01-026




MDAA-01-114EN



MDC1-01-128EN


## OPERATOR'S STATION

5. Push selector knob (2) to display Attachment Adjust screen (7).




MDCD-01-026

6. Rotate selector knob (2) to highlight Priority (Arm Roll-Out) (8).



MDAA-01-235EN

7. Push selector knob (2) to display Priority (Arm Roll-Out) screen (9).
8. Rotate selector knob (2) clockwise to increase flow rate to the attachment. Rotate selector knob (2) counterclockwise to increase flow rate to the arm roll-out circuit.



MDAA-01-132EN




## OPERATOR'S STATION


### Priority (arm roll-in) (Except ZX350LC-6N, 380LC-6N)

Select an attachment other than the bucket on the work mode screen. (Refer to the page 1-35)


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Setting Menu (4).
3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate selector knob (2) to highlight Attachment Adjustment (6).




MDC1-01-001



MDCD-01-026




MDAA-01-114EN



MDC1-01-128EN


## OPERATOR'S STATION

5. Push selector knob (2) to display Attachment Adjust screen (7).



6. Rotate selector knob (2) to highlight Priority (Arm Roll-In) (8).

MDCD-01-026




7. Push selector knob (2) to display Priority (Arm Roll-In) screen (9).

MDAA-01-236EN

8. Rotate selector knob (2) clockwise to increase flow rate to the attachment.

Rotate selector knob (2) counterclockwise to increase flow rate to the arm roll-in circuit.




MDAA-01-131EN

# OPERATOR'S STATION


## Attachment Name Input

Attachment name can be changed on this screen.


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Setting Menu (4).
3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate selector knob (2) to highlight Attachment Name Input (6).




MDC1-01-001



MDCD-01-026




MDAA-01-114EN



MDC1-01-133EN


## OPERATOR'S STATION

- Push selector knob (2) to display Attachment Name Input screen (7).



MDCD-01-026


- Rotate selector knob (2) to highlight Desired Attachment Name (8).




MDAA-01-134EN

- Push selector knob (2) to display Name Change screen (9).
- Rotate selector knob (2) right or left to highlight a character, and push selector knob (2).
- After inputting the new name, rotate selector knob (2) to highlight "SET". Push selector knob (2) to finalize the setting.

**NOTE:** In order to delete the last entered character, rotate selector knob (2) to highlight "BS" (Back Space), and then push selector knob (2). In order to delete all entered characters, rotate selector knob (2) to highlight "ALL CLEAR". Push selector knob (2).



MDAA-01-137EN



MDAA-01-145EN

## OPERATOR'S STATION

### Auto Shut-Down


**⚠ WARNING:** This function automatically stops the engine. Pay extra attention to the work and work environment when using this function.

The auto shut-down function can be set in this screen. Set the auto shut-down time and enable (ON) the function beforehand. The engine automatically stops after the preset time at the state in which the pilot control shut-off lever is pulled. 30 seconds before the engine stop, the monitor displays a message that engine will be stopped and the indicator starts flashing. The buzzer also sounds. The buzzer sounds once at 30 seconds before, and sounds continuously from 15 seconds before the stoppage. The engine speed decreases to the idling speed, and then stops after 15 seconds. When the pilot control shut-off lever is pushed before stopping the engine, the auto shut-down is disabled and the engine will not stop.


**IMPORTANT:** When the engine is stopped by the auto shut-down function, turn the key switch to ACC or OFF once, then turn it to START to restart the engine. Turn the key switch OFF after auto shut-down when leaving the machine for long period of time. Do not leave the machine after auto shut-down. Failure to do so may discharge the batteries.

#### Auto Shut-Down: ON/OFF


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Setting Menu (4).
3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate selector knob (2) to highlight Auto Shut-Down (6).




MDC1-01-001



MDCD-01-026




MDAA-01-114EN



MDC1-01-147EN


## OPERATOR'S STATION


- Push selector knob (2) to display Auto Shut-Down screen (7).



MDCD-01-026

- Rotate selector knob (2) to highlight ON (Enable) (8).
- Push selector knob (2) to set the auto shut-down function ON. Push selector knob (2) again to turn the auto shut-down function OFF.


 **NOTE:** When the function is ON, the mark "■" is displayed in green. When the function is OFF, the mark "■" is displayed in gray.




MDAA-01-148EN


### Auto Shut-Down: Setting Time

- On Auto Shut-Down screen (7), rotate selector knob (2) to highlight Setting Time (9) and push selector knob (2).
- Rotate selector knob (2) to adjust the Auto Shut-Down activation.
- Push selector knob (2) to make the change.

 **NOTE:** 30 seconds before the engine stops, the monitor will display "Engine Shut-Down Soon." message (10).



MDAA-01-150EN



MDC1-01-146EN


## OPERATOR'S STATION

### Aftertreatment Device Regeneration Inhibited


**IMPORTANT:** The aftertreatment device regeneration can be inhibited at this screen to prevent auto regeneration while operating the machine in a dusty area or indoors.

#### Setting Procedure

1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).




MDC1-01-001



MDCD-01-026


2. Rotate selector knob (2) to highlight Setting Menu (4).




MDAA-01-114EN

## OPERATOR'S STATION


3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate switch (2) to highlight Aftertreatment Device Regeneration inhibited (6).
5. Push selector knob (2) to display aftertreatment device regeneration inhibited screen (7).
6. Rotate selector knob (2) to highlight ✓ (8), and push selector knob (2) to display Aftertreatment Device Regeneration Inhibited screen (9).
7. Rotate switch (2) to highlight ON (10). Confirmation screen is added.
8. Push selector knob (2) to turn aftertreatment device Regeneration Inhibited ON. Push selector knob (2) again to turn aftertreatment device Regeneration Inhibited OFF.
9. When ON is selected, the regeneration inhibited icon will be displayed on the monitor. (Refer to the page 1-25)

 **NOTE:** When the auto shut-down function is ON, the mark "■" is displayed in orange. When the auto shut-down function is OFF, the mark "■" is displayed in gray.


**IMPORTANT:** When the aftertreatment device regeneration request is displayed, move the machine to a safe place. Perform the manual regeneration by following the specified procedure. Failure to do so may damage the aftertreatment device. Refer to "Aftertreatment Device" section (1-25, 5-10) for the manual regeneration.




MDC1-01-283EN



MDCD-01-026



MDC1-01-325EN




MDC1-01-284EN




## OPERATOR'S STATION

### Password Change (Optional)

1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).




MDC1-01-001



MDCD-01-026


2. Rotate selector knob (2) to highlight Setting Menu (4).



MDAA-01-114EN


## OPERATOR'S STATION

3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate selector knob (2) to highlight Password Change (6).




MDAA-01-156EN

5. Push selector knob (2) to display Password Change screen (7).




MDCD-01-026



MDAA-01-157EN


6. Input current password from the numeric keypad.




MDAA-01-158EN

# OPERATOR'S STATION

- 7. Input the new password and push selector knob (2). 3 to 8 digits can be input for password.




MDAA-01-159EN




MDAA-01-160EN

## OPERATOR'S STATION


8. Input the new password again to confirm it and push selector knob (2).



MDAA-01-161EN




MDAA-01-162EN



MDCD-01-026

9. The password has been changed.




MDAA-01-163EN

# OPERATOR'S STATION


## Sub Meter

A sub meter selection menu that can be added to the fuel meter is selected on this screen. OFF, Fuel Consumption Indicator and Breaker Hour Meter are provided. The breaker hour meter indicates the breaker operation time.


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Setting Menu (4).
3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate selector knob (2) to highlight Sub Meter Selection (6).




MDC1-01-315



MDCD-01-026




MDAA-01-114EN



MDAA-01-164EN

## OPERATOR'S STATION

5. Push selector knob (2) to display Sub Meter Selection screen (7).




MDCD-01-026

6. Rotate selector knob (2) to highlight Desired Sub Meter (8). (Selecting OFF will not display a sub meter.)
7. Push selector knob (2) to enable the changes.



**NOTE:**

- Only one sub meter can be selected at a time.
- When a display is selected, the mark "■" is displayed in green. When not selected, the mark "■" is displayed in gray.



MDAA-01-165EN


## OPERATOR'S STATION

### Rear View Camera Monitor


**IMPORTANT:** The image displayed on the rear view camera monitor is meant only as an aid. Actual position and distance of people and objects in the rear view camera monitor will be different. When operating the machine, pay thorough attention to the surrounding situation.

#### Rear View Camera ON/OFF


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Setting Menu (4).
3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate selector knob (2) to highlight Rear View Camera Monitor (6).




MDC1-01-001



MDCD-01-026




MDAA-01-114EN



MDAA-01-168EN

## OPERATOR'S STATION

5. Push selector knob (2) to display Rear View Camera Monitor screen (7).




MDCD-01-026


6. Push selector knob (2) to turn the rear view camera monitor ON/OFF.
7. When the rear view camera monitor is ON, rear view image is continuously displayed on the basic screen.

### IMPORTANT:

- In order to obtain a clear image, clean the lens and the monitor display before operating the machine.
- Never attempt to change the mounting position of the rear view camera.
- Consult your authorized dealer if any abnormality is found on the rear view image.



MDAA-01-169EN


 **NOTE:** The monitor display and camera lens surface are resin product. Lightly wipe the surface with a wet clean cloth. Never use an organic solvent.




## OPERATOR'S STATION

### Brightness Adjustment

1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).




MDC1-01-001




MDCD-01-026

2. Rotate selector knob (2) to highlight Setting Menu (4).



MDAA-01-114EN


3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate selector knob (2) to highlight Brightness Adjustment (6).



MDAA-01-171EN


## OPERATOR'S STATION

5. Push selector knob (2) to display Brightness Adjustment screen (7).



MDCD-01-026


6. Rotate selector knob (2) clockwise to make the screen brighter, counterclockwise to make the screen darker.




MDAA-01-172EN

 **NOTE:**

- When the light is turned ON, the monitor screen changes to night mode and mark (8) is displayed. Brightness can be adjusted for day mode and night mode respectively.
- Even if the light is turned ON during daytime, you can activate the daytime screen by pushing "0" (9) on the numeric keypad.



MDAA-01-173EN




MDAA-01-018


# OPERATOR'S STATION

## Language Settings

1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).




MDC1-01-001




MDCD-01-026

2. Rotate selector knob (2) to highlight Setting Menu (4).



MDAA-01-114EN


3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate selector knob (2) to highlight Language/言語 (6).



MDAA-01-176EN


## OPERATOR'S STATION


5. Push selector knob (2) to display Language/言語 screen (7).



MDCD-01-026

6. Rotate selector knob (2) to highlight the desired language. Push selector knob (2) to make the change.

 **NOTE:** When a display is selected, the mark "■" is displayed in green. When not selected, the mark "■" is displayed in gray.



MDAA-01-177EN

## OPERATOR'S STATION

### Lists of Display Language

Language	Screen Display
Japanese	日本語
English	English
Spanish	Español
Italian	Italiano
French	Français
German	Deutsch
Dutch	Nederlands
Russian	Русский
Portuguese	Português
Finnish	Suomi
Greek	Ελληνικά
Swedish	Svenska
Norwegian	Norsk
Chinese (Simplified)	简体中文
Chinese (Traditional)	繁體中文
Korean	한국어


Language	Screen Display
Indonesian	Bahasa Indonesia
Thai	ภาษาไทย
Vietnamese	Tiếng Việt
Myanmarese	မြန်မာစာစကား
Arabic	اللغة العربية
Persian	زبان فارسی
Turkish	Türkçe
Danish	Dansk
Estonian	Eesti
Polish	Polski
Icelandic	Íslenska
Croatian	Hrvatski
Slovenian	Slovenščina
Romanian	limba română
Bulgarian	Български език
Lithuanian	Lietuvių kalba

# OPERATOR'S STATION


## Unit Selection

Unit system displayed on the monitor can be selected in this screen.

1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).




MDC1-01-001




MDCD-01-026

2. Rotate selector knob (2) to highlight Setting Menu (4).



MDAA-01-114EN


3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate selector knob (2) to highlight Unit Selection (6).



MDAA-01-181EN


## OPERATOR'S STATION

5. Push selector knob (2) to display Unit Selection screen (7).



MDCD-01-026

6. Rotate selector knob (2) to highlight the Desired Unit System. Push selector knob (2) to set the unit (Metric or US system).




MDAA-01-182EN


7. Before changing °C and °F, turn the blower of the air conditioner ON.

Rotate selector knob (2) to highlight desired unit system (°C or °F). Push selector knob (2) to set the unit.

When pressing selector knob (2), "Wait." will be displayed and then the change will be completed.



MDAA-01-183EN




MDAA-01-184EN

## OPERATOR'S STATION


### Display Item Selection (Rear View Camera OFF)

The display under the meters can be set to OFF (disable), Logo or Operational information.

1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).




MDC1-01-001




MDCD-01-026

2. Rotate selector knob (2) to highlight Setting Menu (4).



MDAA-01-114EN

3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate selector knob (2) to highlight Display Item Selection (6).




MDC1-01-237EN




## OPERATOR'S STATION


5. Push selector knob (2) to display Display Item Selection screen (7).




6. Rotate selector knob (2) to highlight the Desired Display. Push selector knob (2) to set the image. (Selecting OFF sets non-display.)

 **NOTE:** When a display is selected, the mark "■" is displayed in green. When not selected, the mark "■" is displayed in gray.

MDCD-01-026




MDAA-01-238EN



Logo

MDC1-01-239



Operation Information


MDC1-01-222

## OPERATOR'S STATION


### Main Menu Sequence Change

Menu sequence of Air Conditioner, Radio and Work Mode can be changed in this screen. Frequently used menu can be located on top of the screen.

1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).




MDC1-01-001



MDCD-01-026


2. Rotate selector knob (2) to highlight Setting Menu (4).



MDAA-01-114EN


## OPERATOR'S STATION

3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate selector knob (2) to highlight Main Menu Sequence Change (6).




MDAA-01-186EN

5. Push selector knob (2) to display Main Menu Sequence Change screen (7).



MDCD-01-026

6. Rotate selector knob (2) to highlight a menu to be on the top of the screen. Push selector knob (2) to set the menu to the top of the screen.




MDAA-01-187EN

# OPERATOR'S STATION


## Information Menu

The information menu includes Operation, Maintenance Troubleshooting and Monitoring.


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Information Menu (4).
3. Push selector knob (2) to display Information Menu screen (5).




MDC1-01-001



MDCD-01-026



MDAA-01-190EN




MDAA-01-191EN-NH

# OPERATOR'S STATION

## Operation


The Operation screen displays Fuel Consumption, Breaker Operation, Attachment Operation, Travel Operation, and Actual Operation menus. The Fuel Consumption screen displays fuel consumption, operating hours, and fuel consumption rate, for the period since the monitoring unit was last reset. The Breaker Operation screen displays breaker operating hours, machine operating hours and operating rate, for the period since the monitoring unit was last reset. The Attachment Operation screen displays total operating hours of front attachment, travel and all operation for the period since the monitoring unit was last reset.




MDC1-01-001

## Fuel Consumption


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Information Menu (4).
3. Push selector knob (2) to display Information Menu screen (5).
4. Rotate selector knob (2) to highlight Operation (6).



MDCD-01-026




MDAA-01-190EN



MDAA-01-191EN-NH

## OPERATOR'S STATION


5. Push selector knob (2) to display Operation screen (7).



MDCD-01-026

6. Rotate selector knob (2) to highlight Fuel Consumption (8).


7. Push selector knob (2) to display Fuel Consumption screen (9).



MDAA-01-193EN

The Machine Operation Hours, Fuel consumption, and Average Fuel Consumption rate can be checked on this screen.

Pushing selector knob (2) returns to the previous screen. To clear the Fuel Consumption and Machine Operation Hours, rotate selector knob (2) to highlight CLEAR (10), and then push selector knob (2).



MDAA-01-194EN

**IMPORTANT: Total fuel consumption and fuel consumption rate depend on the operating environment and the operation method of the machine.**


**The values shown on the screen are just for reference.**

**A difference could arise between actual fuel consumption and fuel consumption as displayed on the monitor unit.**


## OPERATOR'S STATION

### Breaker Operation


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Information Menu (4).
3. Push selector knob (2) to display Information Menu screen (5).
4. Rotate selector knob (2) to highlight Operation (6).




MDC1-01-001



MDCD-01-026




MDAA-01-190EN



MDAA-01-191EN-NH

## OPERATOR'S STATION


5. Push selector knob (2) to display Operation screen (7).



MDCD-01-026

6. Rotate selector knob (2) to highlight Breaker Operation (8).

7. Push selector knob (2) to display Breaker Operation screen (9).




MDAA-01-196EN

Operating Time, Machine Operation Hours and Operation Ratio can be checked in this screen.

Pushing selector knob (2) returns to the previous screen.

To clear the Operation Time and Machine Operation Hours data, rotate selector knob (2) to highlight CLEAR (10), and then push selector knob (2).




MDAA-01-197EN




# OPERATOR'S STATION

## Attachment Operation


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Information Menu (4).
3. Push selector knob (2) to display Information Menu screen (5).
4. Rotate selector knob (2) to highlight Operation (6).




MDC1-01-001



MDCD-01-026




MDAA-01-190EN



MDAA-01-191EN-NH


# OPERATOR'S STATION

5. Push selector knob (2) to display Operation screen (7).



MDCD-01-026

6. Rotate selector knob (2) to highlight Attachment Operation (8).




MDAA-01-199EN

7. Push selector knob (2) to display Attachment Operation screen (9).

The attachment Operating Time can be checked in this screen.

Push selector knob (2) to return to the previous screen. To clear the Operating Time data, rotate selector knob (2) to highlight CLEAR (10), and then push selector knob (2).




MDAA-01-200EN


# OPERATOR'S STATION

## Travel Operation


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Information Menu (4).
3. Push selector knob (2) to display Information Menu screen (5).
4. Rotate selector knob (2) to highlight Operation (6).




MDC1-01-001



MDCD-01-026




MDAA-01-190EN



MDAA-01-191EN-NH

## OPERATOR'S STATION


5. Push selector knob (2) to display Operation screen (7).



MDCD-01-026


6. Rotate selector knob (2) to highlight Travel Operation (8).

7. Push selector knob (2) to display Travel Operation screen (9).



MDAA-01-202EN

Total Travel Operating Time can be checked in this screen. Push selector knob (2) to return to the previous screen. To clear the Operating Time data, rotate selector knob (2) to highlight CLEAR (10), and then push selector knob (2).




MDAA-01-203EN


## OPERATOR'S STATION

### Actual operation


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Information Menu (4).
3. Push selector knob (2) to display Information Menu screen (5).
4. Rotate selector knob (2) to highlight Operation (6).




MDC1-01-001



MDCD-01-026




MDAA-01-190EN



MDAA-01-191EN-NH


## OPERATOR'S STATION

5. Push selector knob (2) to display Operation screen (7).



MDCD-01-026


- 6. Rotate selector knob (2) to highlight Actual Operation (8).
- 7. Push selector knob (2) to display Actual Operation screen (9).



MDAA-01-205EN

The actual Operating Time can be checked in this screen. Push selector knob (2) to return to the previous screen. To clear the Operating Time data, rotate selector knob (2) to highlight CLEAR (10), and then push selector knob (2).

**NOTE:** The Operating Time includes travel operation hours as well as all other operations.



MDAA-01-206EN

# OPERATOR'S STATION

## Maintenance


The maintenance screen includes maintenance notice, remaining hours until the next maintenance, and maintenance intervals.

### Maintenance Items


- Engine Oil
- Engine Oil Filter
- Hydraulic Oil
- Hydraulic Oil Pilot Filter
- Hydraulic Oil Full-Flow Filter
- Pump Transmission Oil
- Travel Device Oil
- Swing Device Oil
- Swing Bearing Grease
- Air Cleaner Filter
- Fuel Filter
- Air Conditioner Filter
- DEF/AdBlue® Supply Module Main Filter
- Fuel Solenoid Pump Filter
- Oil Separator Element (Only ZX130-6N, 160LC-6N, 180LC-6N)
- User Setting 1
- User Setting 2

### Maintenance Notice


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Information Menu (4).
3. Push selector knob (2) to display Information Menu screen (5).
4. Rotate selector knob (2) to highlight Maintenance (6).




MDC1-01-001



MDCD-01-026




MDAA-01-190EN



MDAA-01-223EN-NH

## OPERATOR'S STATION

5. Push selector knob (2) to display Maintenance screen (7).




MDCD-01-026

6. Rotate selector knob (2) to highlight Maintenance Notice (8).


7. Push selector knob (2) to turn the Maintenance Notice ON. Push selector knob (2) again to turn the Maintenance Notice OFF.


ON : When the required interval is reached, an information message is displayed on the screen.

OFF : No notification message is displayed.




MDAT-01-208EN

 **NOTE:** When the required interval for an item is reached, screen (9) is displayed for 10 seconds when the key is switched ON. Push Return to Previous Screen switch to delete the notification. When checking the maintenance items from the menu, items where the set time has been reached are marked with a spanner.



MDC1-01-213EN




MDAA-01-214EN




## OPERATOR'S STATION

### Remaining Time and Maintenance Interval


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Information Menu (4).
3. Push selector knob (2) to display Information Menu screen (5).
4. Rotate selector knob (2) to highlight Maintenance (6).




MDC1-01-001



MDCD-01-026




MDAA-01-190EN



MDAA-01-223EN-NH

## OPERATOR'S STATION


5. Push selector knob (2) to display Maintenance screen (7).



MDCD-01-026

6. Rotate selector knob (2) to highlight a Maintenance Item to be checked (8). (In the example on the right, Engine Oil is selected.)

7. Push selector knob (2) to display the time remaining for the selected maintenance item.




MDAA-01-336EN

### Resetting Data


To reset the remaining time data, rotate selector knob (2) to highlight RESET (9), and then push selector knob (2).

The value of the remaining hours is reset to that of the change interval. The previous change date/hour is updated with the current date and time.


### Maintenance Interval Setting

To change the maintenance interval, rotate selector knob (2) to highlight  (11), and then push selector knob (2).

The background color of Maintenance Interval (10) changes, then rotate selector knob (2) to adjust the time, and then push selector knob (2) to enable the change.



MDAA-01-210EN




MDAA-01-212EN

# OPERATOR'S STATION


## Troubleshooting

A fault code generated by the controller connected to the controller area network is displayed on this screen.


1. Push switch (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate switch (2) to highlight Information Menu (4).
3. Push switch (2) to display Information Menu screen (5).
4. Rotate switch (2) to highlight Troubleshooting (6).




MDC1-01-001



MDCD-01-026




MDAA-01-190EN



MDAA-01-215EN

## OPERATOR'S STATION

- Push selector knob (2) to start troubleshooting. After displaying "Wait." message, the screen displays controller troubleshooting (7).




MDCD-01-026


- Currently generated fault codes are displayed at the right side of each item. Rotate selector knob (2) to highlight an item displaying the failure codes.
- Push selector knob (2) to display currently generated fault code (8).

Up to 20 fault codes can be displayed.


**IMPORTANT:** Send the troubleshooting result to your nearest HITACHI sales representative as soon as possible.



MDAA-01-216EN



MDAA-01-218EN




MDAA-01-219EN

# OPERATOR'S STATION


## Monitoring

The engine speed can be checked.


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Information Menu (4).
3. Push selector knob (2) to display Information Menu screen (5).
4. Rotate selector knob (2) to highlight Monitoring (6).




MDC1-01-001



MDCD-01-026




MDAA-01-190EN




MDAA-01-220EN-NH

# OPERATOR'S STATION

5. Push selector knob (2) to display Monitoring screen (7).



MDCD-01-026




MDC1-01-221EN

## OPERATOR'S STATION

### Switch Panel

- 1- Return to Previous Screen Switch
- 2- Return to Basic Screen Switch
- 3- Selector Knob
- 4- Temperature Control Switch/Mode Switch
- 5- AUTO/OFF Switch/Fan Switch
- 6- AM/FM Selector/Tuning Switch
- 7- Power Switch/Volume Control Knob
- 8- Engine Control Dial
- 9- Auto-Idle Switch
- 10- Travel Mode Switch
- 11- Power Mode Switch
- 12- Work Light Switch
- 13- Wiper/Washer Switch
- 14- Numeric Keypad



## OPERATOR'S STATION

---

### Return to Previous Screen Switch (Monitor)

Push this switch to return to the previous screen.



MDAA-01-010

### Return to Basic Screen Switch (Monitor)

Allows any screen to return to the basic screen.




MDAA-01-011

### Selector Knob (Monitor)

Push : Push this switch while the basic screen is displayed, the menu screen opens.

Push this switch after the menu screen, the action is confirmed.

Rotate : Cursor moves.




MDAA-01-012

### Temperature Control Switch/Mode Switch (Air Conditioner)

Push : Air vent is selected.

Rotate : Sets the temperature.

TEMP/MODE



MDAA-01-013

### AUTO/OFF Switch/Fan Switch (Air Conditioner)

Push : Push this switch while the air conditioner is OFF, and it turns to AUTO. Push this switch while operating the air conditioner, and it turns OFF.

Rotate : Adjusts the blower speed.



MDAA-01-015




## OPERATOR'S STATION

### AM/FM Selector/Tuning Switch (Radio)

Push : AM/FM is selected.

Rotate : Adjusts radio frequency.

PUSH  
TUNE/AM,FM




MDAA-01-014

### Power Switch/Volume Control Knob (Radio)

Push : Turns power ON/OFF.

Rotate : Adjusts the volume.

PUSH  
VOL/PWR




MDAA-01-016

### Engine Control Dial

Use engine control dial (1) to adjust engine speed.

The fully clockwise position : Fast Idle

Counterclockwise : Slow Idle



M1P1-01-068

## OPERATOR'S STATION

### Auto-Idle Switch


Auto-idle switch (2) sets the engine speed control mode to either Auto-Idle ON or OFF.

- Auto-Idle Speed


When auto-idle switch (2) is turned to ON position, the engine speed decreases to the idle after approximately 4 seconds at the state in which the control lever is turned to neutral.

This function saves fuel consumption.

When the auto-idle mode is selected, auto-idle indicator (3) on the monitor panel lights.



MDAA-01-017



MDC1-01-314

 **NOTE:**


- Auto-idle control may not work completely until the end of the warm-up.
- The auto-idle control function does not operate when the aftertreatment device is regenerating.

### Travel Mode Switch

Two travel modes, FAST and SLOW, are selected by turning the travel mode switch to either position.

 Mark (Fast Speed Mode)

 Mark (Slow Speed Mode)




MDCD-01-028


## OPERATOR'S STATION

### Power Mode Switch

The three engine speed modes, ECO, PWR or H/P mode are selected by operating the power mode switch.

- ECO (Economy) Mode  
Operate the machine in this mode when performing normal work.  
ECO is displayed on Power Mode Display (1).
- PWR (Power) Mode  
Use PWR (Power) mode when extra horsepower is needed.  
PWR is displayed on Power Mode Display (1).
- H/P (High Power) Mode  
Use the H/P mode when extra fast speed and/or heavy duty work is needed.

 **NOTE:** ECO mode is set automatically when starting the engine. Set PWR mode if necessary.




MDAA-01-274


MDC1-01-001

### Work Light Switch


Work light switch has the following positions.

- 1 Position : Work light (3) on the base machine will light.  
Also, the switch panel illumination will light.
- 2 Position : Work light (4) mounted on the boom and work light (3) on the right side of the machine will light. At the same time, the switch panel illumination will light. The monitor changes to night mode.
- OFF : Work lights (3), (4), and the switch panel illumination will turn off.

 **NOTE:** When the key switch is turned OFF while the work light switch is in 2-position, work light (4) turns ON for 30 seconds.



MDCD-01-029



M157-01-146

## OPERATOR'S STATION

### Wiper/Washer Switch

The wiper and the window washer are operated using the wiper/washer switch.

- **Wiper**  
Turn the wiper/washer switch to the specified position to operate the wiper.

**OFF** The wiper stops and is retracted.


**INT Position** The wiper operates intermittently at the interval selected by the switch position as described below. INT mode has three positions of operating speed as shown below.

**INT (Slow):** The wiper operates at 8-second interval.


**INT (Mid):** The wiper operates at 6-second interval.


**INT (Fast):** The wiper operates at 3-second interval.

**ON** The wiper operates continuously.


 **NOTE:** When the front window (upper) is opened, the wiper and washer will not operate. If the front window is opened while operating the wiper, the wiper stops.

- **Washer**  
Push and hold the wiper/washer switch to squirt washer fluid onto the front window. When the wiper/washer switch is pressed for more than 2 seconds, the wiper operates until the switch is released. When the wiper/washer switch is released, the wiper automatically retracts.  
When operating the wiper in INT mode, while push and hold the wiper/washer switch, the wiper operates continuously.

 **NOTE:** The wiper motor protection control stops wiper operation, to prevent it from becoming stuck when operated for long period of time under high load. When the wiper stops, do not change the arm position and wait several minutes until the wiper starts operation again.



MBFM-01-005



MDC1-01-513

## OPERATOR'S STATION

---


### Numeric Keypad

Used for inputting password.

Push the numeric keypad of 1 to 8 while the radio is ON, the radio station will switch to memorized channel of 1 to 8.

When the light is turned ON, the monitor changes to night mode screen.


Even if the light is turned ON, you can activate the daytime screen by pushing "0" on the numeric keypad.




MDAA-01-018

## OPERATOR'S STATION

### Switch Panel (for Optional Equipments)

 **NOTE:** The optional switch locations differ, depending on the kinds of optional devices that the machine is equipped with. Before using the switches, confirm which types of optional devices the machine is equipped with. Raise the armrest when operating the optional switch. All available optional devices are shown below.


- Travel Alarm Deactivation
- Rear Light
- Electrical Control
- ON/OFF Operation




MDAA-01-327

## OPERATOR'S STATION

### Travel Alarm Deactivation Switch (Optional)


The travel alarm buzzer sounds during travel operation. When pushing the  mark of travel alarm deactivation switch (1), the travel alarm buzzer function is deactivated.



M1U1-01-035

### Rear Light Switch (Optional)

When rear light switch (2) is turned ON, the rear light at the rear of the cab roof comes ON.




MDC1-01-501

### Electrical Control Main Switch (Optional)


Turn the pilot control shut-off lever to the UNLOCK position. The electrical control (grip switch) system becomes operable by pushing electrical control main switch (3). It is turned OFF by pressing switch (3) again. It is also turned OFF when the key switch is turned OFF or the pilot control shut-off lever is turned to LOCK position.


**CAUTION:** When there is no need to use the electrical control (grip switch) system, turn OFF main switch (3) to avoid incorrect operation.




MDAA-01-311

### ON/OFF Operation Switch (Optional)

When the  marked side of ON/OFF operation main switch (4) is pressed, the ON/OFF operation (grip switch) system becomes operable.

**CAUTION:** When there is no need to use the ON/OFF operation (grip switch) system, push the  marked side of the main switch to avoid incorrect operation.




MDAA-01-356

## OPERATOR'S STATION

### Key Switch


- 1- OFF (Engine Off)
- 2- ACC (Horn, Radio etc.)
- 3- ON (Engine ON)
- 4- START (Engine Start)



MDC1-01-502

### Power Boost Switch


Power boost switch (5) is provided on the top of the right control lever. While pressing power boost switch (5), the maximum digging power is boosted within approximately 8 seconds to increase work capacity.



MDAA-01-292

### Horn Switch

Horn switch (6) is provided on the top of the left control lever. The horn sounds continuously as long as switch (6) is pressed.




MDAA-01-293



## OPERATOR'S STATION

### Electrical Control Main Switch (Optional)

- Attachment Switch (Assist Operation) (Main Operation)  
This switch (1) is mainly used for optional devices and attachments with a rotary or a tilt function. The attachment becomes operable when electrical control main switch (1) is pushed and main switch indicator (2) is lit.




MDAA-01-311

**IMPORTANT: The attachment switch is operable only when indicator (2) of electrical control main switch (1) is lit. Indicator (2) will not light unless the pilot control shut-off lever is in the UNLOCK position. Indicator (2) turns OFF and the attachment switch becomes inoperable when the pilot control shut-off lever is placed in the LOCK position while indicator (2) is lit. To operate the attachment switch, place the pilot control shut-off lever in the UNLOCK position, and then push electrical control main switch (1) to turn indicator (2) light ON.**

### AUX Function Lever 1

1. Auxiliary
2. Power Boost Switch
3. Attachment Switch (Assist Operation)
4. Auxiliary
5. Horn Switch
6. Auxiliary



Left Control Lever

Right Control Lever


MDAA-01-337

MCGB-01-030

## OPERATOR'S STATION

### ON/OFF Operation Switch (Optional)

- Attachment Switch (Assist Operation)  
This switch is mainly used for optional devices and attachments having a rotary or tilt function. The attachment moves only when the switch is pressed.




MDAA-01-356

**IMPORTANT:** When the  mark side of ON/OFF operation main switch (1) is pressed, the attachment switch becomes operable.

### AUX Function Lever 3

1. Attachment Switch (Assist Operation)
2. Power Boost Switch
3. Auxiliary
4. Auxiliary
5. Horn
6. Attachment Switch (Assist Operation)



MDAA-01-337

MDAA-01-337

### CAUTION:

- **These switches are provided for operating attachments of this machine. Hitachi does not bear responsibility on any human injury, malfunction and/or physical loss or damage incurred by unauthorized application or use of unauthorized attachments, optional parts or modified switches, that void the Hitachi Warranty Policy.**
- **Before using this switch, thoroughly read the operation manual of the corresponding attachment and check the operation of each function in a safe area.**
- **Before operating an attachment with this switch, confirm the requirements on safe and proper mounting and operation of the attachment with its manufacturer or distributor and observe them.**

## OPERATOR'S STATION


### Cigar Lighter

#### Using Cigar Lighter


**IMPORTANT:** In case the cigar lighter does not pop out automatically 30 seconds after pushing the cigar lighter in, pull out the cigar lighter manually. Consult your authorized dealer.

1. Insert key switch (1). Turn it to "ACC" or "ON" position.
2. Push and release the cigar lighter knob.
3. The cigar lighter knob will return to the original position when the lighter becomes usable. Pull the cigar lighter out to use.
4. After use, reinsert the cigar lighter to its original position in the panel.

**CAUTION:** Do not power anything other than a genuine Hitachi Construction Machinery electrical device from the cigar lighter port.



MDC1-01-502




MDAA-01-297

## OPERATOR'S STATION


### Cab Light Switch

Push switch (1) on the cab light to turn the cab light ON.

- ON : The cab light comes and stays ON.  
(The light does not turn ON while the key OFF.)
- OFF : The cab light goes OFF.
- Neutral : The cab light turns ON as the cab door is opened.  
The cab light automatically goes off after 30 seconds.  
(The cab light turns ON while the key switch is OFF.)




MDAA-01-305



MDAA-01-318

### Installing Fire Extinguisher (Optional)

A fire extinguisher can be installed at the left rear corner inside the cab. Consult your authorized dealer to install a fire extinguisher.



MDAA-01-319


## OPERATOR'S STATION

### Pilot Control Shut-Off Lever

Pilot control shut-off lever (1) functions to prevent the machine from being mistakenly operated when the operator accidentally touches the control lever or pedals when getting on or off the machine.


#### **⚠ WARNING:**

- **Always pull pilot control shut-off lever (1) into the full LOCK position. Unless pilot control shut-off lever (1) is fully moved to the LOCK position, the control lever is not locked, possibly creating a hazardous situation.**
- **When leaving the machine, always stop the engine. Then, pull pilot control shut-off lever (1) up to the LOCK position.**
- **Always pull pilot control shut-off lever (1) up to the LOCK position before transporting the machine and leaving the machine.**
- **Confirm that pilot control shut-off lever (1) is in the LOCK position before starting the engine. The engine will not start in any position other than the LOCK position.**



LOCK position

MDAA-01-295




UNLOCK Position

MDAA-01-296

### Engine Stop Switch

In case the engine does not stop even if the key switch is turned OFF due to failure of the machine, move switch (2) located at the front-left side of the seat stand downward to stop the engine.

After operating switch (2), be sure to return switch (2) back to the upward position.




MDAA-01-290

## OPERATOR'S STATION

### Fuse Box


#### A

10- CONTROLLER 5 A	20- OPT.3 (ALT) 5 A
9- BACKUP 10 A	19- HORN 10 A
8- ECU 30 A	18- IDLE STOP 5 A
7- START 5 A	17- POWER ON 5 A
6- OPT.2 (ALT) 20 A	16- GLOW RELAY 5 A
5- OPT.1 (ALT) 5 A	15- AUX 10 A
4- SOLENOID 20 A	14- MONITOR 5 A
3- HEATER 20 A	13- LIGHTER 10 A
2- WIPER 10 A	12- RADIO 5 A
1- LAMP 20 A	11- FUEL PUMP 5 A



MDAA-01-297

#### A




M1GR-01-003

#### B

30- -	40- -
29- -	39- -
28- SENSOR_UNIT 10 A	38- -
27- AUX.3 5 A	37- -
26- QUICK HITCH 5 A	36- -
25- IMMOBI 5 A	35- DCU 20 A
24- 12VUNIT 10 A	34- AUX.2 10 A
23- CAB LAMP REAR 10 A	33- WARNING LAMP 10 A
22- CAB LAMP FRONT 10 A	32- CAB LAMP FRONT +2 10 A
21- SEAT HEATER 10 A	31- SEAT COMPR. 10 A

#### B



M1GR-01-003


## OPERATOR'S STATION

---

### Auto Air Conditioner

#### Features:


- Full Auto-Temperature Control:  
Automatically controls the air temperature in the cab to maintain the temperature set by the temperature control switch regardless of outside air temperature and intensity of the sun.
- Max. Cooling and Heating:  
Maximum cooling or heating can be obtained by rotating the temperature control switch clockwise (32 °C) or counterclockwise (18 °C) respectively.
- Heater Start-Operation Control System:  
In winter or in cold weather, when starting the engine, the engine coolant is cool and air temperature inside the cab is low. Until the coolant is warmed, when the front foot vent and/or foot vent is selected, the air flow level is fixed to the minimum setting and cool air is restricted from entering the cab.


 *NOTE: Even in summer, the high idle speed may be higher than the normal speed due to the above control system.*

## OPERATOR'S STATION


### Name of Components

- 1- Front Vent
- 2- Foot Vent
- 3- Defroster Vent
- 4- Rear Vent
- 5- Temperature Control Switch/Mode Switch
- 6- AUTO/OFF Switch/Fan Switch


 **NOTE:** Air flow direction can be adjusted by moving the louvers on all air vents except for foot vent (2). The louvers on front vents (1) and defroster vent (3) can be completely opened and closed by hand.



MDAA-01-295



MDAA-01-289








MDCD-01-026



# OPERATOR'S STATION

## Controller Part Name and Function

- Mode Switch (5)  
Selects the air vent. The selected air vent is indicated on monitor (7).
-  Air flows out of the front and defroster vents.  
(Including defroster vent)
-  Air flows out of the front, rear and defroster vents.  
(Including defroster vent)
-  Air flows out of the front, rear, foot and defroster vents.  
(Including defroster vent)
-  Air flows out of the foot vents.




MDCD-01-026

Each time mode switch (5) is pressed, the vent mode can be changed in 4 stages as illustrated below.



- When switch (6) is selected in AUTO:  
The air vent mode is automatically selected.
- Temperature Control Switch (5):  
Sets the air temperature in the cab.  
Temperature in the cab can be set between 18.0 and 32.0 °C by rotating temperature control switch (5). Temperature can be set in 0.5 °C increments.  
The set-temperature is displayed on monitor (7).




MDC1-01-001


## OPERATOR'S STATION

- Fan Switch (6)
  - When AUTO indicator (8) is ON, the blower speed is automatically controlled.
  - When AUTO indicator (8) is OFF, the blower speed is controlled in 6 steps. Rotate blower switch (6) clockwise to increase blower speed. Rotate blower switch (6) counterclockwise to decrease blower speed. Monitor (7) indicates the corresponding blower speed.
- AUTO/OFF Switch (6)

While the air conditioner is OFF, pressing AUTO/OFF Switch (6) switches the unit to AUTO mode. While operating the air conditioner, pressing AUTO/OFF switch (6) stops operation.



MDCD-01-026



MDC1-01-001

## OPERATOR'S STATION

---

### Cab Heater Operation

1. AUTO/OFF switch (6):

According to signals sent from various sensors, the air conditioner amplifier automatically selects the air flow-in vents, air suction ports, and air flow-in temperature at the vent, and controls the blower speed.


2. Temperature Control Switch (5):

Adjust temperature control switch (5) so that "25.0" is indicated on the monitor. Control air temperature inside cab using switch (5) as necessary.

3. As Required:

- Operate Mode switch (5) to manually select the air vent.
- Operate Fan switch (6) to manually control the blower speed.
- Operate the air conditioner setting screen on the monitor to maintain the air vent in the fresh air mode or air circulation mode.

Usually the cab heater turns the dehumidifier function OFF, however, it can be turned ON by switching the A/C to ON at the air conditioner setting screen.



MDCD-01-026

## OPERATOR'S STATION

### Cooling Operation

1. AUTO/OFF switch (6):

Push AUTO/OFF switch (6) to set the air conditioner AUTO mode. According to signals sent from various sensors, the air conditioner amplifier automatically selects the air flow-in vents, air suction ports, and air flow-in temperature at the vent, and controls the blower speed.


2. Temperature Control Switch (5):

Adjust temperature control switch (5) so that "25.0" is indicated on the monitor. Control air temperature inside the cab using switch (5) as necessary.


3. As Required:

- Operate Mode switch (5) to manually select the air vent.
- Operate Fan switch (6) to manually control the blower speed.
- Operate the air conditioner setting screen on the monitor to maintain the air vent in the fresh air mode or air circulation mode.

If the front window (lower) becomes misty, manually close the defroster vent (3). (The vent can be closed manually.)





MDCD-01-026




MDAA-01-295

## OPERATOR'S STATION

### Defroster Operation

1. Push AUTO/OFF Switch (6) to blow out temperature-controlled air. When starting the engine during the cold season, the engine coolant temperature and air temperature in the cab are low. The Heater Start-Operation Control System controls the blow rate to the minimum (LO) in order to restrict cool air from flowing into the cab.
2. Adjust temperature control switch (5) so that "25.0" is indicated on the monitor. From the air conditioner setting screen on the monitor, set to fresh air mode.
3. Select the front vents  or the front and rear vents  using mode switch (5).




MDCD-01-026

Control air flow direction by adjusting the louvers at front vent (1) and defroster vent (3).

Control air temperature in the cab by using temperature control switch (5).


If the windowpanes become misty during rainy season or in order to eliminate moisture, turn A/C ON at the air conditioner screen on the monitor.



MDAA-01-295

### Cool Head/Warm Feet Operation

Cool and warm air is simultaneously supplied to the head vents and feet vents respectively.

1. Push Fan switch (6) to adjust the blower speed.
2. Push MODE switch (5) to display the front, rear and foot vent mark  on the monitor.

Turn A/C ON from the air conditioner setting screen on the monitor.

Control air temperature inside the cab by using temperature control switch (5).

## OPERATOR'S STATION

### Tips for Optimal Air Conditioner Usage


#### For Rapid Cooling

Temperature in the cab may rise over 80 °C (176 °F) when the machine is exposed to sun light in the summer.

In this case, ventilate air in the cab first by opening the windows for rapid cooling.

After starting the engine, push AUTO/OFF switch (6). Set temperature to "18.0" on the monitor by using temperature control switch (5). Turn air circulation mode ON from air conditioner setting screen on the monitor.

Close the windows when the cab cools down to the ambient temperature.



MDAA-01-292


#### When Windows Become Misty

If the insides of the windows become misty during rainy weather or on humid days, operate the air conditioner to aid in keeping the windows clear.

When the atmosphere is very damp, and if the air conditioner has run excessively, the outside of the windows may become misty. If this happens, turn off the air conditioner to adjust the temperature in the cab.

#### Off-Season Air Conditioner Maintenance

To protect each part of the compressor from a lack of lubricant, operate the air conditioner at least once a month for several minutes with the engine running at a slow speed during off-season.



MDCD-01-026

#### IMPORTANT:

- **Do not suddenly increase the engine speed. Failure to do so may damage the compressor.**
- **Refer to the item "Check Air Conditioner Filter" in the Maintenance Chapter for maintenance of the air conditioner filters.**
- **Always clean the auto air conditioner sensor for effective air conditioner performance. Avoid placing any obstructions around the sensor.**

# OPERATOR'S STATION

## AM/FM Radio Operation

**CAUTION:** Refrain from listening to the radio in the cab while operating the machine.


### Controls on the Radio

#### 1- AM/FM Selector/Tuning Switch

"FM" or "AM" is switched over alternately each time the switch is pressed. Rotate tuning switch (1) clockwise to increase frequency, counterclockwise to decrease frequency.

#### 2- Power Switch/Volume Control Knob

Push: Turns power ON/OFF. Rotate the volume control knob (2) clockwise to increase the sound volume. Rotate it counterclockwise to decrease the sound volume.



MDCD-01-026

### Tuning Procedure

#### • Manual Tuning Procedure

Rotate tuning switch (1) until the desired station is reached.

#### • Automatic Search Function


1. Push selector knob (3) while displaying Basic Screen (4) to display Main Menu screen (5).

2. Rotate selector knob (3) to highlight Radio (6).


Push selector knob (3) to display the Radio screen.

Rotate selector knob (3) to highlight Seek (8). Push selector knob (3) to go to the next higher frequency station. Push selector knob (3).


Rotate selector knob (3) to highlight seek (7). Push selector knob (3) to go to the next lower frequency station. Push selector knob (3).



MDC1-01-001



MDAA-01-092EN



MDAA-01-095EN

# OPERATOR'S STATION


## Station Presetting Procedure

### Setting from Monitor


1. Select the desired station. Refer to the "Tuning Procedure" in the previous section.
2. Push selector knob (1) while displaying Basic Screen (2) to display Main Menu screen (3). Rotate selector knob (1) to highlight Radio (4).
3. Push selector knob (1) to display Radio screen (5).
4. Rotate selector knob (1) to highlight a CH to preset a station. (CH1 to CH8)
5. Push and hold selector knob (1) for more than 1 second. The current station is preset to the selected CH.

### Setting from numeric keypad


1. Select the desired station. Refer to the "Tuning Procedure" in the previous section.
2. Push and hold one keypad buttons (1 to 8) for more than 1 second. The current station is preset to the selected number of CH.




MDCD-01-027



MDC1-01-001



MDAA-01-092EN



MDAA-01-093EN




# OPERATOR'S STATION


## Station Auto-Presetting Procedure

Receivable stations can be automatically detected and preset to the memory.


1. Push selector knob (1) while displaying Basic Screen (2) to display Main Menu screen (3).
2. Rotate selector knob (1) to highlight Radio (4).  
Push selector knob (1) to display Radio screen (5).
3. Rotate selector knob (1) to highlight AUTO PRESET (6).
4. Push selector knob (1) to start AUTO PRESET process.  
AUTO PRESET scans reception frequency, and allocates the stations with the strongest signal to CH1 to CH8.  
AM frequency stations will be preset from CH1 to CH4,  
FM frequency stations will be preset from CH5 to CH8.  
Operating the radio during scan stops the AUTO PRESET.




MDCD-01-026



MDC1-01-001



MDAA-01-092EN




MDAA-01-099EN


# OPERATOR'S STATION

## TONE Control


1. Push selector knob (1) while displaying Basic Screen (3) to display Main Menu screen (4).
2. Rotate selector knob (1) to highlight Radio (5).  
Push selector knob (1) to display Radio screen (6).
3. Rotate selector knob (1) to highlight TONE (7).
4. Push selector knob (1) to adjust TONE control. Rotate selector knob (1) clockwise to boost treble. Rotate selector knob (1) counterclockwise to boost bass. Push selector knob (1) to enable the changes.




MDCD-01-026



MDC1-01-001



MDAA-01-092EN



MDAA-01-096EN

## OPERATOR'S STATION

### Audio Input (Optional)

**IMPORTANT:** This function is available only to a machine equipped with an audio input (optional). Use this function with proper sound volume.

#### Audio Input Selection

Attach the audio input (optional) device and push AM/FM Selector/Tuning Switch (1) to display AM and FM screen as well as AUX input screen (3).

#### Connecting audio device

By removing AUX IN Cap (4), the audio input terminal appears.

Connect your audio device to the audio input terminal of the machine with your audio cable.

#### IMPORTANT:


- Use  $\Phi 3.5$  mm stereo plug for the connection of audio input terminal.
- Put AUX IN cap (4) when the audio input is not in use.

#### Volume Control of audio device


Turn the volume down to the minimum beforehand, and then turn volume control knob (2) clockwise to adjust the volume.

#### IMPORTANT:


- If volume control knob (2) has been set to the maximum level the sound will be extremely loud. Set volume control knob (2) to the minimum first and then turn it clockwise to increase the volume. Adjust the volume control knob on the audio device if the sound is too low, even when the volume control knob (2) is set to the maximum level.
- Operate your audio device to play or stop the sound.



MDCD-01-026



MDC1-01-340



MDAA-01-341


## OPERATOR'S STATION

---

### Cab Door Release Lever

**⚠ CAUTION:**

- **Open the cab door all the way until it securely locks in the latch on the side of the cab.**
- **Do not unlock the cab door when the machine is parked on a slope or while the wind is strong. The cab door may close accidentally, possibly resulting in personal injury.**
- **When opening or closing the cab door, take extra care not to catch fingers between the base machine and the cab door.**



MDAA-01-320

To unlock the door, push down on lever (1).


## OPERATOR'S STATION

---

### Opening/Closing and Removing Cab Inside Window

**⚠ WARNING:**

- Open, close or remove the upper front cab window, overhead window, cab door window or lower front window only after lowering the front attachment to the ground and pulling up pilot control shut-off lever (1) to the LOCK position. Failure to do so may allow the machine to move unexpectedly if a control lever or pedal is mistakenly touched with a part of the body, possibly resulting in personal injury or death.
- Park the machine on a level surface and stop the engine before opening and closing the upper front window.
- When opening the upper front window, hold the window by hands, hold it until the upper front window is locked.
- When closing the upper front window, it may accidentally fall under its own weight. Hold the upper front window with both hands until it is completely closed. The window stops once before closing completely. Do not operate the machine when the window is in this position. The upper front window is not locked in this position, there is a possibility that the window may drop suddenly.




MDAA-01-295


## OPERATOR'S STATION

### Opening Upper Front Window

#### Opening Upper Front Window

1. Press lock release lever (1) at the upper center to release the upper front window lock.
2. Holding lock release lever (1) at the upper center and lower handle (4) on the upper front window as illustrated, pull the upper front window up and back until auto locks (3) at both sides of the upper front window securely catches into the strikers on the ceiling.
3. After confirming that the window securely catches into auto locks (3), slide lock pin (2) into the left bracket boss hole to lock the window in position.

 **NOTE:** When the upper front window is opened, the wiper and washer are inoperable.




MDAA-01-358


#### CAUTION:

- Slowly close the upper front window that you do not catch your fingers.
- Always secure lock pin (2) in the lock position after the upper front window is opened.
- Always pull pilot control shut-off lever (5) to the LOCK position before opening or closing the upper front window.


4. To close the upper front window, hold lock release lever (1) at the upper center and lower handle (4) on the upper front window as illustrated, and follow steps 1 to 3 in the reverse order. The window stops before it completely closes, so close the front window by pushing release lever (1) upward.

Push lock release lever (1) downward to release auto lock (3).

 **NOTE:** Unless the upper front window is securely closed, the wiper and washer will not operate.



MDAA-01-359



MDAA-01-306

MDAA-01-360


## OPERATOR'S STATION

### Removing and Storing Lower Front Window


**CAUTION:** Take care not to get your fingers caught when handling the lower front window.

#### Removing and Storing Lower Front Window

1. Open the upper front window beforehand when removing the lower front window.
2. While pulling the lower front window inward, raise it to remove.
3. Store the removed windowpane in the storing position. After inserting the windowpane into rubber clips (2 and 3), slide it sideways securely into rubber clip (4). Push fastener (1) to lock.



MDAA-01-298




MDAA-01-299

## OPERATOR'S STATION

---

### Opening Side Window

Hold handle (1) and slide windowpane to open the side window.



Side Window

M178-01-061




## OPERATOR'S STATION


---

### Opening/Closing Overhead Window

Move locks (1) toward center of window. Hold handle (2) and lift window until it rises upright. With the window positioned upright, it will be secured in position by dampers (3). Hold handle (2) and pull window down until "click" sound is heard from left and right locks (1). Note that the overhead window can be used as an emergency exit.



MDAA-01-302



MDAA-01-303

## OPERATOR'S STATION

### Opening/Closing Overhead Window (Clear Hatch: If Equipped)


Move locks (1) toward center of window. Hold handle (2) and lift window until it rises upright. With the window positioned upright, it will be secured in position by dampers (3).

Hold handle (2) and pull window down until "click" sound is heard from left and right locks (1).


Note that the overhead window can be used as an emergency exit.

#### IMPORTANT:

- **Replace the clear hatch with a new one every 5 years even if undamaged. Replace the roof within 5 years if there is any visible damage or it receives a major impact.**
- **When cleaning the clear hatch, use a neutral detergent. If acidic or alkaline detergent is used, the clear hatch may become discolored or crack.**
- **Keep organic solvent away from the clear hatch. Failure to do so may cause the clear hatch to become discolored or crack.**



MDAA-01-302



MDAA-01-303

## OPERATOR'S STATION

### Emergency Exit

Escape from the cab in emergency in the following methods:

**CAUTION:** The danger of falling is always present when escaping from the cab in emergency, possibly resulting in serious personal injury. Escape from the cab as safely as possible, depending on the position of the machine and the situation outside.

1. Open the cab door. Escape through the door.
2. If the cab door is difficult to open or use, open the upper front window. Escape through the window.


**NOTE:** Emergency exit decals (2) are affixed to the front and rear windows. See page "OPENING UPPER FRONT WINDOW" for the opening method of the upper front window.

**CAUTION:** If decal (3) is affixed to the front windowpane, the windowpane can be broken. However if decal (3) is not affixed to the front windowpane, the glass cannot be broken with emergency evacuation hammer (1). Take care not to be injured by pieces of broken glass.


3. If the upper front window is difficult to open, check the decal (3) affixed to the windowpane.

If decal (3) is affixed to the front windowpane, break the front windowpane using the emergency evacuation tool (1) installed on the left side of the cab. Escape through the broken windowpane.


4. If decal (3) is not affixed to the front windowpane, or if it is not possible to escape through the front window, break the rear windowpane using emergency evacuation hammer (1). Escape through the broken windowpane.
5. If neither of front and rear windows are available for emergency exit, open the overhead window to escape from the cab.



MDAA-01-321



M1U4-01-012




MDAA-01-322

## OPERATOR'S STATION

### Adjusting Operator's Seat

**⚠ WARNING:** Adjust the seat only after lowering the front attachment to the ground and pulling up the pilot control shut-off lever to the LOCK position. Failure to do so may allow the machine to move unexpectedly if a control lever or pedal is mistakenly touched with a part of the body, possibly resulting in personal injury or death.


**⚠ CAUTION:** Avoid possible injury while operating height/tilt lever (1). When pushing down lever (1), do not grab it. Fingers may be pinched between lever (1) and the seat stand. Be sure to push on the upper face of lever (1) by your palm.



SS-955

#### Seat Height and Angle Adjustment

Seat height at both front and rear is adjusted in range of 60 mm (2.4 in) with 5 steps by using height tilt lever (1). Push down lever (1): to adjust front part of the seat. Pull up lever (1): to adjust rear part of the seat.



MDAA-01-290

#### Console and Seat Fore-aft Adjustment

Operate console and seat slide lever (3) to adjust the seat and both right and left consoles to the desired distance from the travel pedals and levers. The adjustment range for seat and console fore-aft is 160 mm (6.3 in) with 9 steps every 20 mm (0.8 in).

#### Seat Fore-Aft Adjustment

Operate seat slide lever (3) to adjust the seat to the desired distance from the travel pedals and levers. The adjustment range for seat fore-aft is 200 mm (7.9 in) with 21 steps every 10 mm (0.4 in).


#### Backrest Adjustment

Pull up lever (4) to release backrest lock. Move backrest to the desired position and release lever (4).

# OPERATOR'S STATION

## Armrest Adjustment

Armrest (5) can be pulled upright by hand 90°. Pull armrest (5) upright by hand to get on and off the machine easily. The angle of armrest (5) can be adjusted to the desired position by turning adjusting dial (6) located on the bottom of armrest (5).




MDC1-01-512

## OPERATOR'S STATION

### Adjusting Operator's Seat

**⚠ WARNING:** Adjust the seat only after lowering the front attachment to the ground and pulling up the pilot control shut-off lever to the LOCK position. Failure to do so may allow the machine to move unexpectedly if a control lever or pedal is mistakenly touched with a part of the body, possibly resulting in personal injury or death.

**⚠ CAUTION:** Avoid possible injury while operating height/tilt lever (1). When pushing down lever (1), do not grab it. Fingers may be pinched between lever (1) and the seat stand. Be sure to push on the upper face of lever (1) by your palm.



SS-955

#### Seat Height and Angle Adjustment


Seat height adjustment range is 60 mm (2.4 in) with steps every 15 mm (0.6 in) (5 positions in total).

Push down lever (1): to adjust front part of the seat.

Pull up lever (1): to adjust rear part of the seat.

#### Console and Seat Fore-aft Adjustment

Operate console and seat slide lever (3) to adjust the seat and both right and left consoles to the desired distance from the travel pedals and levers. The adjustment range for seat and console fore-aft is 160 mm (6.3 in) with steps every 20 mm (0.8 in).



MDAA-01-331

#### Seat Fore-Aft Adjustment

Operate seat slide lever (3) to adjust the seat to the desired distance from the travel pedals and levers. The adjustment range for seat fore-aft is 200 mm (7.9 in) with steps every 10 mm (0.4 in).

#### Suspension Adjustment

Rotate knob (4) to adjust the suspension.

Rotate knob (4) clockwise (+ direction) to increase suspension stiffness.


Rotate knob (4) counterclockwise (- direction) to decrease suspension stiffness.

## OPERATOR'S STATION

---

### Backrest Adjustment


Pull up lever (5) to release backrest lock. Move backrest to the desired position and release lever (5).



MDAA-01-331

### Armrest Adjustment

Armrest (6) can be pulled upright by hand 90°. Pull armrest (6) upright by hand to get on and off the machine easily. The angle of armrest (6) can be adjusted to the desired position by turning adjusting dial (7) located on the bottom of armrest (6).




MDC1-01-512

## OPERATOR'S STATION

### Adjusting Operator's Seat (Optional)

**⚠ WARNING:** Adjust the seat only after lowering the front attachment to the ground and pulling up the pilot control shutoff lever to the LOCK position. Failure to do so has the risk of operator's part of body touch the control lever or pedal by mistake, allowing the machine to move unexpectedly, which may result in personal injury or death.

**⚠ CAUTION:** Avoid possible injury while operating height/tilt lever (1). When pushing down lever (1), do not grab it. Fingers may be pinched between lever (1) and the seat stand. Be sure to push on the upper face of lever (1) by your palm.



SS-955

#### Seat Height and Angle Adjustment


Seat height adjustment range is 60 mm (2.4 in) with steps every 15 mm (0.6 in) (5 positions in total).

Push down lever (1): to adjust front part of the seat.

Pull up lever (1): to adjust rear part of the seat.

#### Console and Seat Fore-aft Adjustment

Operate console and seat slide lever (3) to adjust the seat and both right and left consoles to the desired distance from the travel pedals and levers. The adjustment range for seat and console fore-aft is 160 mm (4.7 in) with steps every 20 mm (0.8 in).



MDAA-01-332

#### Seat Fore-Aft Adjustment

Operate seat slide lever (3) to adjust the seat to the desired distance from the travel pedals and levers. The adjustment range for seat and console fore-aft is 200 mm (4.7 in) with steps every 10 mm (0.8 in).

#### Suspension Adjustment

**IMPORTANT:** The seat is supported by the air suspension system. Turn the key switch ON to supply air from the compressor.

Push and pull knob (4) to adjust the suspension. Pull the knob forward to release air, which makes it soft. Push the knob backward to fill air, which makes it hard.




## OPERATOR'S STATION

---

### Backrest Adjustment


Pull up lever (5) to release backrest lock. Move backrest to the desired position and release lever (5).



MDAA-01-332

### Armrest Adjustment

Armrest (6) can be pulled upright by hand 90°. Pull armrest (6) upright by hand to get on and off the machine easily. The angle of armrest (6) can be adjusted to the desired position by turning adjusting dial (7) located on the bottom of armrest (6).



MDC1-01-512

## OPERATOR'S STATION

### Adjusting Operator's Seat (Optional)

**⚠ WARNING:** Adjust the seat only after lowering the front attachment to the ground and pulling up the pilot control shut-off lever to the LOCK position. Failure to do so may allow the machine to move unexpectedly if a control lever or pedal is mistakenly touched with a part of the body, possibly resulting in personal injury or death.


#### Adjusting Seat Height

**IMPORTANT:** The seat is an air suspension type.

Pull lever (1) upward to fill air and raise the seat. Push lever (1) downward to release air and lower the seat. When the seat is properly adjusted for your weight, indicator (2) is in the green zone.

#### Console and Seat Fore-aft Adjustment

Operate console and seat slide lever (3) to adjust the seat and both right and left consoles to the desired distance from the travel pedals and levers. The adjustment range for seat and console fore-aft is 160 mm (6.3 in) with steps every 20 mm (0.8 in).



MDAA-01-333

#### Seat Fore-Aft Adjustment

Operate seat slide lever (4) to adjust the seat to the desired distance from the travel pedals and levers. The adjustment range for seat fore-aft is 190 mm (7.5 in) with steps every 10 mm (0.4 in).

## OPERATOR'S STATION

### Suspension Adjustment

Rotate knob (5) to adjust the suspension.

Rotate knob (5) clockwise to decrease suspension stiffness.

Rotate knob (5) counterclockwise to increase suspension stiffness.

### Fore-Aft Position Adjustment of Seat Surface


Pull lever (6) upward to adjust the seat angle. The adjustment range for seat and console fore-aft is 60 mm (2.4 in) with steps every 15 mm (0.6 in).

### Angle Adjustment of Seat Surface

Pull lever (7) upward to adjust the seat angle. Height of the seat surface is adjustable in 4 steps.

### Backrest Adjustment


Pull up lever (8) to release backrest lock. Move backrest to the desired position and release lever (8).



MDAA-01-333

### Armrest Adjustment

Armrest (9) can be pulled upright by hand 90°. Pull armrest (9) upright by hand to get on and off the machine easily. The angle of armrest (9) can be adjusted to the desired position by turning adjusting dial (10) located on the bottom of armrest (9).



MDC1-01-512

## OPERATOR'S STATION

---

### Console Height Adjustment

Adjust the console height to the operator's comfort and/or work conditions.


Console height can be vertically adjusted to 3 positions at 20 mm (0.8 in) intervals.

**⚠ CAUTION:** Before adjusting the console, support the console. Failure to do so may result in the console dropping suddenly, possibly causing personal injury.

#### Adjusting Procedures

1. Lower the bucket to the ground. Stop the engine.
2. Move the pilot control shut-off lever to the LOCK position.
3. Remove left and right console holding bolts (1). Loosen bolts (2) to adjust the console height.
4. After adjusting, tighten bolts (1) and (2).

Tightening Torque: 50 N·m (5 kgf·m)



M1U1-01-030

## OPERATOR'S STATION

---


### Installation and Adjustment of Mirrors

**⚠ WARNING:** Check visibility before operating the machine. If visibility is poor, adjust the angle of the mirrors. Improper adjustment of the mirrors provides poor visibility, which may cause serious human injury or death.

**IMPORTANT:** The image displayed on the rear view camera monitor is meant only as an aid. When operating the machine, pay thorough attention to the surrounding situation.

Adjust the mirrors so that persons standing within 1 m from the machine (or object with height of 1.2 to 1.5 m and 30 cm in diameter) can be seen from the operator's seat.

**IMPORTANT:** If a modification is made that may restrict the operator's visibility, recheck the operator's visual field.




MDAA-01-334

## OPERATOR'S STATION

### Seat Belt

#### WARNING:

- Be sure to use seat belt (1) when operating the machine.
- Before operating the machine, be sure to examine seat belt (1) and attaching hardware for any failure. If any damage and/or wear are found, replace the part concerned.
- Replace seat belt (1) every 3 years regardless of appearance.




M1U1-01-031

### Seat Belt

1. Confirm that seat belt (1) is not twisted. Securely insert the end of seat belt (1) into buckle (2). Lightly pull on the belt to confirm that the buckle latches securely.
2. Push button (3) on buckle (2) to unfasten seat belt (1).

Replace seat belt (1) if it is damaged or worn, or if the machine is involved in an accident which puts severe stress on the seatbelt.



M1U1-01-032

## OPERATOR'S STATION

### Battery Disconnect Switch

**IMPORTANT:** Do not turn the battery disconnect switch OFF while engine is running or the key switch is in another position than the OFF position. Failure to do so may damage the electrical system.

The battery disconnect switch differs from the engine start key switch. When the battery disconnect switch is turned OFF, the electrical system is cut off, so no electric current flows into the entire circuit.

Before turning the battery disconnect switch OFF, be sure to turn the key switch OFF and wait 5 minutes or more after the engine stops. If the battery disconnect switch is turned OFF within 5 minutes after the engine stops, it may result in malfunction of the electrical system. When the battery disconnect switch is turned from OFF to ON, the preset data of the radio or clock may be initialized. Set the radio and clock again.

Use the battery disconnect switch for the following purposes only.

- Before maintaining or servicing the electrical system
- Before storing the machine for long period of time, preventing the battery discharge
- Before welding operation on the machine body
- Before replacement of the battery




#### Switch Operation

1. Open cover (2).

When lever (1) is in the horizontal position, the battery disconnect switch is ON. When lever (1) is in the horizontal position, lever (1) can not be removed.

2. When lever (1) is turned counterclockwise to the vertical position, the battery disconnect switch turns OFF. Lever (1) can be removed from the battery disconnect switch when it is in the OFF position.

**IMPORTANT:** The DEF/AdBlue® Pump runs for a while after the engine stops to return DEF/AdBlue® from piping to the DEF/AdBlue® tank. Do not turn the battery disconnect switch to the OFF position during this time. Otherwise, the Urea SCR system may be damaged.







## BREAK-IN

---

### Observe Engine Operation Closely

**IMPORTANT:** Use extra caution during the first 50 hours of operation, until you become thoroughly familiar with the sound and feel of your new machine.

1. Only operate the machine in economy (ECO) mode and limit engine horsepower to around 80 % of its full load.
2. Avoid excess engine idling.
3. Check indicator lights and gauges frequently during operation.

### Every 8 Hours or Daily

1. Perform 8-hour or daily service.
2. Watch for fluid leaks.
3. Lubricate working tool pivots every 8 hours for the first 50 hours, and every 8 hours when working in mud and water.

### After the First 50 Hours

1. Perform 50-hour service.
2. Check accessible hardware torque. (See Hardware Torque Specifications in Maintenance chapter.)

### After the First 100 Hours

Perform 50-hour and 100-hour service.



## OPERATING THE ENGINE

---

### Inspect Machine Daily Before Starting

Perform the required daily check before starting the engine.

#### Engine

- Level of engine oil and coolant\*
- Ease of starting, exhaust gas color, and noise
- Oil and water leaks, damage to hoses and pipe lines\*
- Clogging and damage to radiator, oil cooler and intercooler\*
- Loose and/or missing mounting bolts and nuts\*

#### Upperstructure

- Fuel level, leaks and contamination of fuel in tank\*
- Level, leaks and contamination in DEF/AdBlue® tank
- Hydraulic oil level, contamination of hydraulic oil, leaks from hydraulic oil tank\*
- Movement, play and operating force of all control levers
- Operation of all hydraulic components, oil leaks and damage to pipings and hoses\*
- Deformity, breakage, and abnormal noise at each part
- Loose and/or missing mounting bolts and nuts\*
- Washer fluid\*
- Leaks from DEF/AdBlue® hoses
- Dirt around the aftertreatment device

#### Undercarriage


- Sag, wear and damage to crawler\*
- Oil leaks and wear on upper/lower rollers and front idlers
- Oil leaks from travel devices
- Loose and/or missing mounting bolts and nuts\*

#### Working Device

- Check cylinders, pipe lines and hoses for oil leaks and damage\*
- Wear and damage to the bucket
- Check for missing, loose and/or worn bucket teeth\*
- Condition of lubrication of the working device\*
- Check for damage to pin anti-extraction pins, stoppers, rings and bolts
- Loose and/or missing mounting bolts and nuts\*

#### Others

- Operation of instruments, switches, lights and buzzer/horn\*
- Function of parking brake
- Deformity and/or breakage to the head guard
- Abnormal outside appearance of machine
- Wear and damage of the seat belt\*

 **NOTE:** Item with \*mark: Refer to "Maintenance" section for detailed information.

## OPERATING THE ENGINE


### Before Starting Engine


1. Ensure that the battery disconnect switch is in the ON position.
2. Confirm that pilot control shut-off lever (1) is in the LOCK position.
3. Confirm that all control levers are placed in neutral.
4. Insert key (2) to the key switch. Turn it to ON position. Push and hold switch (3) with the engine stopped.

**IMPORTANT:** Always check the machine on a firm, level surface. Never attempt to start the engine while checking the machine.

If engine oil level (4) (green) is displayed, the status is normal.


5. Adjust the seat to allow full control pedals and levers stroke with operator's back against the backrest. Fasten the seat belt.

 **NOTE:** The monitor surface is a resin product. When the surface becomes dusty, lightly wipe the surface with a wet cloth. Never use an organic solvent.




LOCK Position


MDAA-01-295



MDC1-01-502



MDCD-01-026



MDC1-01-041


# OPERATING THE ENGINE

## Starting the Engine

### Starting the Engine in Ordinary Temperature


1. Confirm that pilot control shut-off lever (1) is in the LOCK position.
2. Turn engine control dial (3) to the slow idle position.
3. Sound horn to alert bystanders
4. Insert key (2) to the key switch. Turn it to ON position.
5. "Wait-screen (nothing is displayed)" is displayed on the monitor for 2 seconds. Regardless of pilot control shut-off lever (1) position, the engine can not be cranked during this moment.
6. When the Password Input screen is displayed on the monitor, input the password. Unless the numeric keypad function (ignition block system) is activated, this screen is not displayed.

**IMPORTANT:** When required to activate the numeric keypad function (ignition block system), consult your authorized dealer.




LOCK Position

MDAA-01-295



MDC1-01-502


M1P1-01-068



Password Input Screen


MDAA-01-085EN

## OPERATING THE ENGINE


 **NOTE:** When the key switch is turned ON, the maintenance notification (4) for the item whose maintenance interval has expired displays for 10 seconds. Push Return to Previous Screen switch (5) or turn the pilot control shut-off lever to the UNLOCK position while the rear view camera is enabled to delete the notification.

7. The Basic Screen will be displayed on the monitor. Check that the preheat indicator (6) is OFF at this time.
8. Turn key switch to the START position to rotate the starter. The engine will start.


**IMPORTANT:** Never operate the starter for more than 10 seconds at a time. If the engine fails to start, return the key switch to the OFF position. Wait for more than 30 seconds, then try again. Failure to do so may cause damage to the starter and/or discharging the batteries.



MDC1-01-213EN



MDCD-01-026



Basic Screen


MDC1-01-042


## OPERATING THE ENGINE


- Release key switch (2) just after the engine has started. Key switch (2) will automatically return to the ON position.

 **NOTE:**


- The engine speed will be kept to slow idle speed just after the engine starts. When engine speed control indicator (7) is displayed, slow idle speed will be maintained. When the coolant temperature or hydraulic oil temperature is low, the time will be longer. The engine speed will be kept to slow idle speed even if engine control dial (3) is not set in the slow idle position.
- After the slow idle speed is maintained, the warm-up system automatically operates and the engine speed will temporarily increase even if engine control dial (3) is set to the slow idle position.

 **CAUTION:** Do not attempt to operate the machine when engine speed control indicator (7) is lit. The engine speed may change after the slow idle period and operation speed of work device may suddenly increase, which may cause a serious accident.


 **NOTE:** White smoke may be emitted for several minutes after the engine start, this is not a malfunction.



MDCD-01-030



MDCD-01-026



MDC1-01-355


## OPERATING THE ENGINE

### Starting in Cold Weather

#### Preheating


1. Confirm that pilot control shut-off lever (1) is in the LOCK position.
2. Turn engine control dial (3) to around the middle between the L and H position.
3. Sound the horn to alert bystanders.
4. Insert key (2) to the key switch. Turn it to ON position.
5. "Wait-screen (nothing is displayed)" is displayed on the monitor for 2 seconds. Regardless of pilot control shut-off lever (1) position, the engine can not be cranked during this moment.
6. When the Password Input screen is displayed on the monitor, input the password. Unless the numeric keypad function (ignition block system) is activated, this screen is not displayed.

**IMPORTANT:** When required to activate the numeric keypad function (ignition block system), consult your authorized dealer.




LOCK position

MDAA-01-295



MDC1-01-502

M1P1-01-068




Password Input Screen


MDAA-01-085EN



## OPERATING THE ENGINE


 **NOTE:** When the key switch is turned ON, maintenance notification (4) for the item whose maintenance interval has expired displays for 10 seconds. Push Return to Previous Screen switch (5) or turn the pilot control shut-off lever to the UNLOCK position while the rear view camera is enabled to delete the notification.

7. The Basic Screen will be displayed on the monitor.  
The machine will automatically check if preheating is required or not. When preheating is required, preheat indicator (6) is lit for automatically.


 **NOTE:** In case, preheat indicator (6) does not come ON, preheating is not required. Follow the "Starting the Engine in Ordinary Temperature" section.

8. As soon as preheat indicator (6) goes OFF, turn key switch to START position to rotate the starter.


**IMPORTANT:** Never operate the starter for more than 10 seconds at a time. If the engine fails to start, return the key switch to the OFF position. Wait for more than 30 seconds, then try again. Failure to do so may cause damage to the starter and/or discharging the batteries.



MDC1-01-213EN



MDCD-01-026



Basic Screen


MDC1-01-042


## OPERATING THE ENGINE


- Release key switch (2) just after the engine has started.  
Key switch (2) will automatically return to ON position.

 **NOTE:**


- The engine speed will be kept to slow idle speed just after the engine starts. When engine speed control indicator (7) is displayed, slow idle speed will be maintained. When the coolant temperature or hydraulic oil temperature is low, the time will be longer. The engine speed will be kept to slow idle speed even if engine control dial (3) is not set in the slow idle position.
- The warm-up system automatically operates after keeping slow idle speed, and the engine speed will temporarily increase even if the engine control dial is set in the slow idle position.

 **CAUTION:** Do not attempt to operate the machine when engine speed control indicator (7) is lit. The engine speed may change after the slow idle period and operation speed of work device may suddenly increase, which may cause serious accident.


 **NOTE:** White smoke may be emitted for several minutes after the engine start, this is not a malfunction.



MDCD-01-030



MDCD-01-026



MDC1-01-355

## OPERATING THE ENGINE


### Check Instruments After Starting

#### Checking instruments through monitor functions

After starting the engine, check the following points through the monitor functions.

1. Check that alternator alarm indicator (1) is OFF. In case alternator alarm indicator (1) stays ON, immediately stop the engine. Inspect the alternator and battery system for any abnormality.
2. Check that engine oil pressure alarm indicator (2) is OFF and the alarm buzzer does not sound.

In case engine oil pressure alarm indicator (2) stays ON and the buzzer sounds, immediately stop the engine. Inspect the engine oil pressure system and the oil level.



**IMPORTANT:** In case any abnormality is found on the monitor unit, immediately stop the engine. Inspect the cause of the problem.

MDC1-01-041

#### Check engine noise and exhaust gas color

Check that the engine noise and exhaust gas color is normal.

 NOTE:

- Check the exhaust gas color as follows. (After warm-up operation, run the engine with no loads.)
  - Clear : Normal (Perfect combustion)
  - Black : Abnormal (Imperfect combustion, abnormal aftertreatment device, abnormal fuel system)
  - White : Abnormal (Oil is leaking into the combustion chamber, abnormal aftertreatment device, abnormal fuel system)
- White smoke may be emitted for several minutes after the engine starts, this is not a malfunction.

## OPERATING THE ENGINE

### Using Booster Batteries

**IMPORTANT:** The machine electrical system is a 24 volt negative (-) ground. Use only 24 volt booster batteries with sufficient capacity.

**WARNING:**

- An explosive gas is produced while batteries are in use or being charged. Keep open flames and sparks away from the battery area. Do not continue to use or charge the battery when electrolyte level is lower than specified. Explosion of the battery may result.
- Park the machine and a machine with the booster batteries on a dry or concrete surface, not on steel plates. If the machine is parked on steel plates, dangerous sparks may be unexpectedly created on the machine.
- Never connect a positive terminal to a negative terminal, as a dangerous short circuit will occur.




SA-032

When the machine batteries are exhausted, start the engine using booster batteries as shown below.

#### Connecting the booster batteries cables


1. Stop the engine of the machine on which booster batteries are mounted.
2. Turn the battery disconnect switch to the OFF position.
3. Connect one end of red cable (1) to the positive (+) terminal of the machine batteries, and the other end to the positive (+) terminal of the booster batteries.
4. Turn the battery disconnect switch to the ON position.
5. Connect one end of black cable (2) to the negative (-) terminal of the booster batteries, and then make ground connection to the frame of the machine to be started with the other end of black (-) cable (2). In the last connection to frame, sparks may fly. Be sure to connect the cable end as far away from the machine batteries as possible.
6. After securely connecting the booster cables, start the engine of the machine on which booster batteries are mounted.
7. Start the engine of the machine with a problem.
8. After the engine starts, disconnect cables (2) and (1), following the procedure below.



## OPERATING THE ENGINE

### Disconnecting the booster cables

1. Disconnect black negative (-) cable (2) from the machine frame first.
2. Disconnect the other end of black negative (-) cable (2) from the booster batteries.
3. Disconnect red positive (+) cable (1) from the booster batteries.
4. Disconnect red positive (+) cable (1) from the machine batteries.



## OPERATING THE ENGINE

### Stopping the Engine

#### Engine Stop Procedure

1. Except for special cases, before stopping the engine, lower the bucket to the ground.
2. Pull pilot control shut-off lever (3) to LOCK position.
3. Turn engine control dial (1) to the slow idle position and run the engine for 5 minutes to cool the engine.

**IMPORTANT:** If the engine equipped with a turbocharger is stopped without first performing the cool down operation, the lubricant on the turbocharger bearing surfaces may desiccate due to the intense heat present inside the turbocharger, possibly causing damage to the turbocharger.

**Do not idle for excessively long periods.**

**Observe local and federal engine idling regulations.**

4. Turn key switch (2) OFF to stop the engine.

#### If the engine does not stop, even if the key switch is turned to the OFF position. (Emergency Stop)


In case the engine does not stop even if key switch (2) is turned OFF due to failure of the machine, move engine stop switch (4) downward to stop the engine. The engine will stop. Return engine stop switch (4) to its original position (upward).

**CAUTION:** Do not use engine stop switch (4) unless absolutely necessary. When the machine stops due to machine failure, do not start the machine until repair is completed


**IMPORTANT:** The DEF/AdBlue® pump runs for a while after the engine stops to return DEF/AdBlue® from piping to the DEF/AdBlue® tank. Do not turn battery disconnect switch to the OFF position during this time. Otherwise, the Urea SCR system may be damaged.




SA-390




MDAA-01-295



M1P1-01-068



MDC1-01-502



MDAA-01-290

## OPERATING THE ENGINE

### Engine Auto-Stop in Extremely Low Temperature


**WARNING:** This function automatically stops the engine. Take extra care on the work and work environment when using this function.

**IMPORTANT:** If the machine is left unoperated in an environment with temperatures under  $-20\text{ }^{\circ}\text{C}$  or lower for a long period of time, exhaust gas particles may accumulate in the aftertreatment device, and may result in damage to the device.

In an environment with temperature of  $-20\text{ }^{\circ}\text{C}$  or lower, the engine will automatically stop 60 minutes after the pilot control shut-off lever is pulled to the LOCK position. 30 seconds before the engine stop, the monitor displays "Engine Shut-down soon." message (1) and the indicator starts flashing. The buzzer sounds once 30 seconds before shut-down, and sounds continuously from 15 seconds. The engine speed decreases to idling speed, and then stops after 15 seconds. When the pilot control shut-off lever is pushed down before stopping the engine, the auto shut-down is disabled and the engine will not stop.

**IMPORTANT:** When the engine stops, turn the key switch to ACC or OFF once and then turn it to START to restart the engine. In the case the engine stops automatically, turn the key switch OFF before leaving the machine for a long period of time. Do not leave the machine after auto shut-down. Failure to do so may discharge the batteries.

**NOTE:** The engine can stop automatically when related conditions are met regardless of the auto shut-down function being ON or OFF.



MDC1-01-146EN





# DRIVING THE MACHINE

## Travel Levers and Pedals


### Travel Operation

Travel operation of this machine is controlled by using levers and pedals.

**⚠ WARNING:** If the travel motors are located at the front of the machine, the machine will move in the reverse direction to that shown on the operation instruction decal. Normal travel operation is when the travel motor is at the rear, and the front idler is at the front of the machine.

### NOTE:

- An arrow-mark seal is stuck on the inside surface of the side frame to indicate the machine front direction.
- A travel lever dumper is provided on this machine to ensure smooth travel operation. Therefore, the travel lever or pedal may become heavier in extreme cold (-20 °C or below). This is caused by increase in oil viscosity, not a malfunction.




M104-01-038

### • Forward/Reverse Travel


Push down both left and right levers (or both pedals) frontward to travel the machine forward. Pull down the two levers (or pedals) rearward to travel the machine in reverse. Travel speed can be controlled by the operation stroke of the travel levers and pedals.

### • Ascend/Descend Slopes

Never attempt to ascend or descend slopes steeper than 35 degrees (70 %). Slowly operate the travel levers (or pedals) when descending a slope. When the travel levers are placed in the neutral position, brakes are automatically applied and the machine stops.



M178-03-001



Forward/Reverse Travel



M104-04-009  
M104-04-003

## DRIVING THE MACHINE

---

- Pivot Turn

The machine direction is changed by driving one of two crawlers with either left or right travel levers (or pedals).





Pivot Turn

M104-04-010  
M104-04-005

- Spin Turn

The machine direction is changed by driving two crawlers in opposite direction at a time by operating one lever (or pedal) to forward and another lever (or pedal) to reverse.



Spin Turn



M104-04-011  
M104-04-007



# DRIVING THE MACHINE


## Travel Mode Switch

**WARNING:** Tipping-over accidents can cause serious personal injury. Do not change travel mode switch (1) while traveling. In particular, changing to fast mode (2) while descending a slope is very dangerous. Always stop the machine before changing the travel speed mode.


Turn travel mode switch (1) on the switch panel to the specified position to select the travel mode (Fast/Slow).

- Fast Mode: Turn travel mode switch (1) to  mark (2) position.
- Slow Mode: Turn travel mode switch (1) to  mark (3) position.

-  Mark (Fast Speed Mode)
-  Mark (Slow Speed Mode)



MDCD-01-026



MDCD-01-028

## Travel Alarm (Optional)


During travel operation, the travel alarm sounds to warn people near the machine that the machine is traveling.

### Deactivating Travel Alarm


More than 12 seconds after starting to travel the machine, raise the armrest and push travel alarm deactivation switch (4) to stop the travel alarm. (Within 12 seconds, travel alarm deactivation switch (4) is inoperable.)

When restarting travel after stopping, the travel alarm will sound again. To stop the alarm, push travel alarm deactivation switch (4) again.

**NOTE:** The optional switch locations differ depending on what kinds of optional devices are equipped. Before using the switches, make sure what kinds of optional devices are equipped.



MDAA-01-327



M1U1-01-035

## DRIVING THE MACHINE

### Operating on Soft Ground

- Avoid traveling on very soft ground that does not have sufficient strength to firmly support the machine.
- If the machine is operated on very soft ground or becomes stuck, it may be necessary to clean the track frame area.
- Swing the upperstructure 90 ° and lower the bucket to raise one track off the ground. Keep the angle between the boom and arm 90 to 110 ° and position the rounded side of the bucket on the ground.
- Rotate the raised track back and forth to remove mud and dirt.
- After lowering the track to the ground, select slow travel speed. Carefully move the machine to firm ground.
- Utilize the boom and arm functions to pull the machine toward firm ground.
- Tow the machine if the machine becomes stuck but only if the engine is still operating. Be sure to attach the tow line correctly. (Refer to the "Towing Machine a Short Distance" section on the next page.)



M104-05-012



### Raise One Track Using Boom and Arm

**WARNING:** Keep the angle between boom and arm 90 to 110 ° and position the bucket's round side on the ground.

Swing the upperstructure 90 ° and lower the bucket to raise the track off ground. Do not dig bucket teeth into the ground when using the hoe bucket reversed.

Place blocks under machine frame to support the machine.

**IMPORTANT:** When the machine is modified as a face shovel by installing the hoe bucket in reverse, avoid raising the machine above the ground using the front attachment with the bucket cylinder fully extended. Excessive loads will be applied to the pins around the bucket and the bucket cylinder, resulting in breakage of the pins.



M104-05-013



MZX5-04-003

## DRIVING THE MACHINE

### Towing Machine a Short Distance

**CAUTION:** Cables, straps, or ropes can break causing serious injury. Do not tow the machine with damaged chains, frayed cables, slings, straps, or wire ropes. Always wear gloves when handling cable, straps or wire ropes.


When your machine becomes stuck but the engine is still operational, attach wire ropes to the machine as shown on the right, and slowly tow your machine to firm ground using another machine.

Be sure to attach the wire ropes around the track frames of both machines as shown.


To prevent the wire ropes from being damaged, place protective material between the track frame and the wire ropes.

**IMPORTANT:** Do not use the shackle holes on the track frame for towing the machine.


The center shackle hole on the track frame is provided to pull lightweight objects only. The shackle holes on the bottom of the track frame are used to secure the machine for transportation. Refer to the instructions on page 5-23 for using the center shackle hole appropriately.



M104-05-010



MZX5-04-004



MZX5-04-005

## DRIVING THE MACHINE

### Operating in Water or Mud

The machine can be operated in water up to the upper edge of the upper rollers only if water is flowing slowly, and the worksite ground is firm enough to prevent the machine from sinking past the upper edge of the upper roller.

Frequently check the position of the machine when working in such conditions. Reposition the machine if necessary.


Avoid submerging the swing bearing, swing gears and center joint.

If the swing bearing, swing internal gear and center joint are submerged, remove the drain plug to drain mud and water. Clean swing area. Install plug. Lubricate swing internal gear and swing bearing.

#### Swing Internal Gear Capacity

- ZX130-6N: 9L (2.4 US gal)
- ZX160LC-6N, 180LC-6N,  
210-6N, 210LC-6N,  
250LC-6N, 300LC-6N: 17 L (4.5 US gal)
- ZX350LC-6N, 380LC-6N: 19 L (5.0 US gal)

Lubricate swing bearing.



M104-05-009

Model	A
ZX130-6N	660 mm (26 in)
ZX160LC-6N, 180LC-6N, 210-6N, 210LC-6N, 250LC-6N	770 mm (30 in)
ZX300LC-6N, 350LC-6N, 380LC-6N	860 mm (34 in)


## DRIVING THE MACHINE

### Parking the Machine on Slopes

**⚠ WARNING:** Avoid parking machine on slopes. The machine may tip over, possibly resulting in personal injury.

If parking the machine on a slope is unavoidable:

- Thrust the bucket teeth into the ground.
- Return the control levers to neutral and pull pilot control shut-off lever (2) to the LOCK position.
- Block both tracks.



### Parking the Machine



1. Park the machine on a firm, level surface.
2. Lower the bucket to the ground.
3. Turn the auto-idle switch off.

**IMPORTANT:** Turbocharger may be damaged if the engine is not properly shut down.

4. Turn engine control dial (1) counterclockwise fully to Slow Idle position. Run the engine for approximately 5 minutes to cool the engine.
5. Turn the key switch to OFF. Remove the key from the key switch.
6. Pull pilot control shut-off lever (2) to the LOCK position.

**IMPORTANT:** Protect cab electrical components from bad weather. Always close windows, roof vent and cab door when parking the machine.

7. Close windows, roof vent, and cab door.
8. Lock all access doors and compartments.



MDAA-01-295





## OPERATING THE MACHINE

### Control Lever (ISO Pattern)

#### **⚠ WARNING:**

- Never extend any part of body beyond window bars or frame, as it could be crushed, if boom control lever is accidentally bumped or otherwise engaged.


Never remove the window sash bar.

- Make sure you know the location and function of each control before operating.
- Do not change the operation pattern of the control lever. Failure to do so may result in mistaken operation of the machine.


A label showing the control patterns of the levers and pedals is attached on the right side in the cab.

When a lever is released, it will automatically return to neutral, and that machine function will stop.


- 1- Arm Roll-Out
- 2- Arm Roll-In
- 3- Swing Right
- 4- Swing Left
- 5- Boom Lower
- 6- Boom Raise
- 7- Bucket Roll-In
- 8- Bucket Roll-Out



MDAA-01-288



M104-05-001




M104-05-002

## OPERATING THE MACHINE

### Pilot Control Shut-Off Lever

Pilot control shut-off lever (1) functions to prevent misoperation of the machine if control levers and pedals are accidentally moved when leaving the operator's seat or when entering the cab.

**WARNING:** Always pull pilot control shut-off lever (1) into the full LOCK position. Unless pilot control shut-off lever (1) is fully moved to the LOCK position, the control levers are not locked, possibly creating a hazardous situation. When leaving the machine, always stop the engine. Pull pilot control shut-off lever (1) up to the LOCK position. Always check to be sure that pilot control shut-off lever (1) is pulled up to the LOCK position before transporting the machine or leaving the machine at the end of a shift.



LOCK position

MDAA-01-295

#### Before Leaving the Machine


1. Park the machine on a firm, level surface. Lower the bucket to the ground. Return all control levers to neutral. Properly shut down the engine.
2. Pull pilot control shut-off lever (1) up into the full LOCK position.

#### Before Starting Operation:

Confirm that pilot control shut-off lever (1) is pulled up to the LOCK position before starting the engine. The engine will not start if the pilot control shut-off lever (1) is in any other position than LOCK.

Slowly push down pilot control shut-off lever (1) to the UNLOCK position before starting operation.

Confirm that all control levers and pedals are in neutral and that no part of the machine is in motion.



UNLOCK Position

MDAA-01-296

**WARNING:** If any part of the machine (any actuator) moves when pilot control shut-off lever (1) is lowered to the UNLOCK position despite when all controls are in neutral, the machine is malfunctioning. Immediately pull pilot control shut-off lever (1) back to the LOCK position, and stop the engine. See your authorized dealer.

## OPERATING THE MACHINE

### Warming-Up Operation

In cold weather, warm up the machine until coolant and hydraulic oil temperature increases to the appropriate operating temperature.

#### IMPORTANT:


- The appropriate hydraulic oil operating temperature on this machine is 50 to 80 °C. Hydraulic components may be seriously damaged if the machine is operated with low temperature hydraulic oil. If warming up the machine by relieving the hydraulic system, continuously relieve the relief valve for 10 to 15 seconds then pause for 5 to 10 seconds.
- When the hydraulic oil temperature is 5 °C or lower, the pump torque is restricted to protect the engine.

1. Even after engine starts, leave engine control dial (1) in the slow idle position.  
(Do not operate the machine until the needle of coolant temperature gauge (2) starts swinging.)
2. After the needle of coolant temperature gauge (2) starts swinging, turn engine control dial (1) to approx. Medium position.
3. Operate the boom, arm and bucket cylinders slowly to each stroke end several times. If the machine is equipped with various attachments, operate the attachment function slowly to allow hydraulic oil to circulate through the system.
4. Operate the travel and swing functions slowly to allow hydraulic oil to circulate through the systems.
5. Warming-up operation ends after the above operation is completed.


#### NOTE:

- The engine speed will be kept to slow idle speed just after the engine starts. When engine speed control indicator (7) is displayed, slow idle speed will be maintained. When the coolant temperature or hydraulic oil temperature is low, the time will be longer. The engine speed will be kept to slow idle speed even if engine control dial (1) is not set in the slow idle position.
- The warm-up system automatically operates after keeping slow idle speed, and the engine speed will temporarily increase even if engine control dial (1) is in the slow idle position.


**CAUTION:** Do not attempt to operate the machine when engine speed control indicator (7) is lit. The engine speed may change after the slow idle period and operation speed of work device may suddenly increase, which may cause a serious accident.




M1P1-01-068



MDC1-01-001



M1P1-05-003




MDC1-01-355

## OPERATING THE MACHINE

### Engine Speed Control

Increase and decrease the engine speed using engine control dial (1) located on the switch panel, as illustrated.


- Turn engine control dial (1) clockwise to increase the engine speed. Turn engine control dial (1) counterclockwise to decrease the engine speed.
- Note that the auto-idle function will be deactivated if engine control dial (1) is operated while the engine is running at the auto-idle setting.
- Before stopping the engine, always turn engine control dial (1) counterclockwise to the stop (to the slow idle setting). Run the engine five minutes to cool the engine. Then, turn the key switch to OFF position to stop the engine.



MDCD-01-026


#### NOTE:

- The engine speed will be kept to slow idle speed just after the engine starts. When engine speed control indicator (7) is displayed, slow idle speed will be maintained. When the coolant temperature or hydraulic oil temperature is low, the time will be longer. The engine speed will be kept to slow idle speed even if engine control dial (1) is not set in the slow idle position.
- The warm-up system automatically operates after keeping slow idle speed, and the engine speed will temporarily increase even if engine control dial (1) is set in the slow idle position.



M1P1-01-068

**CAUTION:** Do not attempt to operate the machine when engine speed control indicator (7) is lit. The engine speed may change after the slow idle period and operation speed of the work device may suddenly increase, which may cause a serious accident.



MDC1-01-355

# OPERATING THE MACHINE

## Auto-Idle

### Auto-Idle Function

When auto-idle switch (3) is turned to the A/I ON position, approximately 4 seconds after all control levers are returned to neutral, the engine speed decreases to the auto-idle setting to save fuel consumption.

The engine speed will immediately increase to the speed set by engine control dial (2) when any control lever is operated.


### IMPORTANT:

- Always check if auto-idle indicator (1) is turned ON or OFF before starting operation. If indicator (1) is ON, the auto-idle function will be activated.
- Always be aware of the setting of engine control dial (2) when auto-idle switch (3) is turned to the A/I ON position. If the engine speed is set high with engine control dial (2), and the operator is not aware of the high engine speed setting, the engine speed will unexpectedly increase when any control lever is operated, causing the machine to move unexpectedly, possibly resulting in serious personal injury.


**WARNING:** Prevent the machine from moving unexpectedly. Be sure to turn auto-idle switch (3) to the A/I OFF position when unexpected machine movement is undesirable, especially when loading/unloading the machine for transportation.

### NOTE:

- Auto-idle control may not work completely until the end of the warm-up.
- The auto-idle control function does not operate when the aftertreatment device is regenerating



MDC1-01-314



MDCD-01-026

## OPERATING THE MACHINE


### Auto-Idle ON/OFF

Note that the auto-idle function can be turned ON or OFF by using auto-idle switch (3) only when the key switch is in ON position.


Always check if the auto-idle function is turned ON or OFF with auto-idle indicator (1).

Auto-Idle Indicator (1) ON : Auto-Idle Function ON  
Auto-Idle Indicator (1) OFF : Auto-Idle Function OFF

- When auto-idle switch (3) is turned OFF with auto-idle indicator (1) ON, indicator (1) will go OFF and the auto-idle system is deactivated.
- The auto-idle system is not deactivated even if the engine is stopped by turning the key switch with auto-idle switch (3) in the A/I ON position [indicator (1) ON]. When the engine is restarted, the auto-idle system remains activated, allowing auto-idle indicator (1) to flash for 5 seconds and stay ON later.



MDC1-01-314



MDCD-01-026

## OPERATING THE MACHINE

### Auto Shut-Down

**⚠ WARNING:** This function automatically stops the engine. Take extra care on the work and work environment when using this function.

When the auto shut-down function is turned ON, the engine automatically stops after the preset time at the state in which the pilot control shut-off lever is pulled. 30 seconds before the engine stop, monitor screen (2) displays "Engine Shut-Down Soon." message and indicator (1) starts flashing. Also the buzzer sounds. The buzzer sounds once at 30 seconds before, and continuously sounds from 15 seconds. The engine speed decreases to the idling speed, and then stops after 15 seconds. When the pilot control shut-off lever is pushed down before stopping the engine, the auto shut-down is disabled and the engine will not stop.


**IMPORTANT:** Check whether the status of auto shut-down indicator (1) is ON or OFF. If indicator (1) is ON, the auto shut-down function will be activated.

#### Operating Condition


- The engine is running.
- The pilot control shut-off lever is in the LOCK position.
- Coolant and hydraulic oil temperature are not high.
- The aftertreatment device is not in the process of manual regeneration.

#### IMPORTANT:

- When the engine is stopped by the auto shut-down function, turn the key switch to ACC or OFF once and then turn it to START to restart the engine. Turn the key switch OFF after auto shut-down when leaving the machine for long period of time. Do not leave the machine after auto shut-down. Failure to do so may discharge the batteries.
- When the key switch is turned to the OFF position while the auto shut-down function is ON, the setting will be reset. When required to keep the setting, consult your authorized dealer.



MDC1-01-146EN



MDC1-01-286

# OPERATING THE MACHINE


## IMPORTANT:

- Even if the auto shut-down function is ON, the engine will not stop during manual regeneration of the aftertreatment device.
- When the auto shut-down activates, the air conditioner will also stop.


## Setting the Auto Shut-Down Function

### Auto Shut-Down: On/Off


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Setting Menu (4).
3. Push selector knob (2) to display Setting Menu screen (5).
4. Rotate selector knob (2) to highlight Auto Shut-Down (6).




MDC1-01-001



MDCD-01-026



MDAA-01-114EN




MDC1-01-147EN




## OPERATING THE MACHINE


- Push selector knob (2) to display Auto Shut-Down screen (7).



MDCD-01-026

- Rotate selector knob (2) to highlight ON (8).
- Push selector knob (2) to turn the Auto Shut-Down function ON. Push selector knob (2) again to turn the auto shut-down function OFF.


 **NOTE:** When the function is ON, the mark "■" is displayed in green. When the function is OFF, the mark "■" is displayed in gray.




MDAA-01-148EN


### Setting Time of Auto Shut-Down

- On the Auto Shut-Down screen, rotate selector knob (2) to highlight Setting Time (9).
- Push selector knob (2). Rotate selector knob (2) to adjust the auto shut-down setting time.
- Push selector knob (2) to make the change.

 **NOTE:** 30 seconds before the engine stop, the monitor will display "Engine Shut-Down Soon." message (10).



MDAA-01-150EN



MDC1-01-146EN

## OPERATING THE MACHINE

### Aftertreatment Device Manual Regeneration

#### Manual Regeneration Procedure


When the manual regeneration is needed, screen (1) as shown on the right side will be displayed. When screen (1) is displayed, you need to perform the manual regeneration. Before starting the manual regeneration, be sure to check the following.

If the machine is equipped with a rear view camera, and the camera is enabled, screen (1) is displayed only when the pilot control shut-off lever is in LOCK position.


- No person is present around the machine
- Keep flammable materials away from the aftertreatment device.
- Fuel level alarm does not light.
- DEF/AdBlue® level alarm does not light.

1. Park the machine in a safe place. Lower the front attachment onto the ground.
2. Pull the pilot control shut-off lever to the LOCK position.
3. Set the engine control dial to slow idle.
4. Push aftertreatment device manual regeneration switch (2).
5. When pushing aftertreatment device manual regeneration switch (2), screen (3) as shown on the right side will be displayed and the manual regeneration starts. Bar graph on screen (3) indicates progress of the regeneration process.


**IMPORTANT: The manual regeneration does not start unless the pilot control shut-off lever is in the LOCK position and the engine control dial is in slow idle. When touching the pilot control shut-off lever or the engine control dial during manual regeneration, the regeneration process is aborted. When the process is aborted, start over again.**




MDC1-01-005



MDAA-01-330



MDAA-05-002



MDC1-01-006

## OPERATING THE MACHINE


6. When the manual regeneration is finished, "Regeneration Has Completed." message will be displayed. If "Regeneration Has Failed." message is displayed, start the manual regeneration process again.

### NOTE:


- *Regeneration process may fall in conditions other than those mentioned above (such as sensor malfunction or low ambient temperature).*
- *The engine sound may change and the engine speed may increase when the manual regeneration starts, this is not a malfunction.*
- *Regeneration time varies depending on the ambient temperature.*
- *White smoke may temporarily be generated from the tail pipe during the regeneration process, this is not a malfunction.*
- *Manual regeneration time is shorter directly after machine operation, and longer when engine temperature is low.*
- *Coolant temperature may increase during the manual regeneration.*

### IMPORTANT:

- **If regeneration must be interrupted, push the manual regeneration switch again. The message "Regeneration Has Failed." will be displayed on the monitor, but the machine becomes operable. In this case, manual regeneration should be performed again. Restart manual regeneration as soon as possible.**
- **Depending on the working and environmental conditions, there may be occasions when the effectiveness of the catalyst within the aftertreatment device decreases and replacement becomes necessary. If warm up is finished, ordinarily a manual regeneration will take around 15 to 30 minutes to complete. If the regeneration takes over 40 minutes, contact your nearest authorized dealer to arrange an inspection.**



MDC1-01-083EN



MDC1-01-084EN

## OPERATING THE MACHINE


---

### Work Mode

Select Work Mode in the main menu, and select the appropriate hydraulic circuit and pump flow rate for the front attachment at Work Mode screen.

When the engine is started, the digging mode is automatically set. The following 6 work modes can be selected from the Work Mode screen.

- Digging Mode
- Breaker 1 Mode
- Breaker 2 Mode
- Pulverizer 1 Mode
- Crusher 1 Mode
- Grapple 1 Mode















MDC1-01-001


## OPERATING THE MACHINE

The selected work mode is indicated by attachment mode indicator (2) on Basic Screen (1).

Select the work mode corresponding to the work in which the machine is engaged, referring to the table below.

	Work Mode	Description
	Digging Mode	Select this mode when using bucket.
	Breaker 1 to 5 Mode	Select this mode when using breaker.
	Pulverizer 1 to 5 Mode	Select this mode when using pulverizer.
	Crusher 1 to 5 Mode	Select this mode when using crusher.
	Vibrating Hammer 1 to 5 Mode	Select this mode when using vibrating hammer.
	Grapple 1 to 5 Mode	Select this mode when using grapple.
	Clamshell 1 to 5 Mode	Select this mode when using clamshell.
	Thumb 1 to 5 Mode	Select this mode when using thumb.
	Tilting Rotator 1 to 5 Mode	Select this mode when using tilting rotator.
	Tilting Bucket 1 to 5 Mode	Select this mode when using tilting bucket.
	Others 1 to 5 Mode	Select this mode when other than the above attachment is used.

 **NOTE:** 51 work modes shown above are designated as standard specifications. Up to 11 attachment modes other than digging mode can be designated. Consult your authorized dealer for adding or changing the designation of the attachment modes.




MDC1-01-001


# OPERATING THE MACHINE

## Attachment Selection


1. Push selector knob (2) while displaying Basic Screen (1) to display Main Menu screen (3).
2. Rotate selector knob (2) to highlight Work Mode (4).
3. Push selector knob (2) to display Work Mode screen (5).
4. Rotate selector knob (2) to highlight the Desired Front Attachment.  
(In the right example, "Bucket" (6) is highlighted.)
5. Push selector knob (2) to make the changes.




MDC1-01-001



MDCD-01-026



MDAA-01-100EN



MDAA-01-101EN


## OPERATING THE MACHINE

---

### Power Boost Switch

Power boost switch (4) is located on the top of the right control lever.

When power boost switch (4) is pushed, increased front attachment power will be supplied for about 8 seconds.



MDAA-01-292

# OPERATING THE MACHINE

## Power Mode

Three engine speed modes, ECO, PWR or H/P mode is selected by operating power mode switch (1).

### ECO (Economy) Mode

Operate the machine in this mode when performing normal work.

ECO is displayed on Power Mode Display (2).


### PWR (Power) Mode


Use PWR (Power) mode when extra horsepower is needed.

PWR is displayed on Power Mode Display (3).


### H/P (High Power) Mode

Use the H/P mode when extra fast speed and/or heavy duty work is needed.


 **NOTE:** ECO mode is set automatically when starting the engine. Set PWR mode if necessary.



MDCD-01-027



MDC1-01-001



MDC1-01-353




## OPERATING THE MACHINE

---

### Operating Backhoe

- Use the appropriate arm and bucket for the work. (Refer to the "Bucket Types and Applications" in the Specifications chapter.)
- Pull the bucket toward the machine using the arm as the main digging force.
- When soil sticks to the bucket, remove it by moving the arm and/or bucket rapidly back and forth.
- Place the bucket teeth on the ground with the bottom of the bucket at a 45 degree angle to the ground.
- When trenching a straight line, position the tracks parallel to the trench. After digging to the desired depth, move the machine as required to continue the trench.
- When operating the arm, avoid bottoming the cylinder to prevent cylinder damage.



M107-05-037

#### IMPORTANT:

- **When digging at an angle, avoid striking the tracks with the bucket teeth.**
- **Lower the boom smoothly. Avoid stopping suddenly as this may impact the machine.**
- **When digging a deep excavation, avoid striking the boom or bucket cylinder hoses against the ground.**
- **When operating the machine with the blade (if equipped) positioned towards the front, the bucket teeth may come in contact with the blade.**

## OPERATING THE MACHINE

### Shovel

Backhoe operation digs the ground using the bucket in a roll-in motion. Face shovel operation digs the ground using the arm cylinder in a scraping motion.

**⚠ WARNING:** Take care not to hit the cab when rolling in the arm with a reversed-installed bucket.


**IMPORTANT:** If a bucket hook is mounted, take care not to hit the arm with the hook when rolling in the bucket.

- For face shovel operation, dig the ground using the arm cylinder in a scraping motion.
- When underground water is expected, make a slope angle of 2 to 3 ° to drain this water as shown.

**📌 NOTE:** Because of the hydraulic cylinder structure, digging force of the face shovel operation is smaller than for backhoe operation.



MZX5-05-003



M104-05-020

## OPERATING THE MACHINE


---

### Grading Operation

Operate the boom, arm, and the bucket in such a way so that the bucket teeth move horizontally, constantly keeping them perpendicular to the ground at the grading operation.

**IMPORTANT: Do not pull or push dirt with the bucket when traveling. Excess force will be applied on each part, and the machine may be damaged.**

1. Operate arm roll-in function while slowly raising the boom. Once the arm moves past the vertical position, slowly lower the boom to allow the bucket to maintain a smooth surface.
2. Reverse the directions in step 1 to perform arm roll-out operation.
3. Perform slope finishing work using the same procedure described in steps 1 and 2.



M104-05-017

## OPERATING THE MACHINE

---

### Do Not Strike the Ground with Bucket Teeth

**⚠ WARNING:** Forcibly striking the bucket teeth on the ground may result in personal injury from flying debris. It will also shorten the service life of each part on the front attachment.

If the bucket teeth are forcibly struck on the ground, it shortens the service life of the front attachment parts (especially the bucket).

When digging a hard gravel layer, use the upwards digging force of the bucket. Operate the boom, arm and the bucket simultaneously so that the bucket teeth efficiently bite into the ground.

Flying debris may result in personal injury.

### Avoid Hammer Work

**⚠ WARNING:** As the bucket body has a curved surface, hammer work or piling work is very dangerous. Doing so may damage the bucket and front attachment.

Do not attempt to use the bucket for hammer work and piling work.

Doing so may damage the bucket and front attachment, causing personal injury.





MZX5-05-004

## OPERATING THE MACHINE

---

### Avoid Abusive Operation


Do not attempt to add additional digging force by using travel, raising the rear of the machine to use the machine's weight.



MZX5-05-005

### Never Move an Object Sideways with the Bucket

For example, do not swing the bucket to level material or do not strike objects sideways with the bucket. Doing so may damage the front attachment and the swing system.



MZX5-05-006

## OPERATING THE MACHINE

---

### **Do Not Use Wide Track Shoes on Rough Ground**

Never use wide track shoes on rough ground such as rocks, sand or gravel. Wide track shoes are designed for soft ground.

Failure to do so may result in shoe bending and/or shoe bolt loosening, and may damage other undercarriage components such as track link and rollers.

(Refer to the "Shoe Types and Applications" in the Specifications chapter.)

## OPERATING THE MACHINE

### Shackle Hole Usage

A shackle hole is provided on the track frame to tow light weight objects as specified below.


**IMPORTANT: Be sure to conform to the restrictions and precautions stated below when towing a light weight object using the shackle hole provided on the track frame. The track frame and/or the shackle hole may be damaged otherwise.**

- The maximum drawbar pull.

Model	Maximum Drawbar Pull
ZX130-6N	44100 N (4500 kgf) or less
ZX160LC-6N, 180LC-6N	53900 N (5500 kgf) or less
ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N, 350LC-6N, 380LC-6N	73600 N (7500 kgf) or less

- Be sure to use a shackle.
- Keep the tow line horizontal, straight, and parallel to the tracks.

Select the slow travel mode. Slowly drive the machine when towing.



M104-05-011

## OPERATING THE MACHINE

---

### Pilot Accumulator Functions

Pilot accumulator (1) is a pressure storage reservoir of the control circuit which supplies pressure and enables operation of the control circuit even after stopping the engine. The front attachment can be lowered using the control lever and the weight of the attachment itself, and pressure in the hydraulic circuit can be released after stopping the engine.


#### Pressure Release Procedure of Hydraulic Circuit

1. Set the machine in the parking position.
2. Pull the pilot control shut-off lever to the LOCK position.

Perform items from 3 to 5 within 15 seconds.

As the pressure in pilot accumulator (1) gradually decreases after stopping the engine, pressure in the hydraulic circuit can be released for few seconds after stopping the engine.

3. Stop the engine. Turn the key switch ON.
4. Push the pilot control shut-off lever to the UNLOCK position.
5. Move the control levers and attachment pedals forward and rearward or left and right to release pressure from the hydraulic circuit.
6. Pull the pilot control shut-off lever to the LOCK position and turn the key switch OFF.



MDAA-05-009



## OPERATING THE MACHINE

### How to Lower Boom in Case of Emergency and When Engine Stops

(Without hose-rupture safety valve)

**WARNING:** Prevent personal injury. Confirm that no one is under the front attachment before starting the procedure below.

In case the engine suddenly stops and the engine cannot be restarted, lower the boom by following the procedure below.

**IMPORTANT:** Never loosen screw (2) more than 2 turns. Screw (2) may come off.

1. Loosen lock nut (1) in the emergency valve on the right. Loosen screw (2) one half of a turn. The boom lowering speed can be partly adjusted by loosening screw (2) further.

**IMPORTANT:** Excessive leakage may result if screw (2) and lock nut (1) are tightened insufficiently. Be sure to retighten screw (2) and lock nut (1) to specifications.


2. After the boom is lowered, tighten screw (2) and tighten lock nut (1) to the specifications below.

Locknut (1)

Tightening Torque: 13 N·m (1.3 kgf·m)


Screw (2)

Tightening Torque: 7 N·m (0.7 kgf·m)




ZX130-6N

MDAA-05-008




ZX160LC-6N, 180LC-6N

T1V1-03-03-073



ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N,  
350LC-6N, 380LC-6N

MDAA-05-003



T1V1-03-03-038

## OPERATING THE MACHINE

---

### Precautions for After Operations

- After finishing the day's operation, drive the machine to a firm, level ground where no possibility of falling stones, ground collapse, or floods are present.  
(Refer to the sections "PARKING THE MACHINE" in the DRIVING THE MACHINE chapter.)
- Fully refill the fuel in the fuel tank.
- Clean the machine.

## TRANSPORTING

---

### Transporting by Road

When transporting the machine on public roads, be sure to first understand and follow all local regulations.

- When transporting the machine using a trailer, check the width, height, length and weight of the trailer with the machine loaded. Note that transporting weight and dimensions may vary depending on the type of shoe or front attachments installed.
- Investigate conditions on the route to be traveled in advance, such as dimensional limits, weight limits, and traffic regulations.

In some cases it may be necessary to obtain permission from the local authority concerned, or to disassemble the machine to bring it within local regulation for dimensional or weight limits.

Notify your authorized dealer that you are transporting the machine.



M1V1-06-001

## TRANSPORTING

---

### Loading/Unloading on a Trailer

Always load and unload the machine on a firm, level surface.

**⚠ WARNING:** Be sure to use a loading dock or a ramp for loading/unloading. Never use the front attachment functions when loading or unloading the machine.

#### Ramp/Loading Dock:

1. Before loading, thoroughly clean the ramps, loading dock and flatbed. Dirty ramps, loading docks, and flatbeds with oil, mud, or ice on them are slippery and dangerous.
2. Place blocks against the truck and trailer wheels while using a ramp or loading dock.
3. Ramps must be sufficient in width, length, and strength. Be sure that the incline of the ramp is less than 15 degrees.
4. Loading docks must be sufficient in width and strength to support the machine and have an incline of less than 15 degrees.
5. When loading a machine equipped with a pad crawler or rubber pad shoes, take sufficient care not to allow the machine to slip since the surface of the rubber pad shoe is flat.

Only load the machine after removing soil or clay adhered to the machine.

6. When transporting a machine equipped with a blade, take care not to hit the blade.

## TRANSPORTING

### Loading/Unloading

#### **⚠ WARNING:**


- Always turn the auto-idle switch OFF when loading or unloading the machine. In auto-idle mode, speed may automatically increase.
- Always select slow speed mode with the travel mode switch.
- Never steer while driving up or down a ramp, it is extremely dangerous and may cause the machine to turnover. NEVER attempt to change direction when positioned on the ramp. If repositioning is necessary, first move back to the ground or flatbed, change the direction of travel, and begin to drive again.
- At the point where the ramp meets the level surface there is a sudden change of angle. Take care when traveling over this point, as balance may be lost.
- Extreme care must be taken when swinging the upper structure when the machine is on the trailer flatbed. If the front attachment is fitted, swing slowly with the arm fully rolled-in underneath the boom, being careful not to lose the balance of the machine.

### Loading


#### **⚠ CAUTION:** In cold weather, be sure to warm up the machine before loading or unloading it.

If the front attachment is fitted, load with the front attachment faced towards the front, if the front attachment is not fitted, reverse onto the trailer.

1. Load the machine so that the centerline of the machine aligns with the centerline of the trailer flatbed.
2. Drive the machine onto the ramp slowly.



M1G6-06-002




M107-06-018

## TRANSPORTING

---

### 3. When the front attachment is fitted

- 3.1 Determine a position for the bucket in line with the trailer. Adjust the angle of the boom and the arm at 90 to 110°.
  - 3.2 Lower the bucket onto to the deck of the trailer before the machine passes over the end of the ramp for support.
  - 3.3 Lift the bucket slightly off the deck of the trailer after the machine has moved to the designated space. With the arm lifted inwards, slowly swing the upper structure place around 180°.
  - 3.4 Rest the front attachment on supports such as wooden blocks placed on the trailer flatbed. Also lower the blade onto the deck at this time (if fitted).
4. Stop the engine. Remove the key from the key switch.
  5. Pull the pilot control shut-off lever to the LOCK position.
  6. Close cab windows, roof vent and door, and cover the exhaust opening, to prevent entry of wind and water. Place a cover over the exhaust outlet. Lock all doors, covers and caps if they have a lock.
  7. Store all mirrors and the radio antenna correctly.



M107-06-012



M107-06-013

## TRANSPORTING

### Fastening Machine for Transporting

**WARNING:** Fasten the machine frame to the deck securely with chains and cables. While traveling, loads may shake around, move forward or backward or to the sides.

1. Place cog stoppers or blocks in front of and behind the tracks to help secure the machine.
2. Fasten each corner of the machine and front attachment to the trailer with appropriate strength of chains or cables.



M1V1-06-001

### Unloading


**WARNING:** At the point where the ramp meets the level surface there is a sudden change of angle. Take care when traveling over it.

**IMPORTANT:** Make sure that the angle of the boom and the arm is kept between 90 to 110 ° when unloading the machine.

**Damage to the machine is possible if the arm is kept in a suspended state during unloading.**

1. Travel extremely slowly with the bucket on the ground and the angle of the arm and the boom kept at between 90 to 110 ° when moving from the edge of the trailer onto the ramp.

**IMPORTANT:** When driving the machine over the ramp, do not allow the machine to hit the ground with the arm too hard. Possible damage to the hydraulic cylinders may result.




M107-06-014

## TRANSPORTING

---

2. The bucket must be on the ground before the machine begins to tip forward.
3. As the machine moves forward, raise the boom and extend the arm until the machine is completely off the ramp.





## TRANSPORTING

---

### Lifting Machine

 **WARNING:**

- Use lifting cables and other lifting tools that are sufficient strong, and free from any damage and/or other defect.
- Consult your authorized dealer for correct lifting procedures, and the size and types of lifting cable and tools.
- Pull the pilot control shut-off lever to the LOCK position so that the machine does not accidentally move while being lifted.
- Incorrect lifting procedure and/or incorrect wire rope attachment will cause the machine to move (shift) while being lifted, resulting in machine damage and/or personal injury.
- Do not lift the machine quickly. Excessive load will be applied to the lifting wire ropes and/or lifting tools, possibly causing them to break.
- Do not allow anyone close to, or underneath the lifted machine.
- The indicated gravity center is for the standard specification machine. The center of gravity will vary depending on the kinds of attachments and/or optional equipment installed and their positioning. Take care not to lose the balance of the machine while lifting.

## TRANSPORTING


---

### Lifting

1. Fully extend the arm and bucket cylinders. Lower the boom until the bucket comes in contact with the ground.
2. Pull the pilot control shut-off lever to the LOCK position.
3. Stop the engine. Remove the key from the key switch.
4. Close and lock all doors and covers.
5. Use wire ropes and support bar of sufficient length so that they do not come in contact with the machine while lifting.

Wrap some protectors around wire ropes and/or support bar as required to prevent the machine from being damaged.

6. Set a crane in an appropriate position.
7. Thread the wire rope through and under both sides of the track frames as illustrated. Attach the wire ropes to the crane.



M1G6-06-001

## MAINTENANCE

---

### Correct Maintenance and Inspection Procedures

Learn how to service your machine correctly. Follow the correct maintenance and inspection procedures shown in this manual.

Inspect machine daily before starting.

- Check controls and instruments.
- Level, leakage and contamination of coolant, fuel, DEF/AdBlue® and hydraulic oil
- Check for leaks, kinked, frayed or damaged hoses and lines.
- Walk around machine checking general appearance, noise, heat, etc.
- Check for loose or missing parts.

If there is any problem with your machine, repair it before operating or contact your authorized dealer.

#### IMPORTANT:

- **Use only specified fuel, DEF/AdBlue®, lubricants and coolant.**
- **Be sure to use only genuine Hitachi parts. Failure to do so may result in serious injury or death and/or machine breakdown.**
- **Failure to use recommended fuel, lubricants, and genuine Hitachi parts will result in loss of Hitachi product warranty.**
- **Never adjust engine governor or hydraulic system relief valve.**
- **Protect electrical parts from water and steam.**
- **Never disassemble electrical components such as main controller, sensors, etc.**
- **Never adjust parts of engine fuel system or hydraulic equipment.**
- **Using bad quality fuel, drainage agent, fuel additives, gasoline, kerosene or alcohol refueled or mixed with specified fuel may deteriorate performance of fuel filters and cause sliding problem at lubricated contacts in the injector. It also affects the engine and aftertreatment device parts, leading to malfunction.**
- **Using bad quality DEF/AdBlue® may deteriorate performance of the engine and affect the aftertreatment device, leading to malfunction. Using improper density DEF/AdBlue® may derate the engine power.**
- **Use Hitachi genuine high performance filter.**



SA-005

## MAINTENANCE

---

- **Body Information Controller**

This machine provides a body information controller that stores machine operation information for preventive maintenance.

When maintaining the machine, our authorized service man may download the stored information.

Consult with your authorized dealer for detailed function of this device.

- **Communication Terminal Operation**

It is not necessary to check or operate the communication terminal however if any abnormality is found, consult your authorized dealer.


Before installing any covering attachment such as a head guard, consult your authorized dealer.

Never spray water on the communication terminal and the wirings.

- **Inquire to your local environmental or recycling center or your authorized dealer, for the proper way to recycle or dispose of oil, fuel, coolant, filters, batteries, DEF/AdBlue® and other waste.**

# MAINTENANCE

## Layout



MDC1-07-060

- |                      |                           |   |                               |
|----------------------|---------------------------|---|-------------------------------|
| 1- Tooth             | 13- Swing Bearing         | 25- Radiator, Oil Cooler, Inter<br>Cooler | 36- Track Frame               |
| 2- Side Cutter       | 14- Swing Reduction Gear  | 26- Air Conditioner Condenser             | 37- Track Adjuster            |
| 3- Bucket            | 15- Fuel Tank             | 27- Battery                               | 38- Front Idler               |
| 4- Link A            | 16- Control Valve         | 28- Track Link                            | 39- Air Cleaner               |
| 5- Link B            | 17- Hydraulic Oil Tank    | 29- Shoe                                  | 40- Control Lever             |
| 6- Bucket Cylinder   | 18- Aftertreatment Device | 30- Travel Device                         | 41- Battery Disconnect Switch |
| 7- Arm               | 19- Fuel Filter           | 31- Washer Tank                           | 42- Cab                       |
| 8- Arm Cylinder      | 20- Engine Oil Filter     | 32- Lower Roller                          | 43- Boom Cylinder             |
| 9- Boom              | 21- Pilot Filter          | 33- Upper Roller                          | 44- Work Light                |
| 10- Center Joint     | 22- Pump                  | 34- Fuel Cooler                           | 45- DEF/AdBlue® Supply Module |
| 11- Tools            | 23- Engine                | 35- Expansion Tank                        |                               |
| 12- DEF/AdBlue® Tank | 24- Counterweight         |   |                               |

## MAINTENANCE

---

### **Check the Hour Meter Regularly**

Refer to the List of Check and Maintenance for information about lubricants, check and adjustment intervals. The maintenance guide table is affixed in the utility space. Refer to the next page.

This manual recommends grouping the intervals into three categories as follows:

- Daily Check : To be conducted daily before operation
- Monthly check : To be regularly conducted once per month
- Annual check : To be regularly conducted once per year












Check and maintenance intervals shown in this manual are those for the machines to be operated under normal conditions. In case the machine is operated under more severe conditions, shorten the intervals.

## MAINTENANCE

### Maintenance Guide Table


The maintenance guide table is affixed in the utility space. Lubricate and/or service the parts at the intervals as instructed in the table so that all necessary maintenance can be performed regularly.

- **Symbol Marks**  
The following marks are used in the maintenance guide table.

	Grease (Front Joint Pin, Swing Bearing, Swing Internal Gear)		Hydraulic Oil Filters (Pilot Filter, Full-Flow Filter, Suction Filter)
	Gear Oil (Pump Transmission, Travel Reduction Gear, Swing Reduction Gear)		Air Cleaner Element
	Engine Oil		Coolant (Long-Life Coolant)
	Engine Oil Filter		Fuel Filter (Fuel Main Filter, Pre-Filter)
	Hydraulic Oil		DEF/AdBlue® Supply Module Main Filter
	Oil Separator Element		

# MAINTENANCE

• Maintenance Guide Table



MDC1-07-100

	Item	Page		Item	Page
1	Engine Oil	7-34	10	Oil Separator Element	7-37
2	Coolant (Long-Life Coolant)	7-79	11	Hydraulic Oil Filter (Air Breather)	7-53
3	Grease	7-30	12	Engine Oil Filter	7-34
4	Grease (Top of the Arm Every 50 hours)	7-28	13	Gear Oil (Pump Transmission) (Except ZX130-6N)	7-38
5	Grease	7-31	14	Fuel Filter (Main/Pre)	7-64
6	Hydraulic Oil	7-47	15	DEF/AdBlue® Supply Module Main Filter	7-144
7	Gear Oil (Travel Reduction Gear)	7-40	16	Gear Oil (Swing Reduction Gear)	7-39
8	Hydraulic Oil Filter (Suction)	7-50	17	Air Cleaner Element	7-71
9	Hydraulic Oil Filter (Full-Flow/Pilot)	7-51			



## MAINTENANCE

### Preparations for Inspection and Maintenance

Except in special cases, park the machine by following the procedure before servicing the machine.


1. Park the machine on a firm, level surface.
2. Lower the bucket to the ground.
3. Turn the auto-idle switch OFF.
4. Turn engine control dial to the slow idle position and run the engine for 5 minutes to cool the engine.
5. Turn the key switch OFF to stop the engine. Remove the key. Be sure to place pilot control shut-off lever (1) to the LOCK position.
6. After putting a tag (2) for "Under Serving" on the easy-to-see cab door or control lever, begin the work.

**⚠ WARNING:** Never attempt to maintain the machine when the engine is running in order to prevent the accident. If maintenance work while engine running is unavoidable, strictly comply with the following items.


- One person should take the operator's seat to be ready to stop the engine any time while communicating with other workers.
- When working around moving parts is unavoidable, pay special attention to ensure that hands, feet, and clothing do not become entangled.
- If parts or tools are dropped or inserted into the fan or the belt, they may fly off or be cut off. Do not drop or insert parts and tools into the moving parts.
- Move pilot control shut-off lever (1) to LOCK position so that the machine will not move.
- Never touch the control levers and pedals. If operating the control levers or pedals is unavoidable, signal co-workers to evacuate to safer place.




M104-07-021



MDAA-07-028



SA-2294



SA-026


# MAINTENANCE

## Hood and Access Covers

ZX130-6N, 160LC-6N, 180LC-6N


### ⚠ WARNING:

- Do not keep the hood and access covers open when the machine is parked on a slope, or while the wind is blowing hard. The hood or access covers may close accidentally, possibly resulting in personal injury.
- When opening or closing the hood and access covers, take extra care not to catch fingers between the base machine and the hood or access covers.
- Holding the handle on the access cover, raise the cover until the cover is secured with catch (1).
- After opening the right and/or left access cover, be sure to insert rod (2) into cover lock hole (3) to hold the cover.
- When opening the front right cover, open the rear right cover first. Then, pull to open the front right cover as illustrated. (only ZX160LC-6N, 180LC-6N)




Engine Cover  
ZX130-6N

MDC1-07-065




Engine Cover  
ZX160LC-6N, 180LC-6N

MDC1-07-066




Right Cover  
ZX130-6N

MDC1-07-067




Rear Right Cover  
ZX160LC-6N, 180LC-6N

MDC1-07-068



Left Cover

MDAA-07-064



Front Right Left Cover  
ZX160LC-6N, 180LC-6N


MDC1-07-086

## MAINTENANCE

ZX210-6N, 210LC-6N, 250LC-6N


**⚠ WARNING:**

- Do not keep the hood and access covers open when the machine is parked on a slope, or while the wind is blowing hard. The hood or access covers may close accidentally, possibly resulting in personal injury.
  - When opening or closing the hood and access covers, take extra care not to catch fingers between the base machine and the hood or access covers.
- 
- Holding the handle on the access cover, raise the cover until the cover is secured with catch (1).
  - After opening the right and/or left access cover, be sure to insert rod (3) into cover lock hole (4) to hold the cover.
  - When opening the rear left cover, open the front left cover first. Then, pull to open the rear left cover as illustrated.
  - When opening the front right cover, open the rear right cover first. Then, pull to open the front right cover as illustrated.
  - Do not attempt to start the engine when fan guard (2) is open.




Engine Cover

MDC1-07-021




Rear Right Cover

MDC1-07-001




Front Right Cover

MDC1-07-002



Front Left Cover

MDAA-07-019



Rear Left Cover


MDAA-07-020

## MAINTENANCE

ZX300LC-6N, 350LC-6N, 380LC-6N


### WARNING:

- Do not keep the hood and access covers open when the machine is parked on a slope, or while the wind is blowing hard. The hood or access covers may close accidentally, possibly resulting in personal injury.
  - When opening or closing the hood and access covers, take extra care not to catch fingers between the base machine and the hood or access covers.
- 
- Holding the handle on the access cover, raise the cover until the cover is secured with catch (1).
  - After opening the right and/or left access cover, be sure to insert rod (2) into cover lock hole (3) to hold the cover.
  - When opening the front left cover, open the rear left cover first. Then, pull to open the front left cover as illustrated.
  - When opening the front right cover, open the rear right cover first. Then, pull to open the front right cover as illustrated.




Engine Cover

MDC1-07-022




Rear Right Cover

MDC1-07-003




Front Right Cover

MDC1-07-004



Rear Left Cover

MDAA-07-032



Front Left Cover

MDAA-07-034

## MAINTENANCE

### Maintenance Guide

#### A. Greasing

	Parts	Quantity	Interval (hours)							Page	
			8	50	100	250	500	1000	2000		
1.	Front Joint Pins	Bucket and Link Pins	9	★	★★						7-28
		Others	11	★							7-28
2.	Swing Bearing	2									7-30
3.	Swing Internal Gear	1						★★★			7-31

★ : Add grease daily during first 50 hours of operation.

In case excavations are performed in water, grease the pin after operation is complete.

Shorten greasing intervals when the machine is operated under severe conditions or when the machine is continuously operated for a long period of time.

★★ : Only top of the arm 50 hours.

★★★ : Check and add grease if necessary.

#### IMPORTANT:

- Grease bucket and link pivots every day until break-in operation (50 hours) is complete.
- When a bucket which does not have clearance adjustment mechanism such as slope-finishing bucket or V-type bucket, or a genuine Hitachi hoe bucket before EX-5 model, or an attachment other than genuine Hitachi bucket is used, grease two pins every 250 hours.

#### B. Engine

	Parts		Quantity	Interval (hours)							Page	
				8	50	100	250	500	1000	2000		
1.	Engine Oil	Check Oil Level	1								7-32	
2.	Engine Oil	Change	ZX130-6N, 160LC-6N, 180LC-6N	17 L (4.5 US gal)								7-34
			ZX210-6N, 210LC-6N	23 L (6.1 US gal)								
			ZX250LC-6N	29 L (7.7 US gal)								
			ZX300LC-6N, 350 LC-6N, 380LC-6N	48 L (12.7 US gal)								
3.	Engine Oil Filter	Replace	1								7-34	
4.	Check and Clean Around the Engine		–	As required							7-34	
5.	Replace Oil Separator Element (ZX130-6N, 160LC-6N, 180LC-6N)		1								7-37	

## MAINTENANCE

### C. Transmission

Parts		Quantity	Interval (hours)							Page		
			8	50	100	250	500	1000	2000			
1.	Pump Transmission	Check Oil Level	1								7-38	
		Change	ZX160LC-6N, 180LC-6N, 210-6N, 210LC-6N, 250LC-6N	1.0 L (1.1 US qt)								7-38
			ZX300LC-6N, 350LC-6N, 380LC-6N	1.4 L (1.5 US qt)								
		Air Breather Cleaning	1									7-38
2.	Swing Reduction Gear	Check Oil Level	1								7-39	
		Change	ZX130-6N	3.2 L (3.4 US qt)								7-39
			ZX160LC-6N, 180LC-6N	6.9 L (1.8 US gal)								
			ZX210-6N, 210LC-6N	6.2 L (1.6 US gal)								
			ZX250LC-6N	9.1 L (2.4 US gal)								
			ZX300LC-6N	11.7 L (3.1 US gal)								
ZX350LC-6N, 380LC-6N	17.0 L (4.5 US gal)											
3.	Travel Reduction Gear	Check Oil Level	2								7-40	
		Change	ZX130LC-6N	4.2 Lx2 (1.1 US galx2)								7-41
			ZX160LC-6N, 180LC-6N, 210-6N, 210LC-6N	6.8 Lx2 (1.8 US galx2)								
			ZX250LC-6N	7.8 Lx2 (2.1 US galx2)								
			ZX300LC-6N, 350LC-6N, 380LC-6N	9.2 Lx2 (2.4 US galx2)								

## MAINTENANCE

### D. Hydraulic System

Parts		Quantity	Interval (hours)										Page		
			8	50	100	250	500	1000	1500	2000	2500	5000			
1.	Check Hydraulic Oil Level	1													7-46
2.	Change Hydraulic Oil	ZX130-6N	130 L (34.3 US gal)												7-47
		ZX160LC-6N, 180LC-6N	190 L (50.2 US gal)												
		ZX210-6N, 210LC-6N	200 L (52.8 US gal)									★		★	
		ZX250LC-6N, 300LC-6N	243 L (64.2 US gal)												
		ZX350LC-6N, 380LC-6N	298 L (78.7 US gal)												
3.	Suction Filter Cleaning	1	Each time when hydraulic oil is changed										7-50		
4.	Replace full-flow filter	1						★							7-51
5.	Replace Pilot Oil Filter	1													7-52
6.	Replace Air Breather Element	1													7-53
7.	Check Hoses and Lines	for leaks, loose													7-53
		for cracks, bend, etc.	–												7-54

★ : Changing interval differs according to the brand of hydraulic oil used, kind of filter element or average attachment operating availability.

Refer to the "changing intervals of hydraulic oil and full flow filter element". See recommended oil chart.

### E. Fuel System

Parts		Quantity	Interval (hours)							Page				
			8	50	100	250	500	1000	2000					
1.	Drain Fuel Tank Sump	1											7-60	
2.	Drain Fuel Pre-Filter	1											7-61	
3.	Replace Fuel Main Filter Element	1	(or when indicator lit)									7-64		
4.	Replace Fuel Pre-Filter Element	1	(or when indicator lit)									7-66		
5.	Replace Fuel Solenoid Pump Filter Element	Type A	1										7-68	
		Type B		No maintenance										
6.	Check Fuel Hoses	for leaks, cracks	–											7-70
		for cracks, bend, etc.	–											7-70

### F. Air Cleaner

Parts		Quantity	Interval (hours)						Page			
			8	50	100	250	500	1000		2000		
1.	Air Cleaner Outer Element	Clean	1	(or when indicator lit)								7-71
		Replace	1	After cleaning 6 times or 1 year								7-71
2.	Air Cleaner Inner Element	Replace	1	When outer element is replaced								7-73

## MAINTENANCE

### G. Cooling System

Parts		Quantity	Interval (hours)						Page	
			8	50	100	250	500	1000		2000
1.	Check Coolant Level	1								7-75
2.	Check and Adjust Fan Belt Tension	1		★★						7-77
3.	Change Coolant	ZX130-6N	21 L (5.5 US gal)	Twice a year*						7-79
		ZX160LC-6N, 180LC-6N	24 L (6.3 US gal)							
		ZX210-6N, 210LC-6N, 250LC-6N	28 L (7.4 US gal)							
		ZX300LC-6N	41 L (10.8 US gal)							
		ZX350LC-6N, 380LC-6N	40 L (10.6 US gal)							
4.	Clean Radiator, Oil Cooler and Inter Cooler Core	Outside	1					★		7-81
		Inside	1	Once a year						7-81
5.	Clean Oil Cooler, Radiator and Inter Cooler Front Screen	1					★			7-83
6.	Clean Air Conditioner Condenser	1					★			7-83
7.	Clean Fuel Oil Cooler	1					★			7-83
8.	Drain Intercooler	1	★★★							7-84

★: Shorten the maintenance interval when the machine is operated in dusty areas.

★★: Maintenance required only during first time check.

★★★: If there is a risk of freezing, remove condensate after operating the machine. (only ZX130-6N)

\*: When genuine Hitachi Long-Life Coolant is used, change every two years or 4000 operating hours, whichever comes first.

#### IMPORTANT:

- **Use soft water as a coolant. Do not use strong acid or alkaline water. Use the coolant with genuine Hitachi Long-Life Coolant (LLC) mixed by 30 to 50 %. If a coolant mixed with less than 30 % of Hitachi Long-Life Coolant is used, service life of the cooling parts may be shortened due to damage by freezing or corrosion of coolant system parts.**
- **If mineral-rich water is used for coolant, water stain or scale may build up inside the engine or radiator, causing overheating due to deterioration of coolant performance.**
- **Condensate may accumulate inside the intercooler under some conditions of use. (only ZX130-6N)**
- **Freezing of condensate may cause damage to the intercooler. (only ZX130-6N)**

### H. Electrical System

Parts		Quantity	Interval (hours)						Page	
			8	50	100	250	500	1000		2000
1.	Battery	Check Electrolyte Level	2	Every month						7-88
		Check electrolyte specific gravity	2	Every month						7-90
2.	Replacing Fuses	Replace	–	As required						7-91




## MAINTENANCE

### I. Miscellaneous

Parts		Quantity	Interval (hours)							Page	
			8	50	100	250	500	1000	2000		4500
1.	Check and Replace Bucket Teeth	–									7-94
2.	Change Bucket	–	As required							7-100	
3.	Convert Bucket Connection Into Face Shovel	–	As required							7-101	
4.	Adjust Bucket Linkage	1	As required							7-102	
5.	Remove Travel Levers	2	As required							7-103	
6.	Check and Replace Seat Belt	1		Every 3 years						7-103	
7.	Check Windshield Washer Fluid Level	1	As required							7-104	
8.	Check Track Sag	2									7-105
9.	Clean and Replace Air Conditioner Filter	Circulating Air Filter	Clean	1							7-108
			Replace	1	After cleaning 6 times or so						7-108
	Fresh Air Filter	Clean	1								7-108
			Replace	1	After cleaning 6 times or so						7-108
10.	Check Air Conditioner	–									7-110
11.	Clean Cab Floor	–	As required							7-112	
12.	Retighten Cylinder Head Bolt	–	*As required							7-113	
13.	Inspect and Adjust Valve Clearance	–						*			7-113
14.	Measure Engine Compression Pressure	–						*			7-113
15.	Check Starter and Alternator	–						*			7-113
16.	Check and Replace EGR Device	–	*As required							7-113	
17.	EGR Cooler Cleaning	–								*	7-113
18.	Check Turbo Charger	–								*	7-113
19.	Check and Clean Injector	–								*	7-114
20.	Check Gas Damper	–	*As required							7-114	
21.	Tightening and Retightening Torque of Nuts and Bolts	–		★★							7-114

★★: Maintenance required only during first time check.

 NOTE: \* Contact your authorized dealer for maintenance. Instruction plate for the recommended grease and lubricants is affixed inside the tool box cover.

### J. Aftertreatment Device

Parts		Quantity	Interval (hours)							Page
			8	50	100	250	500	1000	2000	
1.	Check and Clean Aftertreatment Device	–	As required							7-136

### K. Urea SCR System

Parts		Quantity	Interval (hours)							Page		
			8	50	100	250	500	1000	2000		4500	
1.	Check DEF/AdBlue®	1									7-139	
2.	Replace DEF/AdBlue® Supply Module Main Filter	1										7-144
3.	Replace DEF/AdBlue® Tank Water Supply Inlet Filter	1	*If DEF/AdBlue® overflows when supplying water							*	7-146	
4.	Replace DEF/AdBlue® Back Flow Line Filter	1									*	7-147

 NOTE: \* Contact your authorized dealer for maintenance.


## MAINTENANCE

### Periodic Replacement of Parts

To ensure safe operation, be sure to conduct periodic inspection of the machine. In addition, the parts listed below, if defective, may pose serious safety/fire hazards.

These parts may cause serious safety/fire hazards due to deterioration, wear, or fatigue being attributed to material aging or repeated operation. It is very difficult to gauge the extent of deterioration, fatigue, or weakening of the parts listed below simply by visual inspection alone. For this reason, replace these parts at the intervals shown in the table below. Consult your authorized dealer for correct replacement.

Periodic Replacement Parts		Replacement Intervals	
Engine	Fuel hose (Fuel tank, Filter to Engine)	Every 2 years	
	Fuel hose (Engine, Fuel cooler to Fuel tank)	Every 2 years	
	DEF/AdBlue® hoses	Every 2 years	
	Oil filter hose (Engine to oil filter)	Every 2 years	
	Heater hose (Heater to engine)	Every 2 years	
Hydraulic System	Base Machine	Pump suction hose	Every 2 years or 4000 hours whichever comes first
		Pump delivery hose	Every 2 years or 4000 hours whichever comes first
		Swing hose	Every 2 years or 4000 hours whichever comes first
		Travel high pressure hose	Every 2 years or 4000 hours whichever comes first
		Tail Hose	Every 2 years or 4000 hours whichever comes first
		Attachment Line Hose	Every 2 years or 4000 hours whichever comes first
		Hydraulic Fan Suction Hose	Every 2 years or 4000 hours whichever comes first
	Hydraulic Fan Delivery Hose	Every 2 years or 4000 hours whichever comes first	
	Working Device	Boom cylinder line hose	Every 2 years or 4000 hours whichever comes first
		Arm cylinder line hose	Every 2 years or 4000 hours whichever comes first
Bucket cylinder line hose		Every 2 years or 4000 hours whichever comes first	
Seat Belt		Every 3 years	

 **NOTE:** Be sure to replace seals, such as O-rings and gaskets, when replacing hoses.

## MAINTENANCE

### Kind of Oils

#### Brand Names of Recommended Grease

Kind of Grease	Lithium Grease	
Application	Front Attachment Joint Pins, Swing Bearing, Swing Internal Gear	
Air Temp.	-20 to 40 °C (-4 to 104 °F)	
Manufacturer		
Hitachi	Hitachi Grease SEP2 Hitachi Grease EP-2	
Idemitsu Kosan	Daphne Eponex Grease EP No.2 Daphne Eponex Grease No.2	
JX Nippon Oil & Energy Corporation	EPINOC GREASE AP(N)2 LISONIX GREASE EP2	
Shell	Alvania Grease EP2 (Shell Gadus S2 V220 2) Cartridge Grease EP2	
ExxonMobil	Mobilux EP2	
KIGNAS Oil	KIGNAS MP GREASE No.2	
COSMO Oil	COSMO GREASE DYNAMAX EP2	
BP	Energrease LS-EP2	
Castrol	Spheerol EPL2	
Chevron	Multifax EP2	

#### Recommended Engine Oil

**IMPORTANT: Use only genuine Hitachi engine oil as shown below or engine oil equivalent to DH-2 specified in JASO. Failure to do so may deteriorate the engine and Aftertreatment Device performance and/or shorten their service life. Please be noted that all engine failures caused by using engine oil other than specified are excluded from Hitachi Warranty Policy. Consult your authorized dealer for the unclear points.**

Kind of Oil	Engine Oil	
Application	Engine Crank Case	
Air Temp.	-20 to 40 °C (-4 to 104 °F)	
Manufacturer		
Hitachi	Super Wide DH-2 10W40	JASO DH-2


## MAINTENANCE

### Brand Names of Recommended Oil

Application	Swing and Travel Reduction Gear	Pump Transmission
Kind of Oil	Gear Oil	Engine Oil
Air Temp.	-20 to 40 °C (-4 to 104 °F)	-20 to 40 °C (-4 to 104 °F)
Manufacturer		
Hitachi	Hitachi Gear Oil GL-4 90	Super Wide DH-2 10W40 Super Wide DH-1 15W40 Super Wide DH-2 15W40
Idemitsu Kosan	Apolloil Gear Oil HE90	Apolloil Super Wide 15W-40
JX Nippon Oil & Energy Corporation	HYPOID GEAR 90 GEAR4 90	DIESEL CF/DH-1 15W-40 DIESEL CF4/DH-1 15W-40H
Shell	Spirax S2 G 90	Rimula D Multi 15W-40
ExxonMobil	Mobilube GX80W-90	Delvac Super DH-2 15W-40
BP	Energear EP 80W-90	Vanellus C3 Multigrade 15W-30
Castrol	Manual GL-4 80W-90	
Chevron	Thuban SAE 90	DELO 400 Multigrade 15W-30
Remarks	API GL4 Class	API CD Class, JASO DH-1, JASO DH-2

### Brand Names of Recommended Hydraulic Oil

Kind of Lubricant	Hydraulic Oil	
Where to be applied	Hydraulic System	
Change Interval	5000 hours	2000 hours
Environmental Temp.	-20 to 40 °C (-4 to 104 °F)	
Manufacturer		
Hitachi	Super EX 46HN	
Idemitsu Kosan		Super Hydro 46X
JX Nippon Oil & Energy Corporation		SUPER HYRANDO WP46 HYDLUX 46H
Shell		Tellus ST 46 (Tellus S3 V 46)
ExxonMobil		Mobil DTE 10 Excel 46
BP		Bartran HV46
Castrol		Hyspin HVI 46
Chevron		RANDO Ashless 46HD
Others		Product Conforming to JCMAS HK VG46W

 **NOTE:** Consult your authorized dealer for the conditions of use and hydraulic oil other than those described above. Refer to Japan Lubricating Oil Society (JALOS) home page for JCMAS HK qualified product.

## MAINTENANCE

### Recommended Oil Viscosity

Where to be Applied	Kind of Oil	Air Temperature (degrees Celsius)								
		-30	-20	-10	0	10	20	30		40
Engine Oil pan	Engine Oil									Super Wide DH-2 10W40
Pump Transmission	Engine Oil									API CD Class
Swing Reduction Gear Travel Reduction Gear	Gear Oil									Hitachi Gear Oil GL-4_90
Hydraulic System (Hydraulic Oil Tank)	Hydraulic Oil									Super EX46HN
Fuel Tank	Diesel Fuel									ASTM Grade No.2-DS15 ASTM Grade No.2-DS500
										ASTM Grade No.1-DS15 ASTM Grade No.1-DS500
Grease fitting	Lithium Grease									SEP Grease
Radiator	Coolant									Genuine Hitachi LLC (Long-Life Coolant)

## MAINTENANCE

### List of Consumable Parts

#### ZX130-6N, 160LC-6N, 180LC-6N

##### Filter Elements


	ZX130-6N	ZX160LC-6N, 180LC-6N	Quantity
	Part No.	Part No.	
Full-Flow Filter (with O-ring)	YA00008642	YA00016386	1
High Performance Full-Flow Filter	4656609	YA00033064	1
Hydraulic Air Breather Element	4437838	←	1
Pilot Oil Filter (with O-ring)	4630525	←	1
Engine Oil Filter	4658521	←	1
Fuel Main Filter Element	YA00033486	←	1
Fuel Pre-Filter Element	YA00005785	←	1
Air Cleaner Element (outer)	4486002	←	1
Air Cleaner Element (inner)	4486014	←	1
Air Conditioner Circulating Air Filter	4643580	←	1
Air Conditioner Fresh Air Filter	YA00032683	←	1
DEF/AdBlue® Supply Module Main Filter	YA00033443	←	1
Oil Separator Element	YA00045915	←	1

##### Drive Belts

	ZX130-6N	ZX160LC-6N, 180LC-6N	Quantity
	Part No.	Part No.	
Engine Fan Belt	4668374	←	1
Air Conditioner Compressor Belt	4686087	←	1

##### Bucket Parts

		ZX130-6N	ZX160LC-6N, 180LC-6N	Quantity
		Part No.	Part No.	
Tooth	Tooth	963228	←	5
	Lock Pin	963229	←	5
	Lock Rubber	963227	←	5
	Side Cutter (right side)	2015428	←	1
	Side Cutter (left side)	2015429	←	1
Side Cutter	Bolt	J932060	←	8
	Nut	J951020	←	8
	Spring Washer	A590920	←	8
O-ring		4276696	←	4

 NOTE: Quantity row on the above table represents number of parts used for one bucket. The parts quantity of O-ring includes connection part of arm and link

## MAINTENANCE

### Optional Parts

		ZX130-6N		ZX160LC-6N, 180LC-6N	
		Part No.	Quantity	Part No.	Quantity
Clamshell Bucket	Tooth	452632	6	452632	8
	Bolt	447167	18	J932280	24
	Nut	452064	18	J951022	24
	Spring Washer	A590922	18	A590922	24
One Point Ripper	Tooth	971377	1	971377	1
	Pin	971378	1	971378	1
	Bushing Rubber	971379	1	971379	1
Ripper Bucket	Tooth	971377	1	971377	1
	Pin	971378	1	971378	1
	Bushing Rubber	971379	1	971379	1
	Tooth	4427919	2	4427919	2
	Lock Pin	4501627	2	4501627	2
	Lock Rubber	4319920	2	4319920	2

## MAINTENANCE

### ZX210-6N, 210LC-6N

#### Filter Elements


	Part No.	Quantity
Full-Flow Filter (with O-ring)	YA00033065	1
High Performance Full-Flow Filter	YA00033064	1
Hydraulic Air Breather Element	4437838	1
Pilot Oil Filter (with O-ring)	4630525	1
Engine Oil Filter	4658521	1
Fuel Main Filter Element	YA00033486	1
Fuel Pre-Filter Element	YA00005785	1
Air Cleaner Element (outer)	4286128	1
Air Cleaner Element (inner)	4286130	1
Air Conditioner Circulating Air Filter	YA00001490	1
Air Conditioner Fresh Air Filter	YA00032683	1
DEF/AdBlue® Supply Module Main Filter	YA00033443	1

#### Drive Belts

	Part No.	Quantity
Engine Fan Belt	YA00006855	1
Air Conditioner Compressor Belt	YA00007116	1

#### Bucket Parts

		Part No.	Quantity
Tooth	Tooth	4427919	5
	Lock Pin	4501627	5
	Lock Rubber	4501625	5
	Side Cutter (right side)	2014503	1
	Side Cutter (left side)	2014504	1
Side Cutter	Bolt	J932270	12
	Nut	J951022	12
	Spring Washer	A590922	12
O-ring		4089028	4

 **NOTE:** Quantity row on the above table represents number of parts used for one bucket. The parts quantity of O-ring includes connection part of arm and link.



## MAINTENANCE

### Optional Parts

		Part No.	Quantity
Clamshell Bucket	Tooth	452632	8
	Bolt	J932280	24
	Nut	J951022	24
	Spring Washer	A590922	24
One Point Ripper	Tooth	971377	1
	Pin	971378	1
	Bushing Rubber	971379	1
Ripper Bucket	Tooth	971377	1
	Pin	971378	1
	Bushing Rubber	971379	1
	Tooth	4427919	2
	Lock Pin	4501627	2
	Lock Rubber	4319920	2
Ditch Cleaning Bucket (0.30, 0.35, 0.40 m <sup>3</sup> )	Tooth	973347	*
	Lock Pin	963229	*
	Lock Rubber	963227	*
Reinforced Hoe Bucket HD Type	Tooth	4427919	5
	Lock Pin	4501627	5
	Lock Rubber	4501625	5
Reinforced Hoe Bucket HD Type (Transverse- Type-Pin)	Tooth	4364121	5
	Pin	4364125	5
Hoe Bucket with Super V type Bucket Teeth	Tooth	4383048	5
Reinforced Hoe Bucket	Pin	4383069	5

 NOTE: \* The parts quantity of items with \* mark.

- Four parts are required per each bucket of 0.30, 0.35, and 0.40 m<sup>3</sup>.
- Seven parts are required per one ditch cleaning bucket with teeth.

## MAINTENANCE

### ZX250LC-6N, 300LC-6N

#### Filter Elements


	ZX250LC-6N	ZX300LC-6N	Quantity
	Part No.	Part No.	
Full-Flow Filter (with O-ring)	YA00033065	←	1
High Performance Full-Flow Filter	YA00033064	←	1
Hydraulic Air Breather Element	4437838	←	1
Pilot Oil Filter (with O-ring)	4630525	←	1
Engine Oil Filter	4658521	←	1
Fuel Main Filter Element	YA00033486	←	1
Fuel Pre-Filter Element	YA00005785	←	1
Air Cleaner Element (outer)	4286128	4459549	1
Air Cleaner Element (inner)	4286130	4459548	1
Air Conditioner Circulating Air Filter	YA00001490	←	1
Air Conditioner Fresh Air Filter	YA00032683	←	1
DEF/AdBlue® Supply Module Main Filter	YA00033443	←	1

#### Drive Belts

	ZX250LC-6N	ZX300LC-6N	Quantity
	Part No.	Part No.	
Engine Fan Belt	YA00006855	4603925	1
Air Conditioner Compressor Belt	YA00007116	4612331	1

#### Bucket Parts


		Part No.	Quantity
Tooth	Tooth	4512365	5
	Lock Pin	4512366	5
	Lock Rubber	4501625	5
	Side Cutter (right side)	2021232	1
	Side Cutter (left side)	2021233	1
Side Cutter	Bolt	J932275	12
	Nut	J951022	12
	Spring Washer	A590922	12
O-ring		4089028	4

 **NOTE:** Quantity row on the above table represents number of parts used for one bucket. The parts quantity of O-ring includes connection part of arm and link.

## MAINTENANCE

### Optional Parts

		Part No.	Quantity
One Point Ripper	Tooth	4507888	1
	Pin	4507890	1
	Bushing Rubber	4507891	1
Ripper Bucket	Tooth	4507888	1
	Pin	4507890	1
	Bushing Rubber	4507891	1
	Tooth	4383048	2
	Lock Pin	4383069	2
Rock Bucket	Tooth	4400253	5
	Lock Pin	4383465	5
	Shroud	4435856	1
	Shroud	4435857	1
	Bolt	J932780	6
	Nut	J951027	6
	Washer	4085857	6
Ditch Cleaning Bucket (0.36 m <sup>3</sup> , 0.40 m <sup>3</sup> , 0.50 m <sup>3</sup> )	Tooth	973347	*
	Lock Pin	963229	*
	Lock Rubber	963227	*
Reinforced Hoe Bucket HD Type	Tooth	4512365	5
	Lock Pin	4512366	5
	Lock Rubber	4501625	5
* 2 Reinforced Hoe Bucket HD Type (Transverse-Type-Pin)	Tooth	4380343	5
	Pin	4380844	5

 NOTE: \* The parts quantity of items with \* mark.

- Four parts are required per each bucket of 0.36, 0.40, and 0.50 m<sup>3</sup>.
- Seven parts are required per one ditch cleaning bucket with teeth.
- An item with \* 2 mark is for ZX250LC-6N.

## MAINTENANCE

### ZX350LC-6N, 380LC-6N

#### Filter Elements


	Part No.	Quantity
Full-Flow Filter (with O-ring)	YA00033065	1
High Performance Full-Flow Filter	YA00033064	1
Hydraulic Air Breather Element	4437838	1
Pilot Oil Filter (with O-ring)	4630525	1
Engine Oil Filter	4658521	1
Fuel Main Filter Element	YA00033486	1
Fuel Pre-Filter Element	YA00005785	1
Air Cleaner Element (outer)	4459549	1
Air Cleaner Element (inner)	4459548	1
Air Conditioner Circulating Air Filter	YA00001490	1
Air Conditioner Fresh Air Filter	YA00032683	1
DEF/AdBlue® Supply Module Main Filter	YA00033443	1

#### Drive Belts

	Part No.	Quantity
Engine Fan Belt	YA00011518	1
Air Conditioner Compressor Belt	4612331	1

#### Bucket Parts

		Part No.	Quantity
Tooth	Tooth	4512365	5
	Lock Pin	4512366	5
	Lock Rubber	4501625	5
Side Cutter	Side Cutter (right side)	2021232	1
	Side Cutter (left side)	2021233	1
	Bolt	J932275	12
	Nut	J951022	12
	Spring Washer	A590922	12
O-ring		4100180	4

 **NOTE:** Quantity row on the above table represents number of parts used for one bucket. The parts quantity of O-ring includes connection part of arm and link.

## MAINTENANCE

### Optional Parts

		Part No.	Quantity
One Point Ripper	Tooth	4507888	1
	Pin	4507890	1
	Bushing Rubber	4507891	1
Ripper Bucket	Tooth	4507888	1
	Pin	4507890	1
	Bushing Rubber	4507891	1
	Tooth	4383048	2
	Lock Pin	4383069	2
Ditch Cleaning Bucket	Tooth	4400253	5
	Lock Pin	4383465	5
	Shroud	4435856	1
	Shroud	4435857	1
	Bolt	J932780	6
	Nut	J951027	6
	Washer	4085857	6
Rock Bucket	Tooth	973347	*
	Lock Pin	963229	*
	Lock Rubber	963227	*
Hoe Bucket (Super V)	Tooth	4512365	5
	Lock Pin	4512366	5
	Lock Rubber	4501625	5
Rock Bucket (Transverse-Type-Pin)	Tooth	4380343	5
	Pin	4380844	5

 NOTE: \* The parts quantity of items with \* mark.


- Four parts are required per each bucket of 0.50, 0.60, and 0.70 m<sup>3</sup>.
- Seven parts are required per one ditch cleaning bucket with teeth.

# MAINTENANCE

## A. Greasing


### 1 Front Joint Pins --- every 250 hours

Lubricate all fittings shown in the figure.  
\* Only top of the arm 50 hours.




M178-07-007

- Boom Cylinder Bottom Side



M157-07-156

- Boom Foot




M157-07-155

## MAINTENANCE


---

- Boom and Arm Joint Pin, Arm Cylinder Rod Pin and Bucket Cylinder Bottom Pin



M157-07-157

- Boom Cylinder Rod Pins and Arm Cylinder Bottom Pin



M157-07-155

## MAINTENANCE

### 2 Swing Bearing --- every 500 hours

**CAUTION:** Lubricating both the swing bearing and gear, and rotating the upperstructure must be done by one person. Before you lubricate the swing bearing, clear the area of all persons.

Each time you leave the cab

- Lower the bucket to the ground.
- Stop the engine.
- Pull the pilot control shut-off lever to the **LOCK** position.
- Use handrails.


1. Park the machine on a firm, level surface.
2. Lower the bucket to the ground.
3. Turn the auto-idle switch off.

**IMPORTANT:** The turbocharger may be damaged if the engine is not properly shut down.


4. Run the engine at slow idle speed without load for five minutes.
5. Turn the key switch OFF. Remove the key from the key switch.
6. Pull the pilot control shut-off lever to the LOCK position.
7. With the upperstructure stationary, apply grease via the 2 grease fittings.
8. Start the engine. Raise the bucket several inches off the ground and rotate the upperstructure 45 ° (1/8 turn).
9. Lower the bucket to the ground.
10. Repeat the procedure 3 times, beginning with step 3.
11. Apply grease to the swing bearing until grease can be seen escaping from the swing bearing seals.

Model	Capacity
ZX130-6N	0.25 L (0.26 US qt)
ZX160LC-6N, 180LC-6N, 210-6N, 210LC-6N	0.30 L (0.32 US qt)
ZX250LC-6N, 300LC-6N	0.35 L (0.37 US qt)
ZX350LC-6N, 380LC-6N	0.40 L (0.42 US qt)

12. Take care not to supply excessive grease.



M157-07-159



MDCR-07-015



## MAINTENANCE


### 3 Swing Internal Gear --- every 500 hours

**⚠ CAUTION:** Before lubricating the machine, lower the bucket on the ground, stop the engine and pull the pilot control shut-off lever to the LOCK position.

1. Remove cover (1) from upperstructure. Check if the swing internal gear is properly lubricated by grease. Add approximately 0.5 kg of grease, if required.


If the grease is contaminated, remove grease by opening cover (2) at the undercarriage side and change with clean grease.

Model	Grease Capacity
ZX130-6N	9 L (2.4 US gal)
ZX160LC-6N, 180LC-6N, 210-6N, 210LC-6N, 250LC- 6N, 300LC-6N	17 L (4.5 US gal)
ZX350LC-6N, 380LC-6N	19 L (5.0 US gal)




MDC1-07-038

ZX130-6N, 210-6N, 210LC-6N,  
250LC-6N, 300LC-6N, 350LC-6N, 380LC-6N



M104-07-002

ZX160LC-6N, 180LC-6N



M157-07-161

# MAINTENANCE

## B. Engine


### 1 Check Engine Oil Level ---daily


1. Confirm that pilot control shut-off lever (1) is in the LOCK position.
2. Confirm that all control levers are placed in neutral.
3. Insert key (2) into the key switch. Turn it to ON position. Press and hold switch (3) with the engine stopped.

The engine oil level indicator (4) must be displayed in green.

**IMPORTANT:** Do not rely only on the monitor display for checking the machine conditions; visually check them yourself as required such as oil level.


**Always check the machine on a firm, level surface.**

 **NOTE:** If the security function is enabled, a password is required.




LOCK position


MDAA-01-295



MDC1-01-502



MDCD-01-026



MDC1-01-041

## MAINTENANCE

### --- Visual Inspection

**IMPORTANT:** Incorrect engine oil level may cause trouble in the engine (The oil level should be between the upper and lower marks on dipstick (1)).

Even if the engine oil level exceeds the upper limit, maintain oil to the proper level before starting the engine.

Check oil level before starting the engine.

Open the engine cover and pull out dipstick (1). Wipe dipstick (1) with cloth, re-insert it into the pipe to the end, and then pull it out again.

The oil level should be between the upper and lower marks on dipstick (1).


If oil level is below the lower limit mark, add the recommended engine oil via oil filler (2).

If oil level exceeds the upper limit mark, remove cap (4) of drain valve (3) at the bottom of the engine oil pan, and then open drain valve (3) by turning drainer (5) to drain oil.


**CAUTION:** Avoid spillages while changing oil. Spilled fuel and oil, trash, grease, debris, accumulated coal dust, and other flammable materials may cause fires.

After refilling, make sure oil filler cap (2) is securely closed.


**IMPORTANT:** Install drainer (5) to drain valve (3) slowly. Oil may exhaust in large quantity when tightened at once.




MDC1-07-023



M178-07-011



M1U1-07-045



M1U1-07-046

## MAINTENANCE

---

**2** Change Engine Oil  
--- every 500 hours

**3** Replace Engine Oil Filter  
--- every 500 hours

**⚠ CAUTION: Engine oil may be hot just after operation.  
Take extra care to avoid burns.  
After refilling, make sure oil filler cap (2) is securely  
closed.**

1. Run the engine to warm oil.  
DO NOT run the engine until oil is hot.
2. Park the machine on a firm, level surface.
3. Lower the bucket to the ground.
4. Turn the auto-idle switch off.







**IMPORTANT: The turbocharger may be damaged if the  
engine is not properly shut down.**

5. Run the engine at slow idle speed without load for 5  
minutes.
6. Turn the key switch OFF. Remove the key from the key  
switch.
7. Pull the pilot control shut-off lever to the LOCK position.

## MAINTENANCE

**IMPORTANT: Install drainer (5) to drain valve (3) slowly. Oil may exhaust in large quantities when suddenly tightened.**

8. Remove oil filler cap (2).
  9. Remove cap (4) from oil pan drain valve (3). Install drainer (5) to drain valve (3).
  10. Screw drainer (5) into drain valve (3). Drain valve (3) will be opened to drain oil.
  11. Then, allow oil to drain through a clean cloth into a container.
- ZX130-6N, 160LC-6N, 180LC-6N, : 50-liter (13 US gal)  
 210-6N, 210LC-6N, 250LC-6N  
 ZX300LC-6N, 350LC-6N, 380LC-6N : 60-liter (16 US gal)
12. After all oil has been drained, inspect the cloth for any debris such as small pieces of metal.
  13. Remove drainer (5). Install cap (4) to drain valve (3).




## MAINTENANCE


14. Open the right access cover and secure the cover with rod.
15. Remove engine oil filter (6) by turning it counterclockwise with the filter wrench.
16. Clean filter (6) gasket contact area on the engine.
17. Put new oil in from primary side (7) of new cartridge element (6) so it does not overflow. Take care not to insert it from secondary side (8).
18. Install new filter (6). Turn filter (6) clockwise by hand until the gasket touches the contact area. Be sure not to damage the gasket when installing filter (6).
19. Tighten engine oil filter (6) 3/4 to 1 turn further using the filter wrench. Be careful not to overtighten.
20. Fill the engine with recommended oil. Check that oil level is between the circle marks on the dipstick after 15 minutes.
21. Install the oil filler cap.
22. Start the engine. Run the engine at slow idle for 5 minutes.
23. Check that the engine oil pressure indicator on the monitor panel goes out immediately. If not, stop the engine immediately and find the cause.
24. Stop the engine. Remove the key from the key switch.
25. Check for any leakage at the drain plug.
26. Check oil level on the dipstick and add or drain oil to maintain proper oil level. (The oil level should be between the upper and lower limit marks on the oil level gauge.) (Refer to the page 7-33)

### IMPORTANT:


- **When patting new oil in cartridge element (6), take care that no foreign objects get in from secondary side (8).**
- **Do not re-use filter (6).**
- **Incorrect engine oil level may cause trouble in on the engine. Even if the engine oil level exceeds the upper limit, control the oil level to the proper quantity before starting the engine.**
- **Do not overtighten the engine oil pan mounting bolts of ZX130-6N, 160LC-6N and 180LC-6N machines. Failure to do so may damage the packing seal.**




ZX130-6N, 160LC-6N, 180LC-6N MDC1-07-071



ZX210-6N, 210LC-6N, 250LC-6N MDAA-07-103



ZX300LC-6N, 350LC-6N, 380LC-6N M1U1-07-014



MDCR-07-007

## MAINTENANCE

- 4** Check and Clean Around the Engine  
----- as required

**IMPORTANT:** Check for flammable materials in the area around the engine and clean that area.


When the machine is operated in dusty areas, refer to the page 9-1" Maintenance Under Special Environmental Conditions".

- 5** Replace Oil Separator Element (ZX130-6N, 160LC-6N, 180LC-6N)  
----- every 2500 hours


**CAUTION:** The oil separator becomes hot during operation. Severe burns may result if skin comes in contact with the oil separator immediately after operation. Wait for the oil separator to cool before starting any maintenance work.

**IMPORTANT:** To prevent foreign matter from entering, clean cap (3) and its surround before replacing oil separator element (1).

1. Park the machine on solid and level ground with the bucket cylinder fully extended and the arm cylinder fully retracted. Lower the bucket on the ground. Stop the engine.
2. Remove the cap by twisting it counterclockwise.
3. Remove the oil separator element and O-ring (2). Replace them with new ones.
4. Securely tighten the cap by twisting it clockwise by hand.



MDC1-07-066



MDC1-07-079

## MAINTENANCE

### C. Transmission

#### 1 Pump Transmission (Except ZX130-6N)

##### Check Oil Level --- every 250 hours

1. Park the machine on a firm, level surface.
2. Lower the bucket to the ground.
3. Turn the auto-idle switch off.

**IMPORTANT: The turbocharger may be damaged if the engine is not properly shut down.**

4. Run the engine at slow idle speed without load for 5 minutes.
5. Stop the engine. Remove the key from the key switch.
6. Pull the pilot control shut-off lever to the LOCK position.
7. Remove dipstick (1). Oil must be within the specified range.
8. If necessary, remove filler plug (2) and add oil. (See gear oil chart)
9. Recheck oil level.

##### Change Oil --- every 1000 hours


##### Air Breather Cleaning --- every 1000 hours

**CAUTION: Oil may be hot just after operation. Wait for oil to cool before starting work.**

1. Park the machine on a level surface.
2. Lower the bucket to the ground.
3. Turn the auto-idle switch off.


**IMPORTANT: The turbocharger may be damaged if the engine is not properly shut down.**

4. Run the engine at slow idle speed without load for five minutes.
5. Stop the engine. Remove the key from the key switch.
6. Pull the pilot control shut-off lever to the LOCK position.
7. Remove filler plug (2).
8. Remove drain plug (3). Allow oil to drain through a clean cloth into a 2-liter (2.1 US qt) container.
9. After all oil has drained, inspect cloth for any debris such as small pieces of metal.
10. Reinstall drain plug (3).
11. Add oil via filler plug (2) until it is within the specified range on dipstick (1).
12. Reinstall filler plug (2).
13. Remove the air breather and perform cleaning. After cleaning, install the air breather.



M178-07-085


ZX160LC-6N, 180LC-6N, 210-6N, 210LC-6N, 250LC-6N



ZX300LC-6N, 350LC-6N, 380LC-6N

M110-07-015

Specified Range



M1G6-07-004



## MAINTENANCE



### 2 Swing Reduction Gear

#### Check Oil Level --- every 500 hours

1. Park the machine on a firm, level surface.
2. Lower the bucket to the ground.
3. Turn the auto-idle switch off.

**IMPORTANT: The turbocharger may be damaged if the engine is not properly shut down.**

4. Run the engine at slow idle speed without load for 5 minutes.
5. Stop the engine. Remove the key from the key switch.
6. Pull the pilot control shut-off lever to the LOCK position.
7. Remove dipstick (1). Oil must be between marks.
8. If necessary, remove oil filler cap (2) and add oil. (See gear oil chart)
9. Recheck oil level.



#### Change Gear Oil --- every 1000 hours

**CAUTION: Gear oil may be hot just after operation. Wait for gear oil to cool before starting work.**

1. Park the machine on a level surface.
2. Lower the bucket to the ground.
3. Turn the auto-idle switch off.

**IMPORTANT: The turbocharger may be damaged if the engine is not properly shut down.**

4. Run the engine at slow idle speed without load for five minutes.
5. Stop the engine. Remove the key from the key switch.
6. Pull the pilot control shut-off lever to the LOCK position.
7. Remove the drain plug mounted on the end of drain pipe to drain oil.
8. Reinstall the drain plug.
9. Remove oil filler cap (2) and add oil until it is between the marks on dipstick (1).
10. Reinstall oil filler cap (2).

## MAINTENANCE

### 3 Travel Reduction Gear


**CAUTION:** Keep body and face away from air release plug (1). Gear oil may be hot just after operation. Wait for gear oil to cool and then gradually loosen air release plug (1) to release pressure.

#### Check Oil Level --- every 500 hours


1. Park the machine on a firm, level surface.
2. Rotate the travel motor until the imaginary line through plug (1) and plug (3) are vertical.
3. Lower the bucket to the ground.
4. Turn the auto-idle switch off.

**IMPORTANT:** The turbocharger may be damaged if the engine is not properly shut down.

5. Run the engine at slow idle speed without load for 5 minutes.
6. Stop the engine. Remove the key from the key switch.
7. Pull the pilot control shut-off lever to the LOCK position.
8. After gear oil has cooled, slowly loosen air release plug (1) to release pressure.
9. Remove air release plug (1) and oil level check plug (2). Oil must be up to the bottom of hole.
10. If necessary, add oil until oil flows out of oil level check plug (2) hole. (See gear oil chart)
11. Wrap the plug threads with sealing-type tape. Install plugs (1) and (2).  
Tighten plugs (1) and (2) to 50 N·m (5 kgf·m).
12. Check the gear oil level in the other travel reduction gear.



MDAA-07-047



M157-07-170


## MAINTENANCE

### Change Gear Oil --- every 2000 hours

1. Park the machine on a firm, level surface.
2. Rotate the travel motor until the imaginary line through plug (1) and plug (3) are vertical.
3. Lower the bucket to the ground.
4. Turn the auto-idle switch off.

**IMPORTANT: The turbocharger may be damaged if the engine is not properly shut down.**

5. Run the engine at slow idle speed without load for 5 minutes.
6. Stop the engine. Remove the key from the key switch.
7. Pull the pilot control shut-off lever to the LOCK position.
8. After gear oil has cooled, slowly loosen air release plug (1) to release pressure, and temporarily retighten plug (1).
9. Remove drain plug (3) and plug (1), in that order, to drain oil.
10. Clean drain plug (3). Wrap the threads of drain plug (3) with sealing-type tape. Install plug (3). Tighten plug (3).  
Tightening Torque: 50 N·m (5 kgf·m)
11. Remove oil level check plug (2).
12. Add oil until oil flows out of oil level check plug (2) hole.  
(See gear oil chart)
13. Clean plugs (1) and (2). Wrap the threads of oil level check plug (2) and air release plug (1) with sealing-type tape. Reinstall the plugs (1) and (2). Tighten the plugs (1) and (2).  
Tightening Torque: 50 N·m (5 kgf·m)
14. Repeat steps 8. to 13. for the other travel reduction gear.



M157-07-170

# MAINTENANCE

---

## D. Hydraulic System

### Inspection and Maintenance of Hydraulic Equipment

**IMPORTANT:** Never adjust parts of engine fuel system or hydraulic equipment.

**CAUTION:** When checking and/or servicing the hydraulic components, pay special attention to the following points.

1. Be sure that the machine is parked on a level, firm surface before servicing hydraulic equipment.
2. Lower the bucket to the ground and stop the engine.
3. Begin servicing hydraulic components only after components, hydraulic oil and lubricants are completely cooled, and after releasing residual pressure.
  - 3.1 Before checking and/or servicing the hydraulic system, be sure to release the residual pressure from the cylinder circuits of the boom, arm and the bucket, swing piping and pilot piping. An accumulator can be installed on some models of this machine as an option to be capable of moving the front attachment for specified time (around 10 seconds) after stopping the engine.
  - 3.2 Bleed air from the hydraulic oil tank to release internal pressure.
  - 3.3 Immediately after operation, all hydraulic components and hydraulic oil or lubricants are hot and highly pressurized. Begin inspection and/or maintenance work only after the machine has cooled down.

Servicing heated and pressurized hydraulic components may cause plugs, screws and/or oil to fly off or escape suddenly, possibly resulting in personal injury. Hydraulic components may be pressurized even when cooled.

Keep body parts and face away from the front of plugs or screws when removing them.
  - 3.4 Even after air pressure in the hydraulic oil tank is released, when the machine is parking on a slope, the oil pressure in the travel motor and the swing motor circuits are maintained at high pressure as the reaction force of the machine's own weight is constantly applied to the travel motor. Never check and/or service the machine while parked on a slope.

## MAINTENANCE

---

### IMPORTANT:

- **When connecting hydraulic hoses and pipes, take special care to keep seal surfaces free from dirt and to avoid damaging them.**
- **Wash hoses, pipes, and the tank interior with a washing liquid and thoroughly wipe off before reconnecting.**
- **Only use O-rings that are free of damage or defects. Be careful not to damage them during reassembly. Do not allow high pressure hoses to twist when connecting them. The life of twisted hoses will be shortened considerably.**
- **Do not use hydraulic oils other than those listed in the table "Brand names of recommended hydraulic oil".**
- **When adding hydraulic oil, always use the same brand of oil; do not mix brands of oil. When using another manufacturer's hydraulic oil, be sure to change the full amount.**
- **The new machine is filled with Super EX 46HN hydraulic oil (change interval: every 5000 hours). When adding or changing the hydraulic oil, continue to use Super EX 46HN.**
- **Never run the engine without oil in the hydraulic oil tank.**

## MAINTENANCE

### Change Hydraulic Oil and Replace Full-Flow Filter Element

Hydraulic breaker operation causes the hydraulic system to become contaminated faster and quickly deteriorates the hydraulic oil.


Failure to adhere to proper maintenance intervals may result in damage to the base machine and the breaker.

In order to extend service life, particularly that of the hydraulic pump, change the hydraulic oil and the full-flow filter element at the specified frequency given below.

Check machine service hours by using the breaker hour meter. (Refer to the Breaker Operation in the OPERATOR'S STATION chapter.)

Changing intervals for the high performance element (micro-glass)

Breaker Operating Availability	0 %	10 %	20 %	30 %	40 %	50 %	60 %	70 %	80 %	90 %	100 %
Full-Flow Filter	1000	670	510	410	340	290	250	230	200	190	170
Hydraulic oil: 2000 hours life time	2000	1590	1320	1130	990	880	790	710	650	600	560
Hydraulic oil: 5000 hours life time	5000	2790	1930	1480	1200	1010	870	760	680	610	560




MDAA-07-050

## MAINTENANCE

Changing intervals for the standard full-flow filter (paper filter)

Breaker Operating Availability	0 %	10 %	20 %	30 %	40 %	50 %	60 %	70 %	80 %	90 %	100 %
Full-Flow Filter	1000	340	210	150	120	100	80	70	60	60	50
Hydraulic oil: 2000 hours life time	2000	1310	980	780	650	550	480	430	380	350	320
Hydraulic oil: 5000 hours life time	5000	2030	1270	930	730	600	510	440	390	350	320



MDAA-07-051

**NOTE:** Hydraulic oil restriction indicator is optional.

*If a filter-paper element is used, this indicator does not operate.*

## MAINTENANCE

### 1 Check Hydraulic Oil Level --- daily

**CAUTION:** The hydraulic oil tank is pressurized. Push the pressure release button on the tank cap to release pressure, and carefully remove the cap.




M104-07-021

**IMPORTANT:** Never run the engine without oil in hydraulic oil tank.

1. Park the machine on a firm, level surface.
2. Position the machine with the arm cylinder fully retracted and the bucket cylinder fully extended.
3. Lower the bucket to the ground.
4. Turn the auto-idle switch off.

**IMPORTANT:** The turbocharger may be damaged if the engine is not properly shut down.



MDC1-07-035

5. Run the engine at slow idle speed without load for 5 minutes.
6. Turn the key switch OFF. Remove the key from the key switch.
7. Pull the pilot control shut-off lever to the LOCK position.
8. Open the access door in front of the main pump. Check oil level with level gauge (1) on hydraulic oil tank. Oil must be between marks on gauge (1). If necessary, add oil.

To add oil:

9. Push the pressure release button on the air breather to release pressure. Remove the cover.
10. Add oil. Recheck oil level with level gauge (1).
11. Install the cover. Make sure the filter and rod assembly is in correct position.



## MAINTENANCE

### 2 Change Hydraulic Oil --- every 2000 hours or 5000 hours

#### **CAUTION:**

- Hydraulic oil may be hot just after operation. Wait for oil to cool before starting work.
- The hydraulic oil tank is pressurized. Push pressure release button (1) on the air breather before removing the air breather.

**IMPORTANT:** Hydraulic oil changing intervals differ according to kind of hydraulic oils used. (See Recommended Oil Chart in this group)

1. Park the machine on a firm, level surface with the upperstructure rotated 90° for easier access.
2. Position the machine with the arm cylinder fully retracted and the bucket cylinder fully extended.
3. Lower the bucket to the ground.
4. Turn the auto-idle switch off.


**IMPORTANT:** The turbocharger may be damaged if the engine is not properly shut down.

5. Run the engine at slow idle speed without load for 5 minutes.
6. Stop the engine. Remove the key from the key switch.
7. Pull the pilot control shut-off lever to the LOCK position.
8. Clean the top of the hydraulic oil tank to keep dirt out of the hydraulic system.
9. Push pressure release button (1) on the air breather.
10. Remove cover (2).
11. Remove oil using a suction pump. The hydraulic oil tank capacity, up to specified oil level, is approximately the value shown in column A below.


Model	A
ZX130-6N	130 L (34.3 US gal)
ZX160LC-6N, 180LC-6N	190 L (50.2 US gal)
ZX210-6N, 210LC-6N	200 L (52.8 US gal)
ZX250LC-6N, 300LC-6N	243 L (64.2 US gal)
ZX350LC-6N, 380LC-6N	298 L (78.7 US gal)




M104-07-117



M157-07-016



MDAA-07-037




M1U1-07-047


## MAINTENANCE

---

12. Remove drain plug (3). Allow oil to drain.
13. Clean, install and tighten drain plug (3).
14. Add oil until it is between the marks on the oil level gauge.
15. Install cover (2). Tighten the bolts to 50 N·m (5 kgf·m, 36 lbf·ft).
16. Be sure to bleed air from the system following the procedures shown on the next page.



M1U1-07-047



M157-07-062

## MAINTENANCE

### Bleed Air from the Hydraulic System

After changing hydraulic oil, bleed air from the hydraulic system by following the procedures below.

**IMPORTANT: If the hydraulic pump is not filled with oil, it will be damaged when the engine is started. Bleed air from the pump.**

- Bleeding Air from Hydraulic Pump


1. Remove air bleed plug (4) on each pump. Fill the pump with oil through air bleed plug (4) hole.
2. After hydraulic oil is filled in the pump, provisionally tighten plug (4). Start to run the engine at slow idle speed.
3. Slightly loosen one of plugs (4). Allow air to bleed from the pump through the clearance until hydraulic oil permeates around plug (4).
4. After bleeding air, tighten plug (4) to specification.  
Tightening Torque: 95 N·m (9.5 kgf·m, 70.1 lbf·ft)
5. Repeat Steps 3 and 4 for the remainder of plugs (4).

- Bleeding Air from Hydraulic Circuit

1. After filling hydraulic oil, start the engine. While moving all cylinders and the swing motor evenly, lightly operate the machine for 10 to 15 minutes.


As the air bleeding device is provided in the pilot circuit, air will be released by conducting the above operation for 5 minutes.

2. Lower the bucket to the ground to return to the position to check hydraulic oil level.
3. Stop the engine. Check the oil level. Add oil as needed.




ZX130-6N

MDAA-07-072




ZX160LC-6N, 180LC-6N

M1U1-07-035



ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N

MDAA-07-001



ZX350LC-6N, 380LC-6N

MDAA-07-002

## MAINTENANCE


### 3 Suction Filter Cleaning ---each time when hydraulic oil is changed

The suction filter is located on the bottom of the hydraulic oil tank.


Clean the suction filter when changing hydraulic oil.

1. After removing hydraulic oil from the hydraulic oil tank, remove cover (1) and rod assembly (2).
2. Clean the inside of the hydraulic oil tank and the suction filter.
3. Before installing the suction filter, check the dimension of rod assembly (2) shown in figure right. Securely insert rod assembly (2) into pipe (3).
4. Before securing cover (1) with bolts, ensure the top edge of the rod assembly (2) is completely inserted into the hole of support (4).
5. Bleed air from the hydraulic system.

(Refer to the descriptions for " **2** Air bleeding procedures")



M157-07-062




Rod Assembly

M107-07-070

## MAINTENANCE

### 4 Replace Full-Flow Filter --- every 1000 hours


**CAUTION:** Hydraulic oil becomes hot and pressurized during operation. Severe burns may result if skin comes in contact with escaping hydraulic oil just after operation. Wait for the oil to cool before starting any maintenance work.



M1CC-07-002

#### Replace

1. Park the machine on solid and level ground with the bucket cylinder fully extended and the arm cylinder fully retracted. Lower the bucket on the ground as shown to the right. Stop the engine.
2. Before replacing element (5), be sure to bleed air pressure from the hydraulic oil tank by pushing release button on the hydraulic oil tank.
3. Loosen bolts (1) (6 used) to remove cover (2) and O-ring (3). When removing cover (2), slowly remove cover (2) while pressing cover (2) downward so that spring (4) does not fly off.
4. Remove spring (4), and element (5).
5. Take extra care not to allow water or dust to enter the filter case.
6. Replace element (5) and O-ring (3) with new one, and install them to the hydraulic oil tank with spring (4). Be careful not to damage element (5) and O-ring (3).  
Broken element (5) is unusable.
7. Install cover (2) with bolts (1) (6 used).  
Tightening Torque: 50 N·m (5 kgf·m, 36.9 lbf·ft)
8. Bleed air from the pump after replacing element (5).  
(Refer to "Bleed Air from the Hydraulic System".)  
If the machine is operated with air mixed in the hydraulic circuit, damage to the pump may result.



M178-07-069

**IMPORTANT:** Replace element (5) at the regular interval to keep hydraulic oil clean and to extend the service life of the hydraulic components.

## MAINTENANCE

### 5 Replace Pilot Oil Filter --- every 1000 hours



**CAUTION:** The hydraulic oil tank is pressurized. Push the pressure release button on the air breather before replacing pilot oil filter.

1. Park the machine on a firm, level surface.
2. Lower the bucket to the ground.
3. Turn the auto-idle switch off.


**IMPORTANT:** The turbocharger may be damaged if the engine is not properly shut down.

4. Run the engine at slow idle speed without load for 5 minutes.
5. Stop the engine. Remove the key from the key switch.
6. Pull the pilot control shut-off lever to the LOCK position.
7. Remove pilot oil filter (2) by turning it counterclockwise with the filter wrench.
8. Clean the filter O-ring contact area on filter head (1).
9. Apply a thin film of clean oil to the gasket of new filter (2).
10. Install new filter (2). Turn filter (2) clockwise by hand until the O-ring touches the contact area. Be sure not to damage the O-ring when installing filter (2).


**IMPORTANT:** Do not re-use pilot oil filter (2).



MDAA-07-106




M104-07-021




ZX130-6N

MDC1-07-081



ZX160LC-6N, 180LC-6N

MDC1-07-071



ZX210-6N, 210LC-6N, 250LC-6N

MDAA-07-102

## MAINTENANCE

### 6 Replace Air Breather Element --- every 5000 hours


**CAUTION:** Hydraulic oil becomes hot and pressurized during operation. Severe burns may result if skin comes in contact with escaping hydraulic oil just after operation. Wait for the oil to cool before starting any maintenance work.




M104-07-021

#### Procedures:

1. Park the machine on solid and level ground with the bucket cylinder fully extended and the arm cylinder fully retracted. Lower the bucket on the ground as shown to the right. Stop the engine.
2. Before replacing element (3), be sure to bleed air pressure from the hydraulic oil tank by pushing release button on the hydraulic oil tank.
3. Turn cover (2) clockwise approx. 1/4 turn. Remove cap (1) by turning it counterclockwise.
4. Turn cover (2) counterclockwise and remove it. Remove element (3).
5. Install new element (3). Tighten to install cover (2) until cover (2) comes in contact with element (3). Then, further tighten cover (2) 1/4 turn.
6. Securely tighten cap (1) clockwise by hand. While holding cap (1) by hand so that cap (1) does not turn, securely tighten cover (2) by turning counterclockwise 5 to 10 ° by hand.
7. Take care never to allow water and/or contaminant to stay between cover (2) and body (4) (air breathing port).
8. Replace element (3) at the regular interval to keep hydraulic oil clean and to extend the service life of the hydraulic components.



MDAA-07-037



M1G6-07-001

## MAINTENANCE

### 7 Check Hoses and Lines

---daily

--- every 250 hours

#### **!** WARNING:


- Hydraulic oil and lubricant leaks can lead to fire that may result in serious injury. Check for missing or loose clamps, kinked hoses, lines or hoses that rub against each other, damaged oil cooler, and loose oil cooler flange bolts, for leaks.
- Escaping oil under pressure can penetrate the skin causing serious injury. To avoid this hazard, search for oil leaks with a piece of cardboard. Take care to protect hands and body from high-pressure fluids. If an accident occurs, see a doctor familiar with this type of injury immediately.
- Tighten, repair or replace any missing, loose or damaged clamps, hoses and lines.
- Do not bend or strike high-pressure lines.
- Never install bent or damaged hoses or lines.

According to the check points shown below, check hoses and lines for oil leaks and damage.


If any abnormality is found, replace or retighten as instructed in the table.



SA-031





SA-292



SA-044

#### Hose





Interval (hours)	Check Points	Abnormalities	Remedies
Daily	Hose covers	Leak (1)	Replace
	Hose ends	Leak (2)	Replace
	Fittings	Leak (3)	Retighten or replace hose or O-ring








## MAINTENANCE

Interval (hours)	Check Points	Abnormalities	Remedies
Every 250 hours	Hose covers	Damage or leak (4)	Replace
	Hose ends	Damage or leak (5)	Replace
	Hose covers	Exposed reinforcement (6)	Replace
	Hose covers	Crack or blister (7)	Replace
	Hose	Bend (8), Collapse (9)	Replace
	Hose ends and Fittings	Deformation or corrosion (10)	Replace




### Lines

Interval (hours)	Check Points	Abnormalities	Remedies
Daily	Contact surfaces of flange joints	Leak (11)	Replace
	Bolts	Loose or leak (11)	Retighten or replace O-ring
	Welded surfaces on flange joints	Leak (12)	Replace
Every 250 hours	Flange joint neck	Crack (13)	Replace
	Welded surfaces on flange joints	Crack (12)	Replace
	Clamps	Missing or deformation Loose bolts	Replace or retighten




### Hose and Lines

Interval (hours)	Check Points	Abnormalities	Remedies
Daily Check	Flexible master coupling	Leak (14)	Replace or retighten
	Constant torque clamp	Leak (15)	Replace or retighten



### Oil Cooler

Interval (hours)	Check Points	Abnormalities	Remedies
Every 250 hours	Oil Cooler	Leak (16)	Replace



## MAINTENANCE

### Service Recommendations for Hydraulic Fittings

Two hydraulic fitting designs are used on this machine.

- Flat Face O-ring Seal Fitting (ORS Fitting)  
O-ring (1) is used on the sealing surfaces of adapter (2) to prevent oil leakage.

#### Precautions for Use

1. Replace O-ring (1) with a new one when assembling fittings.
2. Check that O-ring (1) is properly fitted in O-ring groove (3). Tighten union (4).


Tightening union (4) with O-ring (1) out of the groove may damage O-ring (1) and cause an oil leak.

3. When assembling fittings, take care not to make a dent on O-ring groove (3) of adaptor (2) and sealing surface (6) on hose (5) or the side of the valve. Failure to do so may result in damage to O-ring (1) leading to an oil leak.
4. If oil leaks from a loose connection of union (4), do not tighten fitting. Open the connection, replace O-ring (1) with new one and check for correct O-ring position before tightening the connection.

#### Tightening Torque:

Tighten fittings to the torque values shown below.

		±10%			
Wrench size (mm)		27	32	36	41, 46
Tightening Torque:	N·m	95	140	180	210
	(kgf·m)	(9.5)	(14)	(18)	(21)
	(lbf·ft)	(70.1)	(103.3)	(132.8)	(154.9)



M104-07-033


## MAINTENANCE

- **Metal Face Seal Fittings**

Tight contact between metal flares on adaptor (7) and metal connector (8) of hose (5) prevents pressure oil leakage. This type of fitting is used on smaller diameter joints.

**Precautions for Use**

Connect or disconnect fittings with care not to damage seat surfaces (9 and 10).



M202-07-051

**Tightening Torque:**


Tighten fittings to the torque values shown below.

Wrench size (mm)		17	19	22	27
Torque	N·m	25	30	40	80
	(kgf·m)	(2.5)	(3)	(4)	(8)
	(lbf·ft)	(18.4)	(22.1)	(29.5)	(59.0)

- **Bent Tube**

Tighten bent tube (11) mounted on the signal control valve to the torque values shown below.

Wrench size (mm)		17, 19
Tightening torque	N·m	35
	(kgf·m)	(3.5)
	(lbf·ft)	(25.8)



M1U1-07-043

## MAINTENANCE

---

### E. Fuel System

 **CAUTION: Beware of fire. Fuel is flammable. Keep fuel away from fire hazards.**

#### **Recommended Fuel**

Use only super high quality or high quality DIESEL FUEL (JIS K-2204) (ASTM D-975) (EN-590). Kerosene must NOT be used.

Using bad quality fuel, drainage agent, fuel additives, gasoline, kerosene or alcohol refueled or mixed with specified fuel may deteriorate performance of fuel filters and cause sliding problem at lubricated contacts in the injector. It also affects the engine parts, leading to malfunction. Using fuel other than ultra low-sulfur or low-sulfur diesel fuel has adverse effects on the engine and the aftertreatment device, which may result in malfunction.

## MAINTENANCE

### Refueling


1. Park the machine on a firm, level surface. Lower the bucket to the ground. Check the fuel level with fuel gauge (1).

If the fuel level is low, stop the engine. Refuel by removing cap (2) on the fuel tank.

2. Remove cap (2) of filler port.

[Cap (2) unlock procedures]

- Release the key lock.
- Pull up handle (3) and turn handle (3) counterclockwise for releasing cap (2) lock.
- Remove cap (2).




MDC1-01-001

3. To avoid condensation, fill the tank at the end of each day's operation. Tank capacity is as follows.

Model	Tank Capacity
ZX130-6N, 160LC-6N, 180LC-6N	285 L (75.3 US gal)
ZX210-6N, 210LC-6N	400 L (105.7 US gal)
ZX250LC-6N, 300LC-6N	500 L (132.1 US gal)
ZX350LC-6N, 380LC-6N	630 L (166.4 US gal)

Do not fill the tank more than specified. Stop filling when a yellow mark on fuel level gauge (4) becomes visible.

Position the oil filler gun so that the gun will not obstruct the floating movement of level gauge (4).




MDCF-07-032

4. Just after fueling, install and lock filler cap (2) to prevent vandalism and loss.
5. Install cap (2) of filler port.


[Cap (2) lock procedures]

- Install cap (2).
- Turn handle (3) clockwise until cap (2) is locked, and push down handle (3).
- Lock the key.



### IMPORTANT:

- **Take care not to allow dirt and/or water to enter the fuel tank.**
- **Wipe off any spilled fuel.**
- **Never forget to remove filler cap (2) when refueling with the automatic fueling device and be sure to stop fueling when the yellow mark on the float of level gauge (4) becomes visible.**



M157-07-060

## MAINTENANCE

### 1 Drain Fuel Tank Sump

--- daily


1. Park the machine on a firm, level surface with the upperstructure rotated 90 ° for easier access.
2. Lower the bucket to the ground.
3. Turn the auto-idle switch off.



M104-07-117

**IMPORTANT: The turbocharger may be damaged if the engine is not properly shut down.**

4. Run the engine at slow idle speed without load for 5 minutes.
5. Turn the key switch OFF. Remove the key from the key switch.
6. Pull the pilot control shut-off lever to the LOCK position.
7. Place 0.5 liters or larger capacity container under drain hose (2) to collect the drained water.
8. Open drain valve (1) to drain water and/or sediment through drain hose (2).
9. After draining water, securely tighten drain valve (1).



MDAA-07-015

## MAINTENANCE

### 2 Drain Fuel Pre-Filter --- daily

**IMPORTANT: Drain fuel pre-filter daily before starting operation. The engine may be damaged if you do not drain fuel pre-filter daily.**


The fuel pre-filter has a water separator function. There is a float (8) inside the case which buoys when water accumulates. Check float (8) position daily. Be sure to drain the water accumulated in the pre-filter until float (8) goes to the bottom of pre-filter case.

#### Drain Procedures


1. Place 0.5 liter (0.5 US qt) or larger capacity container under drain hose (6).
2. Rotate drain plug (5) on the bottom of the pre-filter case counterclockwise. Drain the water accumulated in the pre-filter until float (8) goes to the bottom of pre-filter case. If it is difficult to drain, loosen plug (1) on the top of the pre-filter.
3. After draining water, securely tighten drain plug (5) and plug (1).
4. Start the engine. Check drain plug (5) and plug (1) for fuel leaks.

**IMPORTANT: After draining water mixed in fuel, bleed air from the fuel supply system.**

Wrench size: 14 mm




MDC1-07-092




ZX160LC-6N, 180LC-6N

MDC1-07-072




ZX130-6N

MDC1-07-081



ZX210-6N, 210LC-6N, 250LC-6N

MDC1-07-035



ZX300LC-6N, 350LC-6N, 380LC-6N

MDC1-07-036

## MAINTENANCE

### Bleed Air from the Fuel System

Air in the fuel system may make the engine hard to start or make it run irregularly.

After draining water and sediment from the fuel filter, replacing the fuel filter, cleaning the fuel solenoid pump strainer or running the fuel tank dry, be sure to bleed the air from the fuel system.


### Main Points to Bleed Air

This machine is equipped with a fuel solenoid pump.


**⚠ CAUTION: Fuel leaks may lead to fires.**

1. Check that fuel cock (1) on the bottom of the fuel tank is opened.
2. Turn the key switch ON and hold it in that position for approx. 3 minutes. Thereby, the fuel solenoid pump operates, starting to bleed air.
3. After the main filter is filled with fuel, hold the key switch in the ON position for 30 seconds.
4. Start the engine. Check the fuel supply system for fuel leaks.


**IMPORTANT: Even if air is not thoroughly bled, do not hold the key switch in the ON position for more than 5 minutes. In case air is not thoroughly bled, first return the key switch to the OFF position. After waiting for more than 30 seconds, turn the key switch ON again. Failure to do so may cause damage to the fuel solenoid pump and/or discharging the batteries.**



MDAA-07-007



MDC1-07-047



MDC1-07-046



## MAINTENANCE

---

### **If Air Mixed Downstream of Common Rail**

If air becomes mixed into the fuel system due to lack of fuel and the engine is difficult to start, release air by following the procedure below.

1. Following the above mentioned procedures, bleed enough air up to the engine supply pump entrance.
2. Operate starter motor for long cranking within 20 seconds. If engine falls to start, return key switch to OFF. Wait more than about 60 seconds, and then try again.

## MAINTENANCE

- 3** Replace Fuel Main Filter Element  
 --- every 1000 hours or when fuel filter restriction alarm is lit


**IMPORTANT:**

- Be sure to use only genuine Hitachi elements for the fuel main filter element and the pre-filter element. Failure to do so may deteriorate the engine performance and/or shorten the engine service life. Please be noted that all engine failures caused by using other manufacturers' elements are excluded from Hitachi Warranty Policy.
- Take care not to allow dirt and/or water to enter the fuel tank.


**Procedures:**

1. Close cock (1) on the bottom of the fuel tank.


(to next page)




ZX160LC-6N, 180LC-6N MDC1-07-072




Main Filter Pre-Filter MDC1-07-035  
 ZX210-6N, 210LC-6N, 250LC-6N



ZX130-6N MDC1-07-081



ZX300LC-6N, 350LC-6N, 380LC-6N MDC1-07-036



1 Closed Position MDC1-07-020


## MAINTENANCE

- Place 1 liter or larger capacity container under the drain hose.
- Rotate the bottom of filter element (2) counterclockwise by using a spanner to remove filter element (2) from head cover (3).
- Apply a thin layer of fuel to the cartridge gasket (O-ring).
- Install new filter element (2) on head cover (3) while rotating filter element (2) clockwise. Tightening torque:  $25 \pm 2 \text{ N}\cdot\text{m}$  ( $2.5 \pm 0.2 \text{ kgf}\cdot\text{m}$ ,  $18.4 \pm 1.5 \text{ lbf}\cdot\text{ft}$ )
- Open cock (1) on the bottom of the fuel tank.
- Bleed Air from the Fuel System


After replacing fuel filter element (2), bleed air from the fuel supply system.

(Refer to "**2** Bleed Air from the Fuel System".)


Wrench size: 24 mm



MDC1-07-046



MDC1-07-047



Open Position

MDAA-07-007

## MAINTENANCE

- 4** **Replace Fuel Pre-Filter Element**  
 --- every 1000 hours or when fuel filter restriction alarm is lif


**IMPORTANT:**

- **Be sure to use only genuine Hitachi elements. Failure to do so may deteriorate the engine performance and/or shorten the engine service life. Please be noted that all engine failures caused by using other manufacturers' elements are excluded from Hitachi Warranty Policy.**
- **Take care not to allow dirt and/or water to enter the fuel tank.**

**Procedures:**


1. Close cock (1) on the bottom of the fuel tank.

(to next page)




ZX160LC-6N, 180LC-6N

MDC1-07-072




ZX210-6N, 210LC-6N, 250LC-6N

MDC1-07-035




ZX300LC-6N, 350LC-6N, 380LC-6N

MDC1-07-036



ZX130-6N

MDC1-07-081



1 Close Position

MDC1-07-020

## MAINTENANCE


- Place 1 liter or larger capacity container under drain hose (3).
- Loosen air bleed plug (1) and drain plug (2). Drain fuel until fuel does not flow out of the filter.  
After draining fuel, remove drain plug (2) and replace O-ring.
- Remove the harness connected to sensor (7).

**IMPORTANT: The harness connector has a lock (8). Press lock (8) and disconnect the connector. If an attempt is made to disconnect the connector without releasing lock (8), it may damage the connector.**


- Remove transparent filter case (4) using the exclusive tool.
- When transparent filter case (4) is removed, the O-ring for transparent filter case (4) is exposed. Remove the element by hand.
- Remove filter cartridge (6) by using a band wrench.
- Install new cartridge (6). When the upper gasket of cartridge (6) contacts to the head, further tighten cartridge (6) for 3/4 turns by hand.
- Replace O-ring with new one and tighten transparent filter case (4) to  $10 \pm 1$  N·m using the special tool.
- Tighten air bleed plug (1) and drain plug (2).
- Reconnect the harness that was disconnected from sensor (7).

**IMPORTANT: Fit the parts together until lock (8) of the harness connector is locked in place.**


- Open cock (5) on the bottom of the fuel tank.
- Bleed Air from Fuel System  
After replacing the fuel filter element, bleed air from the fuel supply system.  
(Refer to "2 Bleed Air from the Hydraulic System".)  
Wrench size: 14 mm



MDC1-07-092



MDAA-07-007



MDAK-07-057

## MAINTENANCE

**5** Replace Fuel Solenoid Pump Filter Element  
--- every 1000 hours (Only Type A)


**IMPORTANT:**

- Type of the fuel solenoid pump differs according to the model of the base machine. Type B fuel solenoid pump is maintenance free. For type A fuel solenoid pump, replace the filter by following the procedure below.
- Be sure to use only genuine Hitachi filter elements for the fuel solenoid pump. Failure to do so may deteriorate the engine performance and/or shorten the engine service life. Please be noted that all engine failures caused by using other manufacturers' elements are excluded from Hitachi Warranty Policy.


**Procedures:**

1. Close cock (1) on the bottom of the fuel tank.

(to next page)




Type B




Type A

MDAK-07-061



Open Position


MDAA-07-007



ZX130-6N

Fuel Solenoid Pump Filter

MDC1-07-081




ZX160LC-6N, 180LC-6N

Fuel Solenoid Pump Filter

MDC1-07-072


Fuel Solenoid Pump Filter



ZX210-6N, 210LC-6N, 250LC-6N

MDC1-07-035

Fuel Solenoid Pump Filter



ZX300LC-6N, 350LC-6N, 380LC-6N

MDC1-07-036


## MAINTENANCE

2. Place 1 liter or larger capacity container under drain hose (3).
3. Loosen drain plug (2). Drain fuel until fuel does not flow out of the filter.
4. Remove transparent filter case (4) using the exclusive tool.
5. When transparent filter case (4) is removed, the O-ring for the element and transparent filter case (4) is exposed. Remove the element by hand.
6. Install a new element. Replace O-ring and tighten transparent filter case (4) to  $30 \pm 2$  N·m using the special tool.
7. Tighten drain plug (2).
8. Open cock (5) on the bottom of the fuel tank.
9. Bleed Air from Fuel System


After replacing the fuel filter element, bleed air from the fuel supply system.

(Refer to " **2** Bleed Air from the Hydraulic System".)

Wrench size: 14 mm



MDC1-07-019



Open Position

MDAA-07-007

## MAINTENANCE

- 6** Check Fuel Hoses  
 ---daily  
 --- every 250 hours

**⚠ CAUTION:** Fuel leaks can lead to fires that may result in serious injury.


- Escaping combustible fluid can cause fires. Check for kinked hoses, hoses that rub against each other, and any fuel leaks.
- Repair or replace any loose or damaged hoses.
- Never reinstall bent or damaged hoses.

According to the check points shown below, check hoses for oil leaks and damage.


If any abnormality is found, replace or retighten as instructed in the table.

Hose


Interval (hours)	Check Points	Abnormalities	Remedies
Daily	Hose ends	Leak (1)	Retighten or replace
	Hose covers	Wear, crack (2)	Replace
Every 250 hours	Hose covers	Crack (3)	Replace
	Hose ends	Crack (4)	Replace
	Hose	Bend (5), Collapse (6)	Replace
	Hose fittings	Corrosion (7)	Replace




M137-07-003



M137-07-004



M137-07-005



M137-07-006



## MAINTENANCE

### F. Air Cleaner

- 1** Clean and Replace Air Cleaner Element (Outer)  
Clean --- every 250 hours or when the restriction indicator comes ON  
Replace --- after cleaning 6 times or after one year

**CAUTION:** When using compressed air pressure (less than 0.69 MPa (7 kgf/cm<sup>2</sup>)), dust may scatter. Wear goggles or safety glasses, gloves and face shield.


**IMPORTANT:** Clean and replace the air cleaner element by following the procedure below. If the following procedures are not followed, dirt may enter into the system and an engine malfunction may result.

- Clean and replace the air cleaner element when the engine is stopped.
- Do not remove the inner element when cleaning the outer element.
- Replace the inner element when replacing the outer element. Do not reuse elements.
- Use clean and dried compressed air.
- When blowing compressed air, be sure to keep the air nozzle away from the element to avoid the filter paper being broken by the pressure of the air.

#### Clean or replace the outer element.


Stop the engine before servicing outer element (1).

1. Remove clamp (2) of the cover. Remove the cover. Remove any dirt from the case.
2. Remove outer element (1) by holding its edge and slowly shaking it left to right, up and down while twisting it. Do not scatter dirt while removing outer element (1).




MDAA-07-079

ZX130-6N, 160LC-6N, 180LC-6N




M1U1-07-080

ZX130-6N, 160LC-6N, 180LC-6N



M1U1-07-028

ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N, 350LC-6N, 380LC-6N



M1U1-07-027

ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N, 350LC-6N, 380LC-6N

## MAINTENANCE

3. At this time, do not remove the inner element.

**IMPORTANT: Do not hit or strike outer element (1) against another object to clean the element.**

4. Allow compressed air pressure [less than 0.69 MPa (7 kgf/cm<sup>2</sup>)] to blow out of the inside of outer element (1) to clean the element. After that, blow compressed air along the pleats, and then blow out from the inside. When blowing compressed air, be sure to keep the air nozzle 50 mm or away from the element.


5. After cleaning is complete, be sure to check outer element (1) for any damage such as holes or wear of filter paper. If any damage is found, replace the element with a new one.

6. Press outer element (1) into the air cleaner body straightly by hand. Ensure that outer element (1) is properly installed by pushing its bottom edge.

7. Install cover and tighten clamps (2).


8. In case the air filter restriction indicator lights soon after cleaning outer element (1) even if it has been cleaned less than 6 times, replace both outer and inner elements with new ones.

**IMPORTANT: Do not install outer element (1) and/or the cover forcibly when installing the clamps. Doing so may result in deformation of clamps (2), element, and/or cover.**




ZX130-6N, 160LC-6N, 180LC-6N

MDAA-07-079




ZX130-6N, 160LC-6N, 180LC-6N

M1U1-07-080




ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N, 350LC-6N, 380LC-6N

M1U1-07-027



MJAE-07-059



ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N, 350LC-6N, 380LC-6N

M1U1-07-028


## MAINTENANCE

---

### **2** Replace Air Cleaner Element (Inner) Replace --- When outer element is replaced

**IMPORTANT:** Do not clean and reuse the inner element.

1. After removing outer element (1), clean inside the air cleaner body (2) with a clean cloth before removing inner element (3).
2. Remove inner element (3). Replace it with new one.



M157-07-061

## MAINTENANCE

### G. Cooling System

#### Coolant

**IMPORTANT:** Use soft water as a coolant. Do not use strong acid or alkaline water. Use the coolant with genuine Hitachi Long-Life Coolant (LLC) mixed by 30 to 50 %.

If a coolant mixed with less than 30 % of Hitachi Long-Life Coolant is used, service life of the cooling parts may be shortened due to damage by freezing or corrosion of coolant system parts.

Recommended Products	Alternative Products
Hitachi Genuine Long-Life Coolant	Organic type corrosion inhibitor long life coolant

#### Antifreeze Mixing Ratio

Air Temperature		Mixing Ratio	ZX130-6N				ZX160LC-6N, 180LC-6N				ZX210-6N, 210LC-6N, 250LC-6N			
			Antifreeze		Soft water		Antifreeze		Soft water		Antifreeze		Soft water	
°C	°F	%	liters	US gal	liters	US gal	liters	US gal	liters	US gal	liters	US gal	liters	US gal
-1	30	30	6.3	1.7	14.7	3.9	7.2	1.9	16.8	4.4	8.4	2.2	19.6	5.2
-15	5	35	7.4	2.0	13.6	3.6	8.4	2.2	15.6	4.1	9.8	2.6	18.2	4.8
-20	-4	40	8.4	2.2	12.6	3.3	9.6	2.5	14.4	3.8	11.2	3.0	16.8	4.4
-25	-13	45	9.5	2.5	11.5	3.0	10.8	2.9	13.2	3.5	12.6	3.3	15.4	4.1
-30	-22	50	10.5	2.8	10.5	2.8	12.0	3.2	12.0	3.2	14.0	3.7	14.0	3.7

Air Temperature		Mixing Ratio	ZX300LC-6N				ZX350LC-6N, 380LC-6N			
			Antifreeze		Soft water		Antifreeze		Soft water	
°C	°F	%	liters	US gal	liters	US gal	liters	US gal	liters	US gal
-1	30	30	12.3	3.3	28.7	7.6	12.0	3.2	28.0	7.4
-15	5	35	14.4	3.8	26.6	7.0	14.0	3.7	26.0	6.9
-20	-4	40	16.4	4.3	24.6	6.5	16.0	4.2	24.0	6.3
-25	-13	45	18.5	4.9	22.6	6.0	18.0	4.8	22.0	5.8
-30	-22	50	20.5	5.4	20.5	5.4	20.0	5.3	20.0	5.3

#### Precautions for handling antifreeze

**⚠ CAUTION:** Antifreeze is poisonous.

- Antifreeze is poisonous; if ingested, it can cause serious injury or death. Induce vomiting and get emergency medical attention immediately.
- If antifreeze is accidentally splashed into eyes, flush with water for 10 to 15 minutes and get emergency medical attention.
- When storing antifreeze, be sure to keep it in a clearly marked container with a tight lid. Always keep antifreeze out of the reach of children.
- Pay attention to fire hazards. Antifreeze is specified as a dangerous substance in the fire protection law.
- When disposing of antifreeze, be sure to comply with all local regulations. When storing or disposing of antifreeze, be sure to comply with all local regulations.

# MAINTENANCE

## 1 Check Coolant Level


--- daily


1. Confirm that pilot control shut-off lever (1) is in the LOCK position.
2. Confirm that all control levers are placed in neutral.
3. Insert key switch (2). Turn it to ON position. Press and hold switch (3) with the engine stopped.

Coolant indicator (4) must be displayed in green.

**IMPORTANT:** Do not rely only on the monitor display for checking the machine conditions such as oil level; visually check them yourself as required.


**Always check the machine on a firm, level surface.**

 **NOTE:** If the security function is enabled, a password is required.




LOCK position


MDAA-01-295



MDC1-01-502



MDCD-01-026



MDC1-01-041

## MAINTENANCE


### --- Visual Inspection

The coolant level must be between the MAX COLD (3) and MIN COLD (4) marks on expansion tank (2).

If the coolant level is below the MIN COLD (4) mark, remove cap (1) from expansion tank (2) and refill coolant.


**⚠ CAUTION:** Do not remove cap (1) until the coolant temperature in the radiator becomes cool. Hot steam may spout out, possibly causing severe burns. After the coolant temperature has lowered, slowly loosen cap (1) to release the air pressure inside before removing cap (1).

If expansion tank (2) is empty, add coolant to the radiator and then to expansion tank (2).




ZX130-6N

MDC1-07-073




ZX160LC-6N, 180LC-6N

MDC1-07-074



MDC1-07-024

ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N, 350LC-6N, 380LC-6N



MDC1-07-097

## MAINTENANCE


### 2 Check and Adjust Fan Belt Tension --- every 250 hours (first time after 50 hours)

ZX130-6N, 160LC-6N, 180LC-6N

**IMPORTANT:** Loose fan belt may result in insufficient battery charging, engine overheating, as well as a rapid, abnormal belt wear. Belts that are too tight can damage both bearings as well as the belts.

#### Inspection

Check fan belt tension by depressing the midpoint between the fan pulley and the alternator pulley by your thumb with a depressing force of approximately 98 N (10 kgf, 22 lbf). Deflection must be within the value illustrated in the right. Visually check the belt for wear. Replace if necessary.



#### Adjust Drive Belt Tension

1. Loosen lock nut (1) and alternator lower mounting bolt (3).
2. Rotate tension adjust bolt (2) to adjust the belt tension.
3. After completing adjustment, tighten lock nut (1) and alternator lower mounting bolt (3) to specifications.

Standard Tightening Torque:

Nut : 25 N·m (2.5 kgf·m, 18 lbf·ft)  
Bolt : 52 N·m (5.2 kgf·m, 38 lbf·ft)

**IMPORTANT:** When a new belt is installed, be sure to re-adjust the tension after operating the engine for 3 to 5 minutes at slow idle speed to be sure that the new belt is seated correctly.

## MAINTENANCE

ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N, 350LC-6N,  
380LC-6N

**IMPORTANT:** Loose fan belt may result in insufficient battery charging, engine overheating, as well as premature belt wear. A belt that is too tight can damage both water pump/alternator bearings as well as the belt.


### Inspect

Check fan belt tension by depressing the midpoint between the fan pulley and the alternator pulley by your thumb with a depressing force of approximately 98 N (10 kgf, 22 lbf). Deflection must be within the value illustrated in the right. Visually check the belt for wear. Replace it if necessary.


### Adjust Drive Belt Tension

1. Loosen lock nut (1) at the top of alternator (3), and lock nut (4) at the bottom of alternator (3).
2. Adjust belt tension by moving alternator (3) forward or backward by using adjustment bolt (2).
3. Securely tighten lock nuts (1) and (4).


**IMPORTANT:** When a new belt is installed, be sure to re-adjust the tension after operating the engine for 3 to 5 minutes at slow idle speed to be sure that the new belt is seated correctly.



ZX210-6N, 210LC-6N, 250LC-6N M1GR-07-006



ZX300LC-6N, 350LC-6N, 380LC-6N M1HM-07-001





M197-07-072



## MAINTENANCE


### 3 Change Coolant --- twice a year (in spring and autumn)

 **NOTE:** When genuine Hitachi Long-Life Coolant is used, change interval is once every two years (in autumn every other year) or every 4000 hours whichever comes first.


 **CAUTION:** Do not loosen the cap on the expansion tank when coolant temperature in the radiator is high. Hot steam may spout out, possibly causing severe burns. Loosen the cap slowly to the stop. Release all pressure before removing the cap.

#### Procedure:

1. Park the machine on a solid level surface. Lower the bucket to the ground. Stop the engine.
2. Remove the under cover. Remove the cap from the expansion tank. Open drain cock (1) on the radiator to allow the coolant to drain completely. Remove impurities such as scale at the same time.
3. Close drain cock (1). Refill soft water containing fewer impurities or tap water and radiator cleaner agent. Close the cap on the expansion tank. Start the engine and run it at a speed slightly higher than slow idle; when the needle of the temperature gauge reaches the green zone, run the engine for about 10 or more minutes.
4. Stop the engine and open radiator drain cock (1). Flush out the cooling system with tap water, until draining water is clear. This helps remove rust and sediment.




M1U1-07-029




ZX130-6N

MDC1-07-073




ZX160LC-6N, 180LC-6N

MDC1-07-074



MDC1-07-024

ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N, 350LC-6N, 380LC-6N



MDC1-07-097

## MAINTENANCE

---

5. Close the radiator drain cock (1). Fill the expansion tank with tap water and LLC at the specified mixing ratio. When adding coolant, do so slowly to avoid mixing air bubbles in the system.


Fill coolant in the expansion tank until its level reaches the upper limit line.

**IMPORTANT: If coolant is filled above the upper limit line, air in the cooling system may not be bled from the expansion tank. Do not fill coolant above the upper limit line.**

6. Run the engine for several minutes to stabilize the coolant temperature, and then sufficiently bleed air from the cooling system.

Stop the engine. Ensure that coolant level is in between the upper and lower limit line.

Add coolant if necessary. Check the coolant level again (The coolant level should be between the upper and lower limit lines.)



M1U1-07-029





## MAINTENANCE

- 4** Clean Radiator/Oil Cooler/Inter Cooler Core  
 Outside --- every 500 hours  
 Inside --- once a year

**CAUTION:** Use reduced compressed air pressure (Less than 0.2 MPa, 2 kgf/cm<sup>2</sup>) for cleaning purposes. Wear personal protection equipment including eye protection.

**IMPORTANT:** If air with pressure of higher than 0.2 MPa (2 kgf/cm<sup>2</sup>) or tap water with high delivery pressure is used for cleaning, damage to the radiator/oil cooler/inter cooler fins may result.


The radiator, the oil cooler and the inter cooler are arranged in parallel.  
 If dirt or dust is accumulated on them, cooling system performance decreases. Clean the radiator/oil cooler/inter cooler cores with compressed air pressure (lower than 0.2 MPa (2 kgf/cm<sup>2</sup>)) or tap water. It will prevent a reduction in cooling system performance.



## MAINTENANCE

**⚠ WARNING:**

- Entanglement in moving parts can cause serious injury.
- Before servicing, stop the engine and the fan to prevent any accident.
- Never attempt to start the engine when the cover is open.
- In case tools or parts are dropped into the radiator/oil cooler/inter cooler core, remove them before starting the engine.




ZX130-6N

MDAA-07-087

### Cleaning

#### ZX210-6N, 210LC-6N, 250LC-6N

1. Loosen bolt (3) to open radiator cover (5).
2. Loosen bolt (4) to open cover (6) and perform cleaning.



ZX210-6N, 210LC-6N, 250LC-6N


MDC1-07-057

#### ZX130-6N, 160LC-6N, 180LC-6N, 300LC-6N, 350LC-6N, 380LC-6N

1. Loosen bolt (1) to open cover (2) and perform cleaning.

Take care not to break the fin during clean operation.


Close cover (2) and tighten bolt (1) after cleaning.



ZX160LC-6N, 180LC-6N, 300LC-6N

MDC1-07-026

**IMPORTANT:** When the machine is operated in dusty areas, check the cores periodically and replace if necessary.



ZX350LC-6N, 380LC-6N

MDC1-07-039

## MAINTENANCE

### 5 Clean Oil Cooler, Radiator and Inter Cooler Front Screen

--- every 500 hours

**IMPORTANT:** Check the screen daily and clean it if necessary when the machine is operated in dusty areas.

Pull the clip lever on the screen to remove the screen.

Insert the clip into the cover hole and turn over the clip lever to hold the screen.

The screen can not be held properly if the clip nut is too tight or loose. Adjust the tightening torque of the clip nut to hold the screen.

For rough indication of the tightening torque, refer to the below.

Tightening Torque: 0.5 N·m (0.05 kgf·m, 0.4 lbf·ft)

or

A: 2.5 to 3.5 mm

### 6 Clean Air Conditioner Condenser


--- every 500 hours

**IMPORTANT:** Check the screen daily and clean it if necessary when the machine is operated in dusty areas.

### 7 Clean Fuel Oil Cooler


--- every 500 hours

**IMPORTANT:** Check the screen daily and clean it if necessary when the machine is operated in dusty areas.




ZX130-6N

MDAA-07-089



Except ZX130-6N

MDAA-07-024




MDAA-07-025

## MAINTENANCE


- 8** Drain Intercooler (only ZX130-6N)  
--- after operation (If there is a risk of freezing)

### IMPORTANT:

- Condensate may accumulate inside the intercooler under some conditions of use.
  - Freezing of condensate may cause damage to the intercooler.
- If there is a risk of freezing, drain after operating the machine.
- The intercooler is very hot directly after operation, so allow it to cool before draining.
- Be careful handling the drained condensate as it may be hot.
- After draining, close drain valve securely. Failure to close the drain valve may cause abnormal output of the engine.



MDC1-07-117



Detail A: Closed Position  
(Other than when  
Draining)

Detail A: Open Position  
(When Draining)

MLAD-07-056

## MAINTENANCE

---

### H. Electrical System

 **WARNING:**

- **Improper radio communication equipment and associated parts, and/or improper installation of radio communication equipment affects the machine's electronic parts, causing involuntary movement of the machine.**
- **Improper installation of electrical equipment may cause machine failure and/or a fire on the machine.**
- **Be sure to consult your authorized dealer when installing radio communication equipment or additional electrical parts, or when replacing electrical parts.**

**IMPORTANT:** Never attempt to disassemble or modify the electrical/electronic components. If replacement or modification of such components is required, contact your authorized dealer.

## MAINTENANCE


### 1 Battery

#### WARNING:

- Battery gas can explode. Keep sparks and flames away from batteries.
- Do not leave cover (1) removed. Do not keep tools, metals or flammable materials around the battery or inside the battery room. If a metal tool is placed across the battery terminal and a vehicle component such as the engine block, sparks may be created, possibly resulting in fire and/or explosion.
- Do not continue to use or charge the battery when electrolyte level is lower than specified. Explosion of the battery may result.
- Charge the batteries in a well ventilated location.
- Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into the eyes. Wearing eye protection and rubber gloves.


#### IMPORTANT:

- If the battery is used with the electrolyte level lower than the specified lower level, the battery may deteriorate quickly.
- Do not refill electrolyte more than the specified upper level. Electrolyte may spill, damaging the painted surfaces and/or corroding other machine parts.


 NOTE: In case electrolyte is refilled more than the specified upper level line or beyond the bottom end of the sleeve, remove the excess electrolyte until the electrolyte level is down to the bottom end of the sleeve using a pipette. After neutralizing the removed electrolyte with sodium bicarbonate, flush it with plenty of water, otherwise, consult the battery manufacturer.




SA-032



SA-036



ZX130-6N, 160LC-6N, 180LC-6N MDAA-07-086



MU1-07-016  
ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N, 350LC-6N, 380LC-6N



## MAINTENANCE

---

### Precautions for Handling Batteries

- If electrolyte spills on your skin and/or clothes, immediately flush the skin and/or clothes with water and then wash further with soap.  
If splashed in eyes, flush with water for approximately 15 minutes and seek immediate medical attention.
- Avoid using fire hazards such as matches lighters and tobacco near the batteries. Do not allow sparks to fly.
- Check or service the battery only after stopping the engine, turning the key OFF and removing the battery caps.
- Contact with the battery just after operation may cause personal injury.  
Wait for the battery to cool.
- When the battery is recharged, inflammable hydrogen gas is created. Remove the battery from the base machine. Recharge the battery after removing the caps in a well ventilated area.
- When disconnecting the battery terminals, first disconnect the ground line [minus (-)] side terminal. When connecting the battery terminals, connect the ground line [minus (-)] side terminal last. If a piece of metal, such as a tool comes in contact with the battery plus (+) side terminal and the machine frame when both terminals are connected, the electrical system may short-circuit, possibly creating a dangerous situation.
- If a new battery is used along with an old battery, the service life of the new battery may be shortened. Replace two batteries at the same time.
- Loose terminal may allow sparks to fly. Securely tighten the terminals.

## MAINTENANCE

### Electrolyte Level Check --- monthly

Check the electrolyte level at least once a month.

1. Park the machine on level ground and stop the engine.
2. Check the electrolyte level.
  - 2.1 When checking the level from the battery side:

Clean around the level check lines with a wet towel. Do not use a dry towel. Static electricity may be developed, causing the battery gas to explode. Check if the electrolyte level is between U.L (Upper Level) and L.L (Lower Level).

In case the electrolyte level is lower than the middle level between the U.L and L.L, immediately refill with distilled water or commercial battery fluid.

After refilling, securely tighten the filler plug.

Be sure to refill with distilled water before recharging (operating the machine).

- 2.2 When impossible to check the level from the battery side or no level check mark is indicated on the side:

After removing the filler plug from the top of the battery, check the electrolyte level by viewing through the filler port. It is difficult to judge the accurate electrolyte level in this case. Therefore, when the electrolyte level is flush with the U.L, the level is judged to be proper. Then, referring to the illustrations on the right side, check the level. When the electrolyte level is lower than the bottom end of the sleeve, refill with distilled water or commercial battery fluid up to the bottom end of the sleeve.


After refilling, securely tighten the filler plug.

Be sure to refill with distilled water before recharging (operating the machine).

- 2.3 When an indicator is available to check the level, follow the checking results.



M146-07-109



M146-07-110

#### Proper



Since the electrolyte surface touches the bottom end of the sleeve, the electrolyte surface is raised due to surface tension so that the electrode ends are seen curved.

M146-07-111

#### Lower



When the electrolyte surface is lower than the bottom end of the sleeve, the electrode ends are seen straight.


M146-07-112

## MAINTENANCE

---

3. Always keep the area around the battery terminals clean to prevent battery discharge. Check terminals for loose and/or rust.

Check terminals for loose and/or rust. Coat terminals with grease or petroleum jelly to prevent corrosion build up.



M409-07-072

### Replace Battery

**IMPORTANT: Turn the battery disconnect switch to OFF before replacing the battery.**

This machine is equipped with two 12V batteries. Negative terminal is connected to the ground.

If one battery is damaged on the 24V system, replace the damaged battery with the same type of new battery. If a maintenance free battery is damaged, replace it with new maintenance free battery. Battery charger differs depending on the type of battery. If improper battery is connected, the battery becomes overloaded possibly resulting in malfunction.

## MAINTENANCE

### Check Electrolyte Specific Gravity

--- every one month

**⚠ WARNING:** Battery gas can explode. Keep sparks and flames away from batteries. Use a flashlight to check the battery electrolyte level.

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into the eyes.

Never check the battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Always remove the grounded (-) battery clamp first and replace it last.

Avoid hazard by:

1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Using proper booster battery starting procedures.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. If splashed in eyes, flush with water for 10 to 15 minutes. Get medical attention immediately.


If acid is swallowed:

1. Do not induce vomiting.
2. Drink large amounts of water or milk.
3. Get medical attention immediately.

**📝 NOTE:** Check the specific gravity of the electrolyte after it is cooled, not immediately after operation.

Check the electrolyte specific gravity in each battery cell.

The lowest limit of the specific gravity for the electrolyte varies depending on electrolyte temperature. The specific gravity should be kept within the range shown below. Charge the battery if the specific gravity is below the limit.



## MAINTENANCE

---

### **2** Replacing Fuses --- as necessary

If any electrical equipment fails to operate, first check the fuses. Fuse box is located behind the operator's seat.

 NOTE:

- *One spare fuse for each respective fuse capacity is provided in the fuse box.*
- *A fuse removing jig is provided in the fuse box.*

# MAINTENANCE


## Fuse Box

### A


10- CONTROLLER 5 A	20- OPT.3 (ALT) 5 A
9- BACKUP 10 A	19- HORN 10 A
8- ECU 30 A	18- IDLE STOP 5 A
7- START 5 A	17- POWER ON 5 A
6- OPT.2 (ALT) 20 A	16- GLOW RELAY 5 A
5- OPT.1 (ALT) 5 A	15- AUX 10 A
4- SOLENOID 20 A	14- MONITOR 5 A
3- HEATER 20 A	13- LIGHTER 10 A
2- WIPER 10 A	12- RADIO 5 A
1- LAMP 20 A	11- FUEL PUMP 5 A

### B


30- -	40- -
29- -	39- -
28- SENSOR_UNIT 10 A	38- -
27- AUX.3 5 A	37- -
26- QUICK HITCH 5 A	36- -
25- IMMOBI 5 A	35- DCU 20 A
24- 12VUNIT 10 A	34- AUX.2 10 A
23- CAB LAMP REAR 10 A	33- WARNING LAMP 10 A
22- CAB LAMP FRONT 10 A	32- CAB LAMP FRONT +2 10 A
21- SEAT HEATER 10 A	31- SEAT COMPR. 10 A



MDAA-01-297



M1GR-01-003



M1GR-01-003

## MAINTENANCE


---

- Fusible Link (Main Fuse)

In case the starter will not rotate even if the key switch is turned to the START position, fusible link may be the cause of the trouble. Remove the cover next to the battery to check the fusible link. Replace it if blown.

21- + Side (Red)  
45 A

22- - Side (Black)  
65 A



# MAINTENANCE

## I. Miscellaneous

### 1 Check and Replace Bucket Teeth --- daily

Check bucket teeth (1) for wear and looseness. Replace teeth (1) if tooth wear exceeds the designated service limit shown below.


Model	New	A mm (in)	
		Limit of Use	
ZX130-6N, 160LC-6N	166 (6.5")	85 (3.3")	
ZX180LC-6N, 210-6N, 210LC-6N	200 (7.9")	95 (3.7")	
ZX250LC-6N, 300LC-6N	230 (9.1")	110 (4.3")	
ZX350LC-6N, 380LC-6N	230 (9.1")	115 (4.5")	

### Replace


#### ⚠ CAUTION:

- Guard against injury from flying pieces of metal.
- Wear goggles or safety glasses, and safety equipment appropriate to the job.


1. Use hammer (2) and drift (3) to drive out lock pin (5). Take care not to damage lock rubber (4).
2. Check lock pin (5) and lock rubber (4). Short lock pins (5) and damaged lock rubber (4) must be replaced with new ones.



M104-07-056




M104-07-116



Flush one end of the locking pin to evaluate. In this instance, the locking pin is too short.

M104-07-118

M104-07-058



Crack on the rubber. The steel ball may come out.


The steel ball dents when pushing the ball.

M104-07-059




## MAINTENANCE

3. Clean shank (6) surface.
4. Install lock rubber (4) into shank (6) hole as shown.




M104-07-060

5. Position new tooth (1) over shank (6).



M104-07-061

6. Drive lock pin (5) fully into the hole as shown.



M104-07-062

## MAINTENANCE


### Check Bucket Teeth for H and Super V Type Bucket Teeth

--- daily

**CAUTION:** Guard against injury from flying pieces of metal. Wear goggles or safety glasses, and safety equipment appropriate to the job.

Check bucket teeth (1) for wear and looseness. When tooth (1) wear beyond the service limit, replace them.

ZX350LC-6N, 380LC-6N		Parts No.	New	Limit of Use
A (mm)	1.40 m <sup>3</sup> Hoe Bucket with Super V type Bucket Teeth	4400250	232 (9.1")	99 (3.9")
	Rock Bucket 1.38 m <sup>3</sup> 1.50 m <sup>3</sup>	4400253	229 (9.0")	112 (4.4")



M116-07-124


**IMPORTANT:** When tooth (1) is used in excess of the service limit, a hole will be made on tooth (1), which makes adapter (2) nose exposed and worn out, and will eventually break or let tooth (1) fall off.

#### Procedures:

Removing tooth (1)

1. Preparations for removing tooth point

Hit the left and right top ends and the left and right lugs of tooth (1) alternately with hammer to knock off pebbles, soil, etc., stuck in the gap between tooth (1) and adapter (2).



M116-07-125


## MAINTENANCE

---

### 2. Driving out lock pin (3)

Remove pebbles, dirt, etc., completely from the gap between lock pin (3) and adapter (2). Place pin-removing jig on the top end of lock pin (3) and hit it with hammer to remove lock pin (3).

When driving out lock pin (3), first hit with a shorter jig until top end of lock pin (3) comes to the upper end position of the lug of tooth (1), and then use the longer jig to remove lock pin (3).




M116-07-126

## MAINTENANCE

### 3. Removing the tooth

Turn tooth (1) to the left, twist and pull it toward you to remove it.

**IMPORTANT:** Check if lock pin (3) has cracks. If it has, replace lock pin (3) with new one. While the pin and plug can withstand several replacements of tooth (1) point, be sure to check whether they are usable or not when replacing tooth (1).



M113-07-078

### Mounting the tooth


#### 1. Mounting the tooth

Clean the top end of adapter (2) nose.

Also check that lock pin (3) has no cracks.

If pebbles, dirt, etc., are stuck to adapter (2) nose, tooth (1) will not insert properly and pin (3) cannot be driven in.

Insert tooth (1) slowly until tooth (1) comes to the end of adapter (2) nose while twisting and turning it to the right.




M113-07-080

#### 2. Inserting the lock pin


Insert lock pin (3) with take-up facing toward adapter (2) nose.

With tooth (1) fully inserted onto adapter (2), tap lock pin (3) into tooth (1) with a hammer until the top of lock pin (3) comes flat with the nose surface. (i.e. until the take-up on lock pin (3) fits into the grooves of tooth (1).)

(i.e. until the take-up on lock pin (3) fits into the grooves of tooth (1).)



M173-07-001




M116-07-128

## MAINTENANCE


---

### Other Precautions

1. Since rubber is susceptible to corrosion, do not use grease, oil and other oily materials when inserting lock pin (3).
2. If mounting welding-type nose and adapter (2) onto the bucket, lock pin (3) should be removed from the nose when preheating and welding. Otherwise lock rubber (4) will be spoiled.



M104-07-056



M116-07-124

## MAINTENANCE

### 2 Change Bucket

**CAUTION:** When driving the connecting pins in or out, guard against injury from flying pieces of metal or debris. Wear goggles or safety glasses, hard hat and face shield.



Before starting the conversion work, keep bystanders clear of the machine. Slowly move the front attachment. When using a signal person, coordinate hand signals before starting.

#### Removal

1. Place the bucket in a stable position.
2. Slide the O-rings out of the way, as shown.
3. Remove bucket pins A and B to separate the arm and bucket.

#### Installation

1. Clean the pins and pin bores. Apply sufficient grease to the pins and pin bores.
2. Place the new bucket in stable position as shown in the figure.
3. Fit the arm and alternate bucket. Be sure the bucket will not roll. Install bucket pins A and B.
4. Install the locking pins and snap rings on pins A and B.
5. Install O-rings to the specified positions.
6. Apply grease to each pin.
7. Start the engine and run it at slow idle. Slowly operate the bucket in both directions to check for any interference in bucket movement.



M104-07-063

## MAINTENANCE

### 3 Convert Bucket Connection Into Face Shovel

**CAUTION:** When driving the connecting pins in or out, guard against injury from flying pieces of metal or debris. Wear goggles or safety glasses, hard hat and face shield.





Converting the bucket connection allows you to use the machine as a face shovel. Before starting converting work, keep bystanders clear of the machine. Slowly move the front attachment. When using a signal person, coordinate hand signals before starting.

#### Procedure:

1. Place the bucket in a stable position.
2. Slide the O-rings out of the way, as shown.
3. Remove bucket pins A and B to separate the arm and bucket.

Clean the pins and pin bores. Apply sufficient grease to the pins and pin bores.

4. Turn the bucket 180°. Be sure the bucket will not roll.
5. Fit the arm and alternate bucket. Be sure the bucket will not roll. Install bucket pins A and B.
6. Install the locking pins and snap rings on pins A and B.
7. Install O-rings to the specified positions.
8. Apply grease to each pin.
9. Start the engine and run it at slow idle. Slowly operate the bucket in both directions to check for any interference in bucket movement.




M104-07-064


## MAINTENANCE

### 4 Adjust Bucket Linkage --- as required



The machine is provided with a bucket adjustment system to take up play in the linkage. When play in the linkage increases, remove and install shims (2) as follows:

1. Place the bucket in a stable position.
2. Run the engine at slow idle. With the bucket on the ground, slowly swing counterclockwise slightly until the top of the left bucket boss contacts the arm.
3. Stop the engine. Pull the pilot control shut-off lever to the LOCK position.
4. Slightly loosen 3 bolts (1) using a 22 mm wrench. Remove all shims (2) from clearance (c) between plate (3) and bucket. As shim (2) is a dual partitioning type, it can be easily removed by slightly loosening bolt (1) and inserting tip of a screw driver into the contact surface of left and right shims (2).
5. Push and hold bolts (1) to remove all clearance (a) between arm and boss (4). Holding boss (4) against arm increases clearance (b). Install as many shims (2) into clearance (b) as possible.
6. Install remaining shims (2) into clearance (c) and tighten bolts (1) to 140 N·m (14 kgf·m, 103 lbf·ft).

 **NOTE:** The total number of shims (2) used in clearance (b) and (c) are  $6 \times 2 = 12$ . Remaining shims (2) must be installed in clearance (c) to prevent arm end face or bolt damage. Replace boss (4) with new one if measurement (d) is 5 mm (0.2 in) or less.



M503-07-056



Section A

M1G6-07-010



## MAINTENANCE

### 5 Remove Travel Levers --- as required


Travel levers (3) and (4) may be removed if desired.

#### Procedure:

Remove bolts (1) and (2) to remove travel levers (3) and (4) from brackets.

 **NOTE:** Wrench size: 17 mm

*Tightening Torque: 50 N·m (5 kgf·m, 37 lbf·ft)*




M178-07-077


### 6 Check and Replace Seat Belt Check --- daily Replace --- every 3 years

Prior to operating the machine, thoroughly examine belt (5), buckle (6) and attaching hardware (7). If any item is damaged or materially worn, replace seat belt (5) or component before operating the machine.

We recommend that seat belt (5) should be replaced every 3 years regardless of its apparent condition.



M1U1-07-008




M1U1-07-009


## MAINTENANCE

### 7 Check Windshield Washer Fluid Level --- as required


Check fluid in windshield washer tank (1). If the fluid level is low, remove cap (2) and add fluid via the opening.



MDC1-07-027  
ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N



ZX350LC-6N, 380LC-6N MDC1-07-043




MDAA-07-091  
ZX130-6N, 160LC-6N, 180LC-6N

## MAINTENANCE

### 8 Check Track Sag --- every 50 hours

Swing the upperstructure 90 ° and lower the bucket to raise the track off the ground as shown. Measure distance (A) at the middle of the track frame from the bottom of the track frame to the back face of the track shoe.


Each time, be sure to place blocks under the machine frame to support the machine.



M104-07-067

**CAUTION:** To prevent accidents, care should be taken to ensure that hands, feet, and any body parts do not become entangled when working around the tracks.

Model	Appropriate sag A
ZX130-6N	250 to 280 mm (9.8 to 11.0 in)
ZX160LC-6N	285 to 320 mm (11.2 to 12.6 in)
ZX180LC-6N, 210-6N, 210LC-6N, 250LC-6N	300 to 335 mm (11.8 to 13.2 in)
ZX300LC-6N, 350LC-6N, 380LC-6N	340 to 380 mm (13.4 to 15.0 in)



M107-07-068

**NOTE:** Check track sag after thoroughly removing soil stuck on the track area by washing.

### Adjust Track Sag


1. If track sag is not within specifications, loosen or tighten the track following the procedures shown on the next page.
2. When adjusting track sag, lower the bucket to the ground to raise one track off the ground. Repeat this procedure to raise the other track. Each time, be sure to place blocks under the machine frame to support the machine. To prevent accidents, care should be taken to ensure that hands, feet, and any body parts do not become entangled when working around the tracks.
3. After adjusting both side track sags, rotate the tracks backward and forward to equalize both side track sags.
4. Recheck the track sag once more. Readjust as necessary.

## MAINTENANCE

### Loosen the Track

#### **CAUTION:**


- The pressure inside the cylinder of the track adjuster is high. Do not loosen valve (1) quickly or loosen it too much as valve (1) may fly out or high-pressure grease in the adjusting cylinder may spout out. Slowly loosen valve (1) while keeping body parts and face away from valve (1). Never loosen grease fitting (2).
- To prevent accidents, care should be taken to ensure that hands, feet, and any body parts do not become entangled when working around the tracks.



MDAA-07-013

#### **IMPORTANT:** When gravel or mud is packed between sprockets and track links, remove it before loosening.

1. To loosen the track, slowly turn valve (1) counterclockwise using long socket 24; grease will escape from the grease outlet.
2. Between 1 to 1.5 turns of valve (1) is sufficient to loosen the track. When valve (1) comes in contact with stop plate (3), do not loosen valve (1) further.
3. If grease does not drain smoothly, slowly rotate the raised track.
4. When proper track sag is obtained, turn valve (1) clockwise to the original condition.




MDAA-07-014

Tightening Torque: 90 N·m (9 kgf·m, 66 lbf·ft)

Do not remove valve stop plate (3). Do not loosen bolt (4) while adjusting the track sag.

#### **CAUTION:** Consult your authorized dealer if grease is not sufficiently drained.



MDAA-07-057


## MAINTENANCE

---

### Tighten the Track

**⚠ CAUTION:** It is abnormal if the track can not be adjusted. The strong force acts on the spring in track adjuster. Therefore, the grease in cylinder is highly pressurized. In such cases, **NEVER ATTEMPT TO DISASSEMBLE** the track or track adjuster, because of dangerous high-pressure grease inside the track adjuster. See your authorized dealer immediately.

To tighten the track, connect a grease gun to grease fitting (2) and add grease until the sag is within specifications.



MDAA-07-057

## MAINTENANCE

### 9 Clean and Replace Air Conditioner Filter

#### Clean Circulating/Fresh Air Filters


Circulating Air Filter --- every 500 hours

Fresh Air Filter --- every 500 hours

#### Replace Circulating/Fresh Air Filters

Circulating Air Filter --- After cleaning 6 times or so


Fresh Air Filter --- After cleaning 6 times or so



MDAA-07-040

#### Removing Fresh Air Filter


1. Insert the key into keyhole (2) on left cab side cover (1). Then, rotate the key counterclockwise to unlock the key. Open cover (1).
2. While pressing knobs (4) on both sides of fresh air filter (3) inward, horizontally remove fresh air filter (3).



MDC1-07-045

#### Removing Circulating Air Filter

1. Circulating air filter (5) is located under the rear tray.
2. Holding grips (6), pull them toward you to remove.



MDAA-07-039

## MAINTENANCE

---

 **WARNING:** When using compressed air pressure, wear safety glasses or goggles.

### Cleaning

Clean the circulating and fresh air filters.  
Clean both the circulating and fresh air filters by blowing compressed air or washing with water.

Washing procedure with water is as follows:

1. Use tap water.
2. Submerge the filters in water containing a neutral detergent for about 5 minutes.
3. Clean the filters with water again.
4. Dry the filters.

### Installation

When installing the cleaned circulating/fresh air filters or new filters, follow the reverse order of the Removing Filter procedures described on the previous page.

## MAINTENANCE

### 10 Check Air Conditioner --- every 250 hours

#### Check pipe connections for refrigerant gas leakage

If oil seepage is found around pipe connections, it indicates possible gas leakage.

#### Check Refrigerant

Start the engine and run it at approximately 1500 min<sup>-1</sup> (rpm). Turn the air conditioner switch to ON. Set the fan switch to HI and set the temperature control switch to the coolest position (18 °C on the monitor screen). Operate the air conditioner 2 to 3 minutes. Check if cool air comes out from the vent in the cab.

#### Type and amount of refrigerant when shipping the machine

Model	Type	Amount
ZX130-6N	HFC134a	0.75±0.05 kg
ZX160LC-6N, 180LC-6N		0.80±0.05 kg
ZX210-6N, 210LC-6N, 250LC-6N		0.85±0.05 kg
ZX300LC-6N, 350LC-6N, 380LC-6N		0.95±0.05 kg

#### Check the condenser

If the condenser fins become clogged with dirt or insects, the cooling effect will be decreased.

Be sure to keep it clean at all times. (Refer to "Clean Radiator/Oil Cooler/Inter Cooler Core" in Maintenance Chapter.)


#### Check compressor

After operating the air conditioner for 5 to 10 minutes, touch both the high pressure pipe and the low pressure pipe.

If normal, the high pressure side pipe will be hot, and the low pressure side cold.

#### Check mounting bolts for looseness

Confirm that the compressor mounting bolts and other mounting/fastening bolts are securely tightened.






# MAINTENANCE

## Inspect belt, check and adjust tension


--- every 250 hours

Visually check the compressor and fan belts for wear. Check fan belt tension by depressing the midpoint of the belt with the thumb. Deflection must be shown in the right figure with a depressing force of approximately 98 N (10 kgf). If cool air does not come out, or any other abnormalities are found in air conditioner system, see your authorized dealer for inspection.




ZX130-6N

M1U1-07-086




ZX160LC-6N, 180LC-6N

M1U1-07-086



ZX210-6N, 210LC-6N, 250LC-6N

M1GR-07-007



ZX300LC-6N, 350LC-6N, , 380LC-6N


MDAA-07-030

## MAINTENANCE

### Adjust Compressor Belt Tension

1. Loosen lock nut (2) of tension pulley (1).
2. Move tension pulley (1) by adjusting bolt (3) under tension pulley (1) until tension is correct.
3. Securely tighten bolt (2) of tension pulley (1).
4. After that tighten bolt (3).

**IMPORTANT:** When a new belt is installed, be sure to re-adjust the tension after operating the engine for 3 to 5 minutes at slow idle speed to be sure that the new belt is seated correctly.




Air Compressor Pulley

M1G6-07-013

### 11 Clean Cab Floor --- as required

**IMPORTANT:** When cleaning the cab floor with tap water, spray the floor only. Take care not to splash the surrounding area. Do not increase water spray speed by restricting the hose end, and do not use high pressure steam for cleaning. Be sure to completely remove any moisture from the surrounding area.

1. Park the machine on solid and level surface. Lower the bucket to the ground. Before cleaning, stop the engine.
2. Sweep the cab floor clean using a brush, and brush dust from the cab floor while spraying water.
3. When cleaning the floor mat, sweep dust (water) along the grooves on the floor mat.
4. When cleaning after removing the floor mat, sweep dust (water) through one cleaning hole.



MDAA-07-041

## MAINTENANCE

---

- 12** **Retighten Cylinder Head Bolt**  
--- as required

See your authorized dealer.

- 13** **Inspect and Adjust Valve Clearance**  
--- every 1000 hours

See your authorized dealer.

- 14** **Measure Engine Compression Pressure**  
--- every 1000 hours

See your authorized dealer.

- 15** **Check Starter and Alternator**  
--- every 1000 hours

See your authorized dealer.

- 16** **Check and Replace EGR Device**  
--- as required

See your authorized dealer.

- 17** **EGR Cooler Cleaning**  
--- every 4500 hours

See your authorized dealer.

- 18** **Check Turbo Charger**  
--- every 4500 hours

See your authorized dealer.

## MAINTENANCE

---

### **19** Check and Clean Injector --- as required

See your authorized dealer.

### **20** Check Gas Damper --- as required

**⚠ CAUTION:** The gas damper has been charged with high-pressure nitrogen gas. Inappropriate handling may cause explosion, possibly resulting in serious injury or death.

Gas dumpers are used in the overhead window of the cab. Contact your authorized dealer immediately in any of the following situations.

- The cover or window can not be opened with normal operating force.
- The cover or window can not maintain its open position.
- Oil or gas leak is found.

### **21** Tightening and Retightening Torque of Nuts and Bolts --- every 250 hours (first time after 50 hours)

Tighten or retighten nuts and bolts used on this machine in accordance with the torque values shown in the following table. Bolts and nuts should be replaced with those of the same or higher grade.

Check tightness after the first 50 hours then every 250 hours. For tightening nuts and bolts other than specified in the table below, refer to the Tightening Torque Chart at the end of this section.

## MAINTENANCE

### ZX130-6N

No.	Descriptions	Bolt Dia	Quantity	Wrench size	Torque			
					N·m	(kgf·m)	(lbf·ft)	
1.	Engine cushion rubber mounting bolt and nut	16	4	24	235	(23.5)	(175)	
2.	Engine bracket mounting bolt (Pump side)	12	8	19	110	11	(81)	
3.	Hydraulic oil tank mounting bolt	16	4	24	270	(27)	(200)	
4.	Fuel tank mounting bolt	16	6	24	270	(27)	(200)	
5.	Radiator mounting bolt (Upper side)	–	–	–	–	–	–	
	Radiator mounting bolt (Lower side)	12	3	19	90	(9)	(66)	
6.	Pump mounting bolt	12	10	19	110	(11)	(81)	
7.	Control valve mounting bolt	16	4	24	210	(21)	(155)	
	Control valve bracket mounting bolt	16	4	24	270	(27)	(200)	
8.	Swing device mounting bolt	20	10	30	500	(50)	(370)	
9.	Swing motor mounting bolt (Hexagon wrench)	10	7	8	64	(6.4)	(47)	
10.	ORS fitting for hydraulic hose and piping	–	–	17	25	(2.5)	(18.5)	
		–	–	19	30	(3)	(22)	
		–	–	22	40	(4)	(29.5)	
		–	–	27	80	(8)	(59)	
		–	–	27	95	(9.5)	(70)	
		–	–	32	140	(14)	(103)	
		–	–	36	180	(18)	(133)	
11.	Hycolin® tube mounting nut	–	–	17	35	(3.5)	(26)	
		–	–	19	35	(3.5)	(26)	
12.	Battery mounting nut	10	4	17	50	(5)	(37)	
13.	Cab mounting nut	16	4	24	210	(21)	(155)	
	Cab mounting anchor bolt	22	1	32	550	(55)	(410)	
	Cab cushion rubber mounting bolt	12	8	19	110	(11)	(81)	
14.	Cover mounting bolt	6	–	10	10	(1)	(7.4)	
		8	–	13	20	(2)	(15)	
		10	–	17	50	(5)	(37)	
		12	–	19	90	(9)	(66)	
15.	Constant torque clamp of low pressure piping	–	8	8	14	(1.4)	(10.5)	
	Flexible master coupling of low pressure piping	–	–	13	10.3 to 12.4	(1.0 to 1.2)	(7.6 to 9.1)	
				11	6	(0.6)	(4.4)	
	Jubilee® clamp of low pressure piping	–	–	7	6	(0.6)	(4.4)	
				8	6	(0.6)	(4.4)	
T-bolt clamp of low pressure piping	–	4	10	6	(0.6)	(4.4)		
16.	Swing bearing mounting bolt	(Upperstructure)	18	30	27	390	(39)	(290)
		(Undercarriage)	16	36	24	270	(27)	(200)
17.	Travel device mounting bolt	16	28	24	310	(31)	(230)	
	Travel reduction gear cover mounting bolt	14	8	22	175	(17.5)	(129)	
	Sprocket mounting bolt	16	32	24	265	(26.5)	(195)	
18.	Upper roller mounting bolt	12	8	19	98	(9.8)	(72)	
19.	Lower roller mounting bolt	16	56	24	310	(31)	(230)	
20.	Track shoe mounting bolt	16	352	24	410	(41)	(302)	
21.	Track guard mounting bolt	–	–	–	–	–	–	
23.	Platform handrail mounting bolt	12	4	19	130	(13)	(96)	
24.	Body top handrail mounting bolt	12	8	19	130	(13)	(96)	
25.	Aftertreatment device mounting bolt	Back plate	12	4	19	90	(9)	(66)
		Base plate	12	4	19	110	(11)	(81)
26.	DEF/AdBlue® tank bracket mounting bolt	10	6	17	50	(5)	(37)	
29.	Cab top handrail mounting bolt	16	2	24	270	(27)	(200)	

## MAINTENANCE

### ZX160LC-6N, 180LC-6N

No.	Descriptions	Bolt Dia	Quantity	Wrench size	Torque			
					N·m	(kgf·m)	(lbf·ft)	
1.	Engine cushion rubber mounting bolt and nut	Pump side	18	4	27	400	(40)	(300)
		Pan side	16	2	24	235	(23.5)	(173)
2.	Engine bracket mounting bolt (Pump side)	14	12	19	180	(18)	(133)	
3.	Hydraulic oil tank mounting bolt	18	4	27	400	(40)	(300)	
4.	Fuel tank mounting bolt	16	6	24	270	(27)	(200)	
5.	Radiator mounting bolt (Upper side)	10	8	17	50	(5)	(37)	
	Radiator mounting bolt (Lower side)	16	3	24	270	(27)	(200)	
6.	Pump mounting bolt	12	10	19	110	(11)	(81)	
7.	Control valve mounting bolt	16	4	24	210	(21)	(155)	
	Control valve bracket mounting bolt	16	4	24	270	(27)	(200)	
8.	Swing device mounting bolt	20	14	30	500	(50)	(370)	
9.	Swing motor mounting bolt (Hexagon wrench)	12	8	10	90	(9)	(66)	
10.	ORS fitting for hydraulic hose and piping	–	–	17	25	(2.5)	(18.5)	
		–	–	19	30	(3)	(22)	
		–	–	22	40	(4)	(29.5)	
		–	–	27	95	(9.5)	(70)	
		–	–	32	140	(14)	(103)	
		–	–	36	180	(18)	(133)	
–	–	41	210	(21)	(155)			
11.	Hycolin® tube mounting nut	–	–	17	35	(3.5)	(26)	
12.	Battery mounting nut	10	4	17	50	(5)	(37)	
13.	Cab mounting nut	16	4	24	210	(21)	(155)	
	Cab mounting anchor bolt	22	1	32	550	(55)	(410)	
	Cab cushion rubber mounting bolt	12	8	19	110	(11)	(81)	
14.	Cover mounting bolt	6	–	10	10	(1)	(7.4)	
		8	–	13	20	(2)	(15)	
		10	–	17	50	(5)	(37)	
		12	–	19	90	(9)	(66)	
15.	Constant torque clamp of low pressure piping	–	8	8	14	(1.4)	(10.5)	
	Flexible master coupling of low pressure piping	–	–	13	10.3 to 12.4	(1.0 to 1.2)	(7.6 to 9.1)	
		–	–	11	6	(0.6)	(4.4)	
	Jubilee® clamp of low pressure piping	–	–	7	6	(0.6)	(4.4)	
		–	–	8	6	(0.6)	(4.4)	
–	T-bolt clamp of low pressure piping	–	8	10	6	(0.6)	(4.4)	
16.	Swing bearing mounting bolt	(Upperstructure)	20	37	32	510	(51)	(376)
		(Undercarriage)	20	36	32	500	(50)	(370)
17.	Travel device mounting bolt	20	28	30	630	(63)	(460)	
	Travel reduction gear cover mounting bolt	14	12	22	180	(18)	(133)	
	Sprocket mounting bolt	20	32	30	485	(48.5)	(358)	
18.	Upper roller mounting bolt	16	16	24	270	(27)	(200)	
19.	Lower roller mounting bolt	18	56	27	460	(46)	(340)	
20.	Track shoe mounting bolt	ZX160LC-6N	20	344	27	804	(80.4)	(590)
		ZX180LC-6N	20	368	27	804	(80.4)	(590)
21.	Track guard mounting bolt	18	8	27	500	(50)	(370)	
23.	Platform handrail mounting bolt	12	4	19	130	(13)	(96)	
24.	Body top handrail mounting bolt	12	8	19	130	(13)	(96)	
25.	Aftertreatment device mounting bolt	Back plate	12	4	19	90	(9)	(66)
		Base plate	12	4	19	110	(11)	(81)
26.	DEF/AdBlue® tank bracket mounting bolt	10	6	17	50	(5)	(37)	
29.	Cab top handrail mounting bolt	16	2	24	270	(27)	(200)	

## MAINTENANCE

### ZX210-6N, 210LC-6N, 250LC-6N

No.	Descriptions	Bolt Dia	Quantity	Wrench size	Torque			
					N·m	(kgf·m)	(lbf·ft)	
1.	Engine cushion rubber mounting bolt and nut	22	4	32	550	(55)	(410)	
2.	Engine bracket mounting bolt (Pump side)	16	12	24	270	(27)	(200)	
	Engine bracket mounting bolt (Fan side)	10	8	17	65	(6.5)	(48)	
3.	Hydraulic oil tank mounting bolt	18	4	27	400	(40)	(300)	
4.	Fuel tank mounting bolt	16	6	24	270	(27)	(200)	
5.	Radiator mounting bolt (Upper side)	10	6	17	50	(5)	(37)	
	Radiator mounting bolt (Lower side)	16	3	24	270	(27)	(200)	
6.	Pump mounting bolt	12	12	19	110	(11)	(81)	
7.	Control valve mounting bolt	16	4	24	270	(27)	(200)	
	Control valve bracket mounting bolt	16	4	24	270	(27)	(200)	
8.	Swing device mounting bolt	22	14	32	650	(65)	(480)	
9.	Swing motor mounting bolt (Hexagon wrench)	12	8	10	90	(9)	(66)	
10.	ORS fitting for hydraulic hose and piping	—	—	17	25	(2.5)	(18.5)	
		—	—	19	30	(3)	(22)	
		—	—	22	40	(4)	(29.5)	
		—	—	27	95	(9.5)	(70)	
		—	—	32	140	(14)	(103)	
		—	—	36	180	(18)	(133)	
—	—	41	210	(21)	(155)			
11.	Hycolin® tube mounting nut	—	—	17	35	(3.5)	(26)	
12.	Battery mounting nut	10	4	17	50	(5)	(37)	
13.	Cab mounting nut	16	4	24	210	(21)	(155)	
	Cab mounting anchor bolt	22	2	32	550	(55)	(410)	
	Cab cushion rubber mounting bolt	12	8	19	110	(11)	(81)	
14.	Cover mounting bolt	6	—	10	10	(1)	(7.4)	
		8	—	13	20	(2)	(15)	
		10	—	17	50	(5)	(37)	
15.	Constant torque clamp of low pressure piping	—	8	10	14	(1.4)	(10.5)	
	Flexible master coupling of low pressure piping	—	—	13	10.3 to 12.4	(1.0 to 1.2)	(7.6 to 9.1)	
	Jubilee® clamp of low pressure piping	—	—	7	6	(0.6)	(4.4)	
		—	—	8	6	(0.6)	(4.4)	
	T-bolt clamp of low pressure piping	—	8	10	6	(0.6)	(4.4)	
16.	Swing bearing mounting bolt	(Upperstructure)	22	36	32	640	(64)	(470)
		(Undercarriage)	22	36	32	715	(72)	(530)
17.	Travel device mounting bolt	20	32	30	630	(63)	(460)	
	Travel reduction gear cover mounting bolt	14	12	22	180	(18)	(133)	
	Sprocket mounting bolt	20	40	30	485	(49)	(360)	
18.	Upper roller mounting bolt	16	16	24	270	(27)	(200)	
19.	Lower roller mounting bolt	18	72	27	460	(46)	(340)	
20.	Track shoe mounting bolt	20	408	27	860	(86)	(630)	
21.	Track guard mounting bolt	18	8	27	500	(50)	(370)	
22.	Full track guard	Mounting bolt	18	32	27	460	(46)	(340)
		Through bolt	18	20	27	460	(46)	(340)
23.	Platform handrail mounting bolt	12	4	19	110	(11)	(81)	
24.	Body top handrail mounting bolt	12	12	19	110	(11)	(81)	
25.	Aftertreatment device mounting bolt	12	8	19	90	(9)	(66)	
26.	DEF/AdBlue® tank bracket mounting bolt	10	6	17	50	(5)	(37)	

## MAINTENANCE

### ZX300LC-6N

No.	Descriptions	Bolt Dia	Quantity	Wrench size	Torque			
					N·m	(kgf·m)	(lbf·ft)	
1.	Engine cushion rubber mounting bolt and nut	20	4	30	550	(55)	(410)	
2.	Engine bracket mounting bolt (Pump side)	12	12	19	110	(11)	(81)	
	Engine bracket mounting bolt (Fan side)	10	12	17	65	(6.5)	(48)	
3.	Hydraulic oil tank mounting bolt	18	4	27	400	(40)	(300)	
4.	Fuel tank mounting bolt	16	6	24	270	(27)	(200)	
5.	Radiator mounting bolt (Left and right)	10	6	17	50	(5)	(37)	
	Radiator mounting bolt (Lower side)	16	5	24	270	(27)	(200)	
6.	Pump mounting bolt	12	13	19	110	(11)	(81)	
7.	Control valve mounting bolt	18	4	27	300	(30)	(220)	
	Control valve bracket mounting bolt	16	4	24	270	(27)	(200)	
8.	Swing device mounting bolt	22	14	32	650	(65)	(480)	
9.	Swing motor mounting bolt (Hexagon wrench)	12	8	10	90	(9)	(66)	
10.	ORS fitting for hydraulic hose and piping	—	—	17	25	(2.5)	(18.5)	
		—	—	19	30	(3)	(22)	
		—	—	22	40	(4)	(29.5)	
		—	—	27	95	(9.5)	(70)	
		—	—	32	140	(14)	(103)	
		—	—	36	180	(18)	(133)	
		—	—	41	210	(21)	(155)	
—	—	50	260	(26)	(190)			
11.	Hycolin® tube mounting nut	—	—	17	35	(3.5)	(26)	
12.	Battery mounting nut	10	8	17	25	(2.5)	(18.5)	
13.	Cab mounting nut	16	4	24	210	(21)	(155)	
	Cab mounting anchor bolt	22	2	32	550	(55)	(410)	
	Cab cushion rubber mounting bolt	12	8	19	110	(11)	(81)	
14.	Cover mounting bolt	8	—	13	20	(2)	(15)	
		10	—	17	50	(5)	(37)	
		12	—	19	90	(9)	(66)	
15.	Constant torque clamp of low pressure piping	—	8	10	14	(1.4)	(10.5)	
	Flexible master coupling of low pressure piping	—	1 pair	17	20.5 to 22.6	(2.1 to 2.3)	(15.0 to 16.5)	
	Jubilee® clamp of low pressure piping	Air cleaner I/C pipe	—	—	7	6	(0.6)	(4.4)
		For the radiator	—	—	8	6	(0.6)	(4.4)
		For the radiator (engine side)	—	—	8	6.9	(0.7)	(5.1)
T-bolt clamp of low pressure piping	—	8	11	10	(1.0)	(7.4)		
16.	Swing bearing mounting bolt	(Upperstructure)	22	36	32	640	(64)	(470)
		(Undercarriage)	22	36	32	640	(64)	(470)
17.	Travel device mounting bolt	20	40	30	630	(63)	(460)	
	Travel reduction gear cover mounting bolt	14	12	22	180	(18)	(133)	
	Sprocket mounting bolt	20	48	30	550	(55)	(410)	
18.	Upper roller mounting bolt	18	16	27	460	(46)	(340)	
19.	Lower roller mounting bolt	22	64	32	840	(84)	(620)	
20.	Track shoe mounting bolt	22	384	32	1128	(113)	(830)	
21.	Track guard mounting bolt	22	24	32	750	(75)	(550)	
22.	Full track guard	Mounting bolt	22	28	32	750	(75)	(550)
		Through bolt	20	18	30	500	(50)	(370)
23.	Platform handrail mounting bolt	12	4	19	110	(11)	(81)	
24.	Body top handrail mounting bolt	12	12	19	110	(11)	(81)	
25.	Aftertreatment device mounting bolt	12	18	19	90	(9)	(66)	
26.	DEF/AdBlue® tank bracket mounting bolt	10	6	17	50	(5)	(37)	












## MAINTENANCE

### ZX350LC-6N, 380LC-6N

No.	Descriptions	Bolt Dia	Quantity	Wrench size	Torque			
					N-m	(kgf-m)	(lbf-ft)	
1.	Engine cushion rubber mounting bolt and nut	20	4	30	550	(55)	(410)	
2.	Engine bracket mounting bolt (Pump side)	12	12	19	110	(11)	(81)	
	Engine bracket mounting bolt (Fan side)	10	12	17	65	(6.5)	(48)	
3.	Hydraulic oil tank mounting bolt	18	4	27	400	(40)	(300)	
4.	Fuel tank mounting bolt	16	6	24	270	(27)	(200)	
5.	Radiator mounting bolt (Left and right)	10	6	17	50	(5)	(37)	
	Radiator mounting bolt (Lower side)	16	3	24	270	(27)	(200)	
6.	Pump mounting bolt	12	13	19	110	(11)	(81)	
7.	Control valve mounting bolt	18	4	27	300	(30)	(220)	
	Control valve bracket mounting bolt	16	4	24	270	(27)	(200)	
8.	Swing device mounting bolt	22	14	32	650	(65)	(480)	
9.	Swing motor mounting bolt (Hexagon wrench)	12	8	12	90	(9)	(66)	
10.	ORS fitting for hydraulic hose and piping	–	–	17	25	(2.5)	(18.5)	
		–	–	19	30	(3)	(22)	
		–	–	22	40	(4)	(29.5)	
		–	–	27	95	(9.5)	(70)	
		–	–	32	140	(14)	(103)	
		–	–	36	180	(18)	(133)	
		–	–	41	210	(21)	(155)	
–	–	50	260	(26)	(190)			
11.	Hycolin® tube mounting nut	–	–	17	35	(3.5)	(26)	
12.	Battery mounting nut	10	8	17	25	(2.5)	(18.5)	
13.	Cab mounting nut	16	4	24	210	(21)	(155)	
	Cab mounting anchor bolt	22	2	32	550	(55)	(410)	
	Cab cushion rubber mounting bolt	12	8	19	110	(11)	(81)	
14.	Cover mounting bolt	8	–	13	20	(2)	(15)	
		10	–	17	50	(5)	(37)	
		12	–	19	90	(9)	(66)	
15.	Constant torque clamp of low pressure piping	–	8	10	14	(1.4)	(10.5)	
	Flexible master coupling of low pressure piping	–	1 pair	17	20.5 to 22.6	(2.1 to 2.3)	(15 to 16.5)	
	Jubilee® clamp of low pressure piping	Air cleaner I/C pipe	–	–	7	6	(0.6)	(4.4)
		For the radiator	–	–	8	6	(0.6)	(4.4)
		For the radiator (engine side)	–	–	8	6.9	(0.7)	(5.1)
T-bolt clamp of low pressure piping	–	8	11	10	(1.0)	(7.4)		
16.	Swing bearing mounting bolt	(Upperstructure)	27	36	41	1230	(123)	(910)
		(Undercarriage)	27	36	41	1230	(123)	(910)
17.	Travel device mounting bolt	20	48	30	630	(63)	(460)	
	Travel reduction gear cover mounting bolt	14	12	22	180	(18)	(133)	
	Sprocket mounting bolt	22	44	32	680	(68)	(500)	
18.	Upper roller mounting bolt	18	16	27	460	(46)	(340)	
19.	Lower roller mounting bolt	22	64	32	840	(84)	(620)	
20.	Track shoe mounting bolt	22	384	32	1128	(113)	(830)	
21.	Track guard mounting bolt	22	24	32	750	(75)	(550)	
22.	Full track guard	Mounting bolt	22	28	32	750	(75)	(550)
		Through bolt	20	18	30	500	(50)	(370)
23.	Platform handrail mounting bolt	12	4	19	110	(11)	(81)	
24.	Body top handrail mounting bolt	12	12	19	110	(11)	(81)	
25.	Aftertreatment device mounting bolt	12	18	19	90	(9)	(66)	
26.	DEF/AdBlue® tank bracket mounting bolt	10	6	17	50	(5.0)	(37)	
27.	Oil cooler mounting bolt	Left and right side	10	6	17	50	(5.0)	(37)
		Lower side	16	3	24	270	(27)	(200)
28.	Oil cooler fan frame mounting bolt	16	2	24	270	(27)	(200)	
	Oil cooler fan motor mounting bolt	14	2	22	180	(18)	(133)	

## MAINTENANCE

### Tightening Torque Chart

Bolt Dia. mm	Hexagon Wrench									Socket Bolt				
	  			  			  			Wrench size mm	Socket Bolt			Wrench size mm
	N·m	(kgf·m)	(lbf·ft)	N·m	(kgf·m)	(lbf·ft)	N·m	(kgf·m)	(lbf·ft)		N·m	(kgf·m)	(lbf·ft)	
6							3.3 to 4.2	(0.3 to 0.4)	(2.4 to 3.1)	10				5
8	30	(3.0)	(22)	20	(2.0)	(15)	10	(1.0)	(7.4)	13	20	(2.0)	(15)	6
10	65	(6.5)	(48)	50	(5.0)	(37)	20	(2.0)	(15)	17	50	(5.0)	(37)	8
12	110	(11)	(81)	90	(9)	(66)	35	(3.5)	(26)	19	90	(9)	(66)	10
14	180	(18)	(133)	140	(14)	(103)	55	(5.5)	(41)	22	140	(14)	(103)	12
16	270	(27)	(200)	210	(21)	(155)	80	(8.0)	(59)	24	210	(21)	(155)	14
18	400	(40)	(300)	300	(30)	(220)	120	(12)	(89)	27	300	(30)	(220)	14
20	550	(55)	(410)	400	(40)	(300)	170	(17)	(125)	30	400	(40)	(300)	17
22	750	(75)	(550)	550	(55)	(410)	220	(22)	(162)	32				
24	950	(95)	(700)	700	(70)	(520)	280	(28)	(205)	36				
27	1400	(140)	(1030)	1050	(105)	(770)	400	(40)	(300)	41				
30	1950	(195)	(1440)	1450	(145)	(1070)	550	(55)	(410)	46				
33	2600	(260)	(1920)	1950	(195)	(1440)	750	(75)	(550)	50				
36	3200	(320)	(2360)	2450	(245)	(1810)	950	(95)	(700)	55				


**⚠ CAUTION:** If fixing bolts for counterweight are loosened, consult your nearest authorized dealer.

#### IMPORTANT:

- Apply lubricant (e. g. white zinc B solved into spindle oil) to bolts and nuts to stabilize their friction coefficient.
- Remove soil, dust, and/or dirt from the nut and bolt thread surfaces before tightening.
- Tighten nuts and bolts to specifications. If tightened with excessively low or high torque, missing or breakage of nuts and/or bolts may result.


# MAINTENANCE

## 1. Engine cushion rubber mounting bolts and nuts



Pump Side


M1U1-07-040



Fan Side


M1U1-07-034

## 2. Engine bracket mounting bolts



Pump Side

M1U1-07-040




Fan Side

M1U1-07-034

## MAINTENANCE


---

### 3. Hydraulic oil tank mounting bolts



MDAA-07-026


### 4. Fuel tank mounting bolts




MDAA-07-026

# MAINTENANCE

## 5. Radiator mounting bolts




ZX160LC-6N (Left and right) MDC1-07-085




ZX130-6N

MDAA-07-093




ZX160LC-6N, 180LC-6N

MDAA-07-088




ZX350LC-6N, 380LC-6N (Left and right)

MDC1-07-048




ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N (Left and right)

MDC1-07-027



ZX350LC-6N, 380LC-6N (Lower side)

MDC1-07-041




ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N (Lower side)

MDAA-07-101


# MAINTENANCE

## 6. Pump mounting bolts



ZX130-6N


MDC1-07-082



MDAA-07-110


Except ZX130-6N

## 7. Control valve mounting bolts



M1U1-07-025


## Control valve bracket mounting bolts



M1U1-07-041


## MAINTENANCE

### 8. Swing device mounting bolts



ZX130-6N


M175-00-002



Except ZX130-6N


M1U1-07-053

### 9. Swing motor mounting bolts



ZX130-6N


M175-00-002



Except ZX130-6N

M1U1-07-053


### 10. ORS fittings for hydraulic hoses and piping



M104-07-079


# MAINTENANCE

## 11. Hycolin® tube mounting nuts



ZX130-6N


M1U1-07-111



Except ZX130-6N


M1U1-07-035

## 12. Battery mounting nuts



ZX130-6N

MDAA-07-098




Except ZX130-6N

MDAA-07-088




## MAINTENANCE

### 13. Cab mounting nuts




M1U1-07-026

### Cab mounting anchor bolt




M1U1-07-054

### Cab cushion rubber mounting bolt



MDC1-07-052


### 14. Cover mounting bolts



MDCF-07-031


# MAINTENANCE

## 15. Constant torque clamp of low pressure piping



MDC1-07-093


## Flexible master coupling of low pressure piping



MDC1-07-103


ZX300LC-6N, 350LC-6N, 380LC-6N

## T-bolt clamp of low pressure piping




MDC1-07-094

ZX130-6N




MDC1-07-096

ZX160LC-6N, 180LC-6N



ZX210-6N, 250LC-6N

MDC1-07-116




ZX300LC-6N, 350LC-6N, 380LC-6N

MDC1-07-103


## MAINTENANCE

### 16. Swing bearing mounting bolts




Upperstructure Side

M107-07-088



Undercarriage Side  
Except ZX130-6N

M107-07-089




Undercarriage Side  
ZX130-6N

M1U1-07-113

## MAINTENANCE


---

### 17. Travel device mounting bolts




M164-07-005

### Travel reduction gear cover mounting bolts




M1G6-07-007

### Sprocket mounting bolts



M154-07-050

### 18. Upper roller mounting bolts




M157-07-224

## MAINTENANCE


---

19. Lower roller mounting bolts




M107-07-092

20. Track shoe mounting bolts



M107-07-093


21. Track guard mounting bolts



MDAA-07-058


## MAINTENANCE

### 22. Full track guard mounting bolts




MDAA-07-059

### Full track guard through bolt




MDAA-07-059

### 23. Platform handrail mounting bolt



MDC1-07-058


### 24. Body top handrail mounting bolt




MDC1-07-059

## MAINTENANCE

### 25. Aftertreatment device mounting bolts




ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N, 350LC-6N, 380LC-6N  
MDC1-07-049



ZX130-6N, 160LC-6N, 180LC-6N  
(Back plate)


MDC1-07-075



ZX130-6N, 160LC-6N, 180LC-6N  
(Base plate)

MDC1-07-076

### 26. DEF/AdBlue® tank bracket mounting bolts




MDC1-07-042

## MAINTENANCE


---

### 27. Oil cooler mounting bolt



Left and right side

MDC1-07-061




Lower side

MDC1-07-062




## MAINTENANCE

28. Oil cooler fan frame mounting bolts




MDAA-07-045

Oil cooler fan motor mounting bolts



MDAA-07-046

29. Cab top handrail mounting bolt



ZX130-6N, 160LC-6N, 180LC-6N

MDC1-07-077

## MAINTENANCE

### J. Aftertreatment Device

- 1 Check and Clean Aftertreatment Device  
--- as required

#### IMPORTANT:

- Check and clean flammable materials on the area around the Aftertreatment device.
- Condensation for dew may blow out from exhaust outlet (1) of the aftertreatment device and black deposition may be observed; it is not a malfunction.

Do not disassemble the base machine support parts and sensors.


When the machine is operated in dusty areas, refer to the page "9-1 Maintenance Under Special Environmental Conditions".

Open the engine cover.

Check the NOx sensor, harnesses of exhaust temperature sensors and dosing module for abnormality.

Securely close the engine cover.

Clean it if necessary.



MDC1-07-015

## MAINTENANCE

---

### K. Urea SCR System

 **WARNING: Fill specified DEF/AdBlue® into the DEF/AdBlue® tank.**

**If improper DEF/AdBlue® is refilled, fire or system failure may result. If improper liquid is refilled in the DEF/AdBlue® tank, consult your authorized dealer for check or repair.**

Specified DEF/AdBlue®

Refill DEF/AdBlue® which meets Japanese Industrial Standards (JIS K2247), International Organization for Standardization (ISO 22241) or Deutsche Industrie Normen (DIN 70070). If improper liquid (diesel oil, kerosene or gasoline) is refilled in the DEF/AdBlue® tank, fire or system failure may result. The specified DEF/AdBlue® is colorless and odorless solution (urea 32.5%, water 67.5%) which begins to freeze at -11 °C (12.2 °F). Store the DEF/AdBlue® in -10 to 40 °C environment.

In some cases, specified area solution is referred to by one or more of these names:

- Aqueous Urea Solution 32
- AUS 32
- NOx Reduction Agent
- Catalyst Solution

## MAINTENANCE

---

### CAUTION:

- DEF/AdBlue® is colorless and harmless solution. It is harmless when contacting with the body, however, it may cause skin to become inflamed depending on the constitution of the individual. Flush DEF/AdBlue® with clean water when it contacts on the skin.
- If you swallow DEF/AdBlue® by mistake, drink 1 or 2 cups of water or milk and seek immediate medical attention.
- If DEF/AdBlue® is accidentally splashed into eyes, flush with water for 15 minutes or longer and get emergency medical attention.


### IMPORTANT:

- Use dedicated container recommended by the business entity who is handling DEF/AdBlue® to store DEF/AdBlue®. Do not use general container, a container used for other purpose and contaminated container because the quality of DEF/AdBlue® deteriorates.
- The DEF/AdBlue® is non-combustible, however, move DEF/AdBlue® to a safe place when fire occurs.
- Wash out spilled DEF/AdBlue® with clean water.
- Seal the container and store it in a well ventilated place. If DEF/AdBlue® freezes, the quality does not change just after freezing.
- As long as sealed by an airtight stopper, unless water evaporates DEF/AdBlue® will not deteriorate within the guarantee period.
- Do not pour waste DEF/AdBlue® and its containers onto the ground, and do not allow waste to flow into rivers and/or lakes. When disposing DEF/AdBlue®, make sure to let authorized industrial waste disposal contractor dispose of it appropriately.

# MAINTENANCE

## 1 Check DEF/AdBlue® ---daily

Park the machine on a level surface. Lower the bucket to the ground. Check the DEF/AdBlue® level with DEF/AdBlue® gauge (1).  
Add DEF/AdBlue® if necessary.




MDC1-01-001

### Refill DEF/AdBlue®

#### **CAUTION:**

- Refill DEF/AdBlue® which meets Japanese Industrial Standards (JIS K2247), International Organization for Standardization (ISO 22241) or Deutsche Industrie Normen (DIN 70070) in DEF/AdBlue® tank (2). If low density DEF/AdBlue® is refilled, alarm will be generated, restricting machine operation. Do not dilute DEF/AdBlue® with water.
- Do not add any additives to the specified DEF/AdBlue®, Similarly, do not use DEF/AdBlue® that already has additives in it. Doing so may cause damage to the machine.
- Wear safety equipment such as safety glasses or goggles, rubber gloves appropriate to the job. Wash DEF/AdBlue® with clean water when it contacts on the skin. If DEF/AdBlue® is accidentally splashed into eyes, flush with water for 15 minutes or longer and get emergency medical attention.



MDC1-07-064

1. Park the machine according to the instruction on PREPARE MACHINE FOR MAINTENANCE (7-7).
2. DEF/AdBlue® tank (2) is located in the cover at right front of the machine. Open the cover with the key. Holding the handle on the access cover, raise the cover until the cover is secured with catch.

Prior to starting to refill, make sure no contaminants, such as sand or dust, are on the DEF/AdBlue® refill container or the port of the DEF/AdBlue® device.

3. Clean dust and mud around the filler port of DEF/AdBlue® tank with clean cloth.

Model	DEF/AdBlue® Tank Capacity
ZX130-6N, 160LC-6N, 180LC-6N	35 L (9.2 US gal)
ZX200-6N, 210LC-6N	57 L (15.1 US gal)
ZX250LC-6N, 300LC-6N, 350LC-6N, 380LC-6N	70 L (18.5 US gal)

## MAINTENANCE

- Remove cap (4) from DEF/AdBlue® tank (2) and refill DEF/AdBlue®. Be sure to stop refilling before the "F" line by checking the level gauge (5) float.

### IMPORTANT:


- Make sure the containers and equipment used for refilling are free of contaminants, such as sand, mud and dirt. If any contaminants are present, either rinse them off with soft water or wipe them off with a clean cloth before refilling.
  - Take care not to allow dust and/or water to enter the DEF/AdBlue® tank when refilling.
  - Put cap (4) of DEF/AdBlue® tank (2) on the cap holder (3) to prevent the cap from contamination.
  - If DEF/AdBlue® is filled above the "F" line, the system may be damaged during operation or tank (2) may be broken when frozen.
- Install cap (4) after refilling DEF/AdBlue®. Close the tank cover and lock it with the key.

### IMPORTANT:


- Do not get on top of DEF/AdBlue® tank (2) or sensors and piping on the tank. Failure to do so may damage the machine.
- If it becomes necessary to refill DEF/AdBlue® when cap (4) can not be removed due to freezing, use emergency filler port (6).
- White deposits may be observed when DEF/AdBlue® is dried naturally; it is normal. Wash out DEF/AdBlue® deposits with soft water. Never use a high pressure washer.

### NOTE:

- Wipe spilled DEF/AdBlue® and wash spilled area with plenty of water.
- The sound of flowing water may be heard from the tank after the engine stops. It is the sound of returning DEF/AdBlue® from piping to the tank, not a malfunction.
- DEF/AdBlue® will freeze at low temperature, and deteriorate (ammonification) at high temperature. Store DEF/AdBlue® at temperature between -10 and 40 °C.
- Use dedicated container (purchased container) to store or carry DEF/AdBlue®. Alternatively use a polyethylene resin tank, or stainless steel tank.



MDC1-07-064



Level Gauge

MDC1-07-053

## MAINTENANCE

### Extendable Filler Neck

When refilling DEF/AdBlue® by using a container with a short nozzle, use the extendable filler neck attached to the machine for easy refilling.






Extendable filler neck (5) and strainer (6) are optional. Consult your nearest authorized dealer for replacement parts.

**CAUTION:** Wear safety equipment such as safety glasses or goggles, rubber gloves appropriate to the job. Wash DEF/AdBlue® with clean water when it contacts with the skin. If DEF/AdBlue® is accidentally splashed into eyes, rinse with water for 15 minutes or longer and seek emergency medical attention.

**IMPORTANT:** Take care not to allow dust to contaminate the area when carrying out the work.

1. Hold projected portion (1) on adapter (2) with your fingers and twist clockwise 90 degrees.
2. Pull out adapter (2). Strainer (3) is removed with adapter (2) at the same time.
3. Install strainer (5) for the extendable filler neck to holder (4).
4. Insert extendable filler neck (6) into the filler port, twist clockwise 90 degrees to fix, then fill DEF/AdBlue®.

**NOTE:** After filling DEF/AdBlue®, remove extendable filler neck (6) and twist counterclockwise 180 degrees to put it into strainer (5).



MJAG-07-070

MJAG-07-071

MJAG-07-072


## MAINTENANCE

### Clean Filler Port Strainer

Strainer (1) is provided on the filler port of the DEF/AdBlue® tank. Clean strainer (1) if dirt or dust is observed.

**CAUTION:** Wear safety equipment such as safety glasses or goggles, rubber gloves appropriate to the job. Wash DEF/AdBlue® with clean water when it contacts with the skin. If DEF/AdBlue® is accidentally splashed into eyes, flush with water for 15 minutes or longer and get emergency medical attention.


**IMPORTANT:** Take care not to allow dust to contaminate the area when carrying out the work.




MDC1-07-032

1. Remove strainer (1) from the filler port of the DEF/AdBlue® tank.
2. Clean strainer (1) with compressed air pressure (lower than 0.2 MPa (2 kgf/cm<sup>2</sup>)) or tap water.
3. Install strainer (1) on the filler port of the DEF/AdBlue® tank.


**NOTE:** If extendable filler neck (2) (optional) is used, clean strainer (3) (optional).



MJAG-07-070



MJAG-07-071



MJAG-07-072



## MAINTENANCE

### Change DEF/AdBlue®

**⚠ CAUTION:** Wear safety equipment such as safety glasses or goggles, rubber gloves appropriate to the job. Wash DEF/AdBlue® with clean water when it contacts with the skin. If DEF/AdBlue® is accidentally splashed into eyes, flush with water for 15 minutes or longer and get emergency medical attention.


**IMPORTANT:** When contaminated or deteriorated DEF/AdBlue® is used, malfunction may result. Change DEF/AdBlue® periodically to keep cleanliness in the tank.

1. Remove bolts (1) and cover (2).
2. Place a 70 liter or larger capacity container under drain plug (3).
3. Slowly loosen drain plug (3) to drain DEF/AdBlue®.
4. Tighten drain plug (3) after draining DEF/AdBlue®.


Wrench size: 13 mm

Tightening torque: 19.5 N·m (1.95 kgf·m, 14.5 lbf·ft)

5. Fix cover (2) with bolts (1).



MDC1-07-034



MDC1-07-028

## MAINTENANCE

### 2 Replace DEF/AdBlue® Supply Module Main Filter --- every 4500 hours


A filter (4) is mounted in the DEF/AdBlue® pump. Periodically replace filter (4).

**CAUTION:** Wear safety equipment such as safety glasses or goggles, rubber gloves appropriate to the job. Wash DEF/AdBlue® with clean water when it contacts with the skin. If DEF/AdBlue® is accidentally splashed into eyes, flush with water for 15 minutes or longer and get emergency medical attention.

#### IMPORTANT:

- Take care not to allow dirt and/or water to enter the DEF/AdBlue® tank while replacing filter (4).
- Check for leaks around the mounting position after replacement.
- White deposition may be observed when DEF/AdBlue® is dried naturally; it is normal. Wash out DEF/AdBlue® deposition with clean water. Never use a high pressure washer.

1. Park the machine according to the instruction on Preparations for Inspection and Maintenance (7-7).



MDC1-07-044

## MAINTENANCE

### 2. ZX130LC-6N, 160LC-6N, 180LC-6N

Open the right cover.

ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N, 350LC-6N,  
380LC-6N

Remove bolts (1) and cover (2).


### 3. Place 0.5 liters or larger capacity container under cap (3) to collect the drained water.

### 4. Remove cap (3) from the DEF/AdBlue® pump by using a 27 mm bihexagon wrench.

### 5. Pull out filter (4) inside the pump. As it is tightly mounted, it can not be pulled by hands. Use tools such as a pliers. Replace filter (4) assembly when replacing filter (4) of DEF/AdBlue® supply module.


### 6. Install new filter (4), and tighten cap (3) with 20±5 N·m (2.0±0.5 kgf·m, 15±3.7 lbf·ft) torque.

### 7. Fix cover (2) with bolts (1).




ZX130LC-6N, 160LC-6N, 180LC-6N

MDC1-07-080




MDC1-07-016

ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N, 350LC-6N, 380LC-6N



MDC1-07-017

ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N, 350LC-6N, 380LC-6N



MDC1-07-044

## MAINTENANCE

---

- 3** **Replace DEF/AdBlue® Tank Water Supply Inlet Filter**  
--- every 4500 hours or if DEF/AdBlue® overflows  
when supplying water

**IMPORTANT:** Replace the filter without cleaning. Reusing after cleaning may cause a malfunction.

The filter inside the water supply inlet of the DEF/AdBlue® tank must be replaced periodically. Consult your authorized dealer for replacement.

## MAINTENANCE

---

- 4** Replace the DEF/AdBlue® back flow line filter  
--- every 4500 hours

**IMPORTANT:** Replace the filter without cleaning. Reusing after cleaning may cause a malfunction.

There is a circuit returning DEF/AdBlue® from the DEF/AdBlue® supply module to the DEF/AdBlue® tank. This circuit is equipped with a back flow filter. The back flow filter must be replaced periodically. When it is time to replace it, contact your nearest authorized dealer.



## MAINTENANCE UNDER SPECIAL ENVIRONMENTAL CONDITIONS

### Maintenance Under Special Environmental Conditions

Operating Conditions	Precautions for Maintenance
Muddy Soil, Rainy or Snowy Weather	After Operation : Clean the machine and check for cracks, damage, loose or missing bolts and nuts. Lubricate all necessary parts without delay.
Near the Ocean	After Operation : The following salt pollution measures must be taken when the machine is operated at sea or near the coastline. <ol style="list-style-type: none"> <li>(1) After completing the work, extend/retract the hydraulic cylinders several times to form an oil film on the rod surface. Store the machine with cylinders retracted as much as possible.</li> <li>(2) Thoroughly clean the machine with fresh water to wash off salt.</li> <li>(3) To prevent corrosion, perform touch up painting periodically on hose fittings, lubrication piping and inserting position of cover, where sea water is easily collected.</li> <li>(4) During storage of the machine, cover the machine with tarpaulin to prevent sea water from entering into the cab vent. Apply rust prevention oil (example: ANTIRUST P-1300NP-3 JX Nippon Oil &amp; Energy Corporation) onto plated part of the cylinder rods.</li> </ol>
Dusty Atmosphere	<p>Air Cleaner : Clean the element regularly at shorter service intervals.</p> <p>Radiator : Clean the radiator to prevent clogging of the radiator core.</p> <p>Fuel System, Urea SCR System : Replace the filter element and strainer regularly at shorter service intervals.</p> <p>Engine, Aftertreatment Device : Clean earlier than the normal interval to prevent dust from sticking and accumulating. Inhibit the aftertreatment device regeneration according to the machine operating condition.</p>
Rocky Ground	<p>Tracks : Carefully operate while checking for cracks, damage and loose bolts and nuts. Loosen the tracks a little more than usual.</p> <p>Front Attachment : Standard attachment may be damaged when digging rocky ground. Reinforce the bucket before using it, or use a heavy duty bucket.</p>
Falling Stones	Cab Head Guard : Provide a cab guard to protect the machine from falling stones. Consult your nearest Hitachi dealer.
Freezing Weather	<p>Fuel/Lubricant : Use high quality and low viscosity fuel and oil.</p> <p>Engine Coolant : Be sure to use antifreeze.</p> <p>Battery : Fully charge the batteries at shorter intervals. If not fully charged, electrolyte may freeze.</p> <p>Track : Keep the tracks clean. Park the machine on a hard surface to prevent the tracks from freezing to the ground.</p> <p>DEF/AdBlue® : May become frozen but the machine can be operated normally.</p>





## STORAGE

### Storing the Machine

In case the machine is to be stored for longer than one month, pay attention to the following points to in preparation for the next operation.

#### Precautions for Long-Term Storage

Item	Remedy
Machine Cleaning	Wash the machine. Remove soil or other debris adhered to the machine.
Lubrication/Greasing	Check level of lubricant and contamination. Fill up or change if necessary. Lubricate all grease points. Coat exposed metal surfaces that are subject to rust with grease. (i.e. cylinder rods etc.)
Battery	Remove the batteries and store them in a dry protected place after charging fully. Turn the battery disconnect switch to the OFF position.
Coolant	Add anti-rusting agent. If storing in extremely cold areas, either add extra anti-freeze or drain coolant completely to avoid freezing. In this case, place a sign reading "NO COOLANT".
Protection Against Dust and Moisture	Store the machine in a dry storage area using a protective cover.
Tools	Inspect and repair, then store.
Lubrication Operation	If the oil film on the metal surfaces is lost, rust may occur. This may cause abnormal wear of the machine when the machine operation is restarted. If the machine is to be stored for a long time, at least once a month operate the following hydraulic functions two to three times for lubrication: Travel, swing and digging. Be sure to check the coolant level and lubrication conditions before operating.
DEF/AdBlue®	DEF/AdBlue® may become ammonia when storing it under 40°C for one month or longer. Change DEF/AdBlue® if ammonia odor is observed when opening the tank cap.

 **NOTE:**

- *Lubricating operation is a series of warm-up, travel, swing and digging operation carried out repeatedly for a few cycles at slow speed.*
- *Lubricants will deteriorate during long term storage of the machine. Be sure to carefully check the lubricants before restarting operation of the machine.*

### Precautions for Disconnecting or Connecting Batteries

In case the batteries are kept disconnected for more than one month or when the batteries are reconnected, contact your authorized dealer. Resetting of the Information Controller may be required.



# TROUBLESHOOTING

## Troubleshooting

If any machine trouble has occurred, immediately repair it. Make certain the cause of the trouble and take necessary measures to prevent the reoccurrence of the same trouble.

In case troubleshooting is difficult, or measures marked with \* must be taken, consult your authorized dealer. Never attempt to adjust, disassemble, or repair the hydraulic and/or electrical/electronic parts/components.

**IMPORTANT: Never attempt to disassemble or modify the hydraulic and electrical/electronic components.**

### Engine

Consult your authorized dealer for the engine troubleshooting.

### Engine Auxiliaries

Problem	Cause	Solution
Batteries will not be charged.	Broken battery separator	Replace
	Faulty regulator	* Adjust and replace
	Faulty ground line	* Repair
	Faulty alternator	* Repair or replace
Batteries discharge quickly after being charged.	Shorted cable	* Repair or replace
	Shorted battery separator	Replace
	Increased sediment in battery	Replace
Coolant temperature is too high.	Low coolant level	Refill
	Insufficient fan belt tension	Adjust
	Damaged rubber hose	* Replace
	Faulty thermostat	* Replace
	Faulty coolant temperature gauge	* Replace

Items with \* mark: Consult your authorized dealer.

## TROUBLESHOOTING

<b>Impossible to Start the Engine</b>			
Problem	Cause	Solution	
Engine will not start	Starter does not rotate or is not powerful.	Discharged battery	Charge or replace battery.
		Disconnected, loose, or corroded battery terminals	After repairing the corroded area, securely tighten the connectors.
		Lowered pilot control shut-off lever.	Pull pilot control shut-off lever up.
		Disconnected, loose, or corroded starter ground line terminals.	After repairing the corroded area, securely tighten the connectors.
		Faulty pilot control shut-off lever electrical system	* Repair
		Too high engine oil viscosity	Change engine oil with appropriate viscosity.
		Faulty starter and/or electrical system	* Repair and replace
		Battery Disconnect Switch is in the OFF position	Turn the disconnect switch to the ON position
	Starter rotates.	No fuel	After checking that no fuel is leaking, refill fuel.
		Air in the fuel system	Bleed air.
		Clogged fuel main filter	Replace element
		Clogged fuel pre-filter	Replace element
		Frozen fuel	Warm the fuel pump with hot water or wait until the atmospheric temperature rises.
		Engine stop switch is ON	* Repair and replace
Faulty preheat system		* Repair and replace	
Even though the engine is started, the engine stalls soon.	Too low idle speed	* Repair and replace	
	Clogged fuel main filter	Replace element.	
	Clogged fuel pre-filter	Replace element.	
	Faulty engine control system	* Repair and replace	
	Clogged air cleaner	Clean or replace the element.	
	Faulty fuel system	* Repair and replace	
Engine runs irregularly.	Faulty fuel system	* Repair and replace	
	Water or air in the fuel system	Drain water or bleed air.	
	Faulty engine control system	* Repair and replace	
	Clogged aftertreatment device	* Repair and replace	

Items with \* mark: Consult your authorized dealer.

## TROUBLESHOOTING

<b>Control Lever</b>		
Problem	Cause	Solution
Lever is heavy to operate.	Rusted joint	* Lubricate or repair
	Worn pusher	* Replace
Does not move smoothly.	Worn pusher	* Repair or replace
	Faulty pilot valve	* Replace
Does Not Return to Neutral.	Faulty pilot valve	* Replace
The lever is tilted in the neutral position due to increase in play.	Worn joint	* Repair or replace
	Faulty pilot valve	* Replace

Items with \* mark: Consult your authorized dealer.

## TROUBLESHOOTING

### Hydraulic System

When the machine is stored without operation, air mixed in hydraulic oil will become separated and will accumulate in the cylinder upper sections, causing a delay in the response time of the machine movement or weak power development.

In case these symptoms appear, repeatedly operate all actuators several times.

Problem	Cause	Solution
No hydraulic Functions (Noise from pumps)	Faulty hydraulic pump	* Repair or replace
	Lack of hydraulic oil	Refill
	Broken suction pipe and/or hose	* Repair or replace
No hydraulic Functions (Hydraulic pump noise remains unchanged.)	Faulty pilot pump	* Replace
	Faulty pilot shut-off solenoid valve	* Replace
	Faulty wire harness (pilot shut-off solenoid valve) pilot shut-off switch.	* Repair or replace
	The pilot control shut-off lever is in the LOCK position.	Turn it to the UNLOCK Position.
All actuators have no power.	Malfunction due to worn hydraulic pump	* Replace
	Decreased main relief valve set pressure in the control valve	* Adjust
	Lack of hydraulic oil	Refill
	Clogged suction strainer in the hydraulic oil tank	Clean
	Absorption of air from the oil suction side	Retighten
	Faulty pressure sensor.	* Replace
	Faulty solenoid valve	* Replace
Only one side lever is inoperable or has no power.	Faulty relief valve in the valve	* Repair or replace
	Broken pipe and/or hose	* Repair or replace
	Loose pipe line joint	Retighten
	Broken O-ring at pipe line joint	* Replace
	Faulty hydraulic pump	* Repair or replace
	Faulty pilot valve	* Replace
	Faulty pilot circuit line	* Repair or replace
	Faulty pilot solenoid valve	* Repair or replace

Items with \* mark: Consult your authorized dealer.

## TROUBLESHOOTING

Problem	Cause	Solution
Only one actuator is inoperable.	Broken control valve spool	* Replace
	Embedded foreign matter in valve spool	* Repair or replace
	Broken pipe and/or hose	* Repair or replace
	Loose pipe line joint	Retighten
	Broken O-ring at pipe line joint	* Replace
	Broken actuator	* Repair or replace
	Faulty pilot valve	* Replace
	Faulty pilot circuit line	* Repair or replace
Only one cylinder is inoperable or has no power.	Faulty pilot solenoid valve	* Repair or replace
	Broken oil seal in cylinder	* Repair or replace
	Oil leak due to damage to cylinder rod	* Repair or replace
	Faulty pilot valve	* Replace
	Faulty pilot circuit line	* Repair or replace
Hydraulic oil temperature increases.	Faulty pilot solenoid valve	* Repair or replace
	Stained oil cooler	Clean
	Insufficient engine fan belt tension	Adjust
Oil leak from low pressure hose.	Insufficient rotation speed of hydraulically driven fan	* Repair or replace
	Loose clamps	Retighten
	Faulty suction manifold	* Repair or replace

Items with \* mark: Consult your authorized dealer.

## TROUBLESHOOTING

<b>Drive Function</b>		
Problem	Cause	Solution
One or both side tracks are inoperable.	Damaged center joint	* Repair or replace
	Incompletely released parking brake	* Repair or replace
	Broken travel motor	* Repair or replace
	Faulty pilot valve	* Replace
	Faulty pilot circuit line	* Repair or replace
Does not travel smoothly.	Overly tensioned or slackened crawler sag	Adjust
	Lack of lubricant in front idler and/or roller	Refill
	Deformed track frame	* Repair or replace
	Embedded foreign matter such as rock fragments	Remove
	Dragged parking brake	* Repair
Travel speed does not change.	Faulty travel mode switch.	* Replace
	Faulty pressure sensor.	* Replace
	Pump 1 and 2 delivery pressure sensors	
	Pumps 1, 2 control pressure sensors	
	Poor contact in connectors	* Repair or replace
	Damaged wire harness	* Repair
	Faulty controller (MC)	* Replace
	Faulty solenoid valve	* Repair or replace
Faulty motor	* Repair or replace	

Items with \* mark: Consult your authorized dealer.



## TROUBLESHOOTING

<b>Swing Function</b>		
Problem	Cause	Solution
Upperstructure does not swing.	Faulty swing parking brake	* Repair or replace
	Faulty swing parking brake release valve	* Repair or replace
	Broken swing motor	* Repair or replace
	Faulty pilot valve	* Replace
	Faulty pilot circuit line	* Repair or replace
Swing is not smooth.	Worn swing gear	* Repair or replace
	Damaged swing bearing and bearing balls.	* Repair or replace
	Lack of grease	Refill
	Inversion protective valve	* Repair or replace

Items with \* mark: Consult your authorized dealer.

Just after the control valve, swing motor relief valve and/or the swing motor is replaced, a noise may be emitted and/or operation may not be performed smoothly due to air trapped in the hydraulic line.

Slowly continue to operate the machine for approx. 10 minutes to bleed air.

After repair work is complete, be sure to check the oil level in the hydraulic oil tank. Refill hydraulic oil as needed.

## TROUBLESHOOTING

### Engine Speed

Problem	Cause	Solution
Even if operating the engine control dial, the engine speed does not change.	Blown fuse	Replace
	Faulty engine control dial	* Replace
	Poor contact in connector	* Repair or replace
	Damaged wire harness (between EC dial and MC, or MC and ECM)	* Repair
	Faulty controller (MC, ECM)	* Replace
	Performing manual regeneration	(Normal control)
Work mode does not change.	Faulty mode switch	* Replace
	Poor contact in connector	* Repair or replace
	Damaged wire harness (between MC and monitor)	* Repair
	Faulty controller (MC)	* Replace
	Faulty solenoid valve	* Repair or replace
Auto-idle is inoperable or not released.	Faulty pressure sensor.	* Replace
	Poor contact in connector	* Repair or replace
	Damaged wire harness	* Repair
	Faulty controller.	* Replace
	Performing manual regeneration	(Normal control)

Items with \* mark: Consult your authorized dealer.

### Pump Control

Problem	Cause	Solution
Front attachment and/or travel speed is slow.	Blown control fuse	Replace
	Poor contact in connector	* Repair or replace
	Damaged wire harness	* Repair
	Faulty controller.	* Replace
	Faulty pump solenoid valve.	* Replace
	Faulty pressure sensor.	* Replace

Items with \* mark: Consult your authorized dealer.


### Others

The machine may have a noise, excessive vibration, and abnormal smell when any trouble occurs. Always beware of the machine conditions during operation.

## SPECIFICATIONS

### Specifications

#### ZX130-6N




Model	ZX130-6N
Type of Front-End Attachment	2.52 m (8 ft 3 in) Arm
Bucket Capacity (Heaped)	PCSA 0.50 m <sup>3</sup> (0.65 yd <sup>3</sup> ), CECE 0.45 m <sup>3</sup>
Operating Weight	12400 kg (27400 lb)
Base Machine Weight	9900 kg (21900 lb)
Engine	Isuzu AR-4JJ1XASA-02 74.9 kW/2000 min <sup>-1</sup> (102 PS/2000 rpm)
A: Overall Width (Excluding back mirrors)	2490 mm (8 ft 2 in)
B: Cab Height	2790 mm (9 ft 2 in)
B': Cab Top Handrail Height	2870 mm (9 ft 5 in)
C: Rear End Swing Radius	2190 mm (7 ft 2 in)
D: Minimum Ground Clearance	*410 mm (1 ft 4 in)
E: Counterweight Clearance	*840 mm (2 ft 9 in)
F: Engine Cover Height	*2260 mm (7 ft 5 in)
F': Handrail Height	2870 mm (9 ft 5 in)
G: Overall Width of Upperstructure	2460 mm (8 ft 1 in)
H: Undercarriage Length	3580 mm (11 ft 9 in)
I: Undercarriage Width	2490 mm (8 ft 2 in)
J: Sprocket Center to Idle Center	2880 mm (9 ft 5 in)
K: Track Shoe Width	500 mm (20 in) (Grouser shoe)
Ground Pressure	40 kPa (0.41 kgf/cm <sup>2</sup> , 5.8 psi)
Swing Speed	13.3 min <sup>-1</sup> (rpm)
Travel Speed (fast/slow)	5.5/3.3 km/h (3.4/2.1 mph)
Gradeability	35° (tanθ = 0.70)

\*The dimensions do not include the height of the shoe lug.

## SPECIFICATIONS

### Working Ranges (Grouser shoe)

ZX130-6N



MDC1-12-014

Model	ZX130-6N			
Category	2.52 m (8 ft 3 in) Arm		3.01 m (9 ft 11 in) Arm	
Item	mm	ft·in	mm	ft·in
A : Maximum Digging Reach	8300	27' 3"	8770	28' 9"
B : Maximum Digging Depth	*5540	*18' 2"	*6030	*19' 9"
C : Maximum Cutting Height	*8600	*28' 3"	*8930	*29' 4"
D : Maximum Dumping Height	*6190	*20' 4"	*6520	*21' 5"
E : Overall Height	2870	9' 5"	**2870	**9' 5"
F : Overall Length	7700	25' 3"	**7710	**25' 4"
G : Minimum Swing Radius	2400	7' 11"	2620	8' 7"

**NOTE:** \* The dimensions do not include height of the shoe lug.

\*\* The dimensions asterisked are for transport pin position.

## SPECIFICATIONS

### Shoe Types and Applications

#### ZX130-6N

Shoe Width		500 mm (20 in) Grouser Shoe	600 mm (24 in) Grouser Shoe	700 mm (28 in) Grouser Shoe
Application		For Ordinary Ground (Standard)	For Weak Footing (Option)	For Weak Footing (Option)
Operating Weight	kg (lb)	12400 (27400)	12700 (28000)	12900 (28500)
Base Machine Weight	kg (lb)	9900 (21900)	10200 (22500)	10400 (23000)
Cab Height	mm (ft-in)	2870 (9' 5")	2870 (9' 5")	2870 (9' 5")
Minimum Ground Clearance	mm (ft-in)	*410 (16")	*410 (16")	*410 (16")
Undercarriage Length	mm (ft-in)	3580 (11' 9")	3580 (11' 9")	3580 (11' 9")
Undercarriage Width	mm (ft-in)	2490 (8' 2")	2590 (8' 6")	2690 (8' 10")
Ground Pressure		40 kPa (0.41 kgf/cm <sup>2</sup> , 5.8 psi)	33 kPa (0.34 kgf/cm <sup>2</sup> , 4.8 psi)	29 kPa (0.30 kgf/cm <sup>2</sup> , 4.2 psi)


 NOTE:

- The specifications for the front-end attachment is for 2.52 m (8 ft 3 in) arm with PCSA 0.50 m<sup>3</sup> (0.65 yd<sup>3</sup>) bucket.
- Other than 500 mm (20 in) grouser shoe should not be used on gravel or rocky ground. Operating or digging on gravel ground may cause serious damage to shoe, shoe bolts and other parts such as rollers.
- \*The dimensions do not include the height of the shoe lug.

## SPECIFICATIONS

### Bucket Types and Applications

#### ZX130-6N

Bucket	Bucket Capacity m <sup>3</sup> (yd <sup>3</sup> )		Bucket Width mm (in)		Front-End Attachment		
	PCSA (Heaped)	CECE (Heaped)	With Side Cutters	Without Side Cutters	2.52 m (8' 3") Arm	3.01 m (9' 11") Arm	2.52 m (8' 3") Arm and extension
Hoe Bucket	0.19 (0.25)	0.17	550 (22")	450 (18")	●	●	○
	0.30 (0.39)	0.25	700 (28")	580 (23")	●	●	○
	0.40 (0.52)	0.33	800 (31")	680 (27")	●	●	○
	0.45 (0.59)	0.40	970 (38")	850 (33")	●	○	○
	0.50 (0.65)	0.45	1010 (40")	890 (35")	●	*○	-
	0.59 (0.77)	0.50	1070 (42")	950 (37")	○	-	-
	0.66 (0.86)	0.55	-	1030 (41")	-	-	-
Reinforced Hoe Bucket	0.50 (0.65)	0.45	1010 (40")	890 (35")	●	*○	-
Reinforced Hoe Bucket	0.59 (0.77)	0.50	1070 (42")	950 (37")	○	-	-
One Point Ripper	-	-	-	-	■	-	-
Slope-Finishing Blade	-	-	1000 (39") x 1600 (63")		◇	◇	-
V-Type Bucket	-	-			○	○	-
Clamshell Bucket (Cente-pull type)	0.30 (0.39)	-	-	560 (22")	●	-	-
Clamshell Bucket (Shell-push type)	0.40 (0.52)	-	-	590 (23")	●	-	-

 **NOTE:**


- Symbols in the above table have the following meanings.
  - : General excavating
  - : Light duty excavating
  - : Rock digging
  - : Loading work
  - ◇ : Slope-finishing work
  - : Not applicable (not warrantable)
- Hoe bucket is applicable to the following types of work.
  - General excavating:  
For digging and loading operation of sand, gravel, clay, ordinary earth and so on.
  - Light duty excavating:  
For digging and loading operation of dry, loosened earth, sand, mud and so on.  
Their bulk density shall be less than 1.60 t/m<sup>3</sup> (2700 lb/yd<sup>3</sup>) as a standard.
  - Loading:  
For loading operation of dry, loosened earth and sand.  
Their bulk density shall be less than 1.10 t/m<sup>3</sup> (1850 lb/yd<sup>3</sup>) as a standard.
  - Rock digging:  
For digging/loading operation of mountain gravels, blasted rock, hard clay, soft rock and so on.
- \* Applicable only to 700 mm (28 in) grouser shoe.

**IMPORTANT: Using inapplicable buckets may cause serious damage to the front structure such as boom, arm and hydraulic cylinders.**

## SPECIFICATIONS

### Specifications

#### ZX160LC-6N




Model	ZX160LC-6N
Type of Front-End Attachment	2.58 m (8 ft 6 in) Arm
Bucket Capacity (Heaped)	PCSA 0.60 m <sup>3</sup> (0.79 yd <sup>3</sup> ), CECE 0.55 m <sup>3</sup>
Operating Weight	17000 kg (37500 lb)
Base Machine Weight	13700 kg (30300 lb)
Engine	Isuzu AR-4JJ1XASA-01 82.3 kW/2200 min <sup>-1</sup> (112 PS/2200 rpm)
A : Overall Width (Excluding back mirrors)	2500 mm (8 ft 2 in)
B : Cab Height	2950 mm (9 ft 8 in)
B' : Cab Top Handrail Height	3030 mm (9 ft 11 in)
C : Rear End Swing Radius	2550 mm (8 ft 4 in)
D : Minimum Ground Clearance	*470 mm (1 ft 7 in)
E : Counterweight Clearance	*980 mm (3 ft 3 in)
F : Engine Cover Height	*2530 mm (8 ft 4 in)
F' : Handrail Height	3030 mm (9 ft 11 in)
G : Overall Width of Upperstructure	2480 mm (8 ft 2 in)
H : Undercarriage Length	3920 mm (12 ft 10 in)
I : Undercarriage Width	2490 mm (8 ft 2 in)
J : Sprocket Center to Idle Center	3100 mm (10 ft 2 in)
K : Track Shoe Width	500 mm (20 in) (Grouser shoe)
Ground Pressure	50 kPa (0.51 kgf/cm <sup>2</sup> , 7.3 psi)
Swing Speed	13.3 min <sup>-1</sup> (rpm)
Travel Speed (fast/slow)	5.1/3.3 km/h (3.2/2.1 mph)
Gradeability	35° (tanθ = 0.70)

\*The dimensions do not include the height of the shoe lug.

## SPECIFICATIONS

### Working Ranges (Grouser shoe)

ZX160LC-6N



MDC1-12-016

Model	ZX160LC-6N			
	2.58 m (8 ft 6 in) Arm		3.08 m (10 ft 1 in) Arm	
Category	mm	ft-in	mm	ft-in
A : Maximum Digging Reach	8870	29' 1"	9330	30' 7"
B : Maximum Digging Depth	*5980	*19' 7"	*6490	*21' 4"
C : Maximum Cutting Height	*8880	*29' 2"	*9130	*29' 11"
D : Maximum Dumping Height	*6170	*20' 3"	*6400	*21'
E : Overall Height	3030	9' 11"	3110	10' 2"
F : Overall Length	8620	28' 3"	8650	28' 5"
G : Minimum Swing Radius	2910	9' 7"	2920	9' 7"

**NOTE:** \* The dimensions do not include height of the shoe lug.



## SPECIFICATIONS

### Shoe Types and Applications

#### ZX160LC-6N

Shoe Width		500 mm (20 in) Grouser Shoe	600 mm (24 in) Grouser Shoe	700 mm (28 in) Grouser Shoe
Application		For Ordinary Ground (Standard)	For Weak Footing (Option)	For Weak Footing (Option)
Operating Weight	kg (lb)	17000 (37500)	17200 (38000)	17400 (38400)
Base Machine Weight	kg (lb)	13700 (30300)	13900 (30700)	14100 (31100)
Cab Height	mm (ft-in)	3030 (9' 11")	3030 (9' 11")	3030 (9' 11")
Minimum Ground Clearance	mm (ft-in)	*470 (19")	*470 (19")	*470 (19")
Undercarriage Length	mm (ft-in)	3890 (12' 9")	3890 (12' 9")	3890 (12' 9")
Undercarriage Width	mm (ft-in)	2490 (8' 2")	2590 (8' 6")	2690 (8' 10")
Ground Pressure		50 kPa (0.51 kgf/cm <sup>2</sup> , 7.3 psi)	42 kPa (0.43 kgf/cm <sup>2</sup> , 6.1 psi)	36 kPa (0.37 kgf/cm <sup>2</sup> , 5.2 psi)


 **NOTE:**

- The specifications for the front-end attachment is for 2.58 m (8 ft 6 in) arm with PCSA 0.60 m<sup>3</sup> (0.79 yd<sup>3</sup>) reinforced bucket (heaped).
- Other than 500 mm (20 in) grouser shoe should not be used on gravel or rocky ground. Operating or digging on gravel ground may cause serious damage to shoe, shoe bolts and other parts such as rollers.
- \*The dimensions do not include the height of the shoe lug.

## SPECIFICATIONS

### Bucket Types and Applications

#### ZX160LC-6N

Bucket	Bucket Capacity m <sup>3</sup> (yd <sup>3</sup> )		Bucket Width mm (in) (With side cutter)	Application	Front-End Attachment	
	PCSA (Heaped)	CECE (Heaped)			2.58 m (8' 6") Arm	3.08 m (10' 1") Arm
Hoe Bucket	0.52 (0.68)	0.45	910 (36")		●	●
	0.60 (0.79)	0.55	1045 (41")		●	*●
	0.70 (0.92)	0.60	1125 (44")		○	□
	0.82 (1.07)	0.7	1260 (50")		□	-
Reinforced Hoe Bucket	0.60 (0.79)	0.55	1045 (41")		●	*○
	0.70 (0.92)	0.6	1120 (44")		○	*□
One Point Ripper	-		-		-	-
Slope-Finishing Blade	-		1700 (67")	Bank cutting finish	◇	◇
V-type Bucket					○	○
Clamshell Bucket (Shellpush)		0.4 (0.52)	Bucket width 590 (23")	Side ditching	●	-

 NOTE:


- Symbols in the above table have the following meanings.
  - : General excavating
  - : Light duty excavating
  - : Rock digging
  - : Loading work
  - ◇ : Slope-finishing work
  - : Not applicable (not warrantable)
- Hoe bucket is applicable to the following types of work.
  - General excavating:  
For digging and loading operation of sand, gravel, clay, ordinary earth and so on.
  - Light duty excavating:  
For digging and loading operation of dry, loosened earth, sand, mud and so on.  
Their bulk density shall be less than 1.60 t/m<sup>3</sup> (2700 lb/yd<sup>3</sup>) as a standard.
  - Loading:  
For loading operation of dry, loosened earth and sand.  
Their bulk density shall be less than 1.10 t/m<sup>3</sup> (1850 lb/yd<sup>3</sup>) as a standard.
  - Rock digging:  
For digging/loading operation of mountain gravels, blasted rock, hard clay, soft rock and so on.
- \* Applicable only to 700 mm (28 in) grouser shoe.

**IMPORTANT: Using inapplicable buckets may cause serious damage to the front structure such as boom, arm and hydraulic cylinders.**

## SPECIFICATIONS

### Specifications

#### ZX180LC-6N



MDC1-12-011


Model	ZX180LC-6N
Type of Front-End Attachment	2.71 m (8 ft 11 in) Arm
Bucket Capacity (Heaped)	PCSA 0.70 m <sup>3</sup> (0.92 yd <sup>3</sup> ), CECE 0.60 m <sup>3</sup>
Operating Weight	19000 kg (41900 lb)
Base Machine Weight	15100 kg (33300 lb)
Engine	Isuzu AR-4JJ1XASA-01 82.3 kW/2200 min <sup>-1</sup> (112 PS/2200 rpm)
A: Overall Width (Excluding back mirrors)	2800 mm (9 ft 2 in)
B: Cab Height	2950 mm (9 ft 8 in)
B': Cab Top Handrail Height	3030 mm (9 ft 11 in)
C: Rear End Swing Radius	2550 mm (8 ft 4 in)
D: Minimum Ground Clearance	*450 mm (1 ft 6 in)
E: Counterweight Clearance	*980 mm (3 ft 3 in)
F: Engine Cover Height	*2530 mm (8 ft 4 in)
F': Handrail Height	3030 mm (9 ft 11 in)
G: Overall Width of Upperstructure	2480 mm (8 ft 2 in)
H: Undercarriage Length	4170 mm (13 ft 8 in)
I: Undercarriage Width	2800 mm (9 ft 2 in)
J: Sprocket Center to Idle Center	3370 mm (11 ft 1 in)
K: Track Shoe Width	600 mm (24 in) (Grouser shoe)
Ground Pressure	42 kPa (0.43 kgf/cm <sup>2</sup> , 6.1 psi)
Swing Speed	14.1 min <sup>-1</sup> (rpm)
Travel Speed (fast/slow)	4.8/3.1 km/h (3.0/1.9 mph)
Gradeability	35 ° (tanθ = 0.70)

\*The dimensions do not include the height of the shoe lug.

## SPECIFICATIONS

### Working Ranges (Grouser shoe)

ZX180LC-6N



MDC1-12-012

Model	ZX180LC-6N	
Category	2.71 m (8 ft 11 in) Arm	
Item	mm	ft-in
A : Maximum Digging Reach	9430	30' 11"
B : Maximum Digging Depth	*6570	*21' 7"
C : Maximum Cutting Height	*9400	*30' 10"
D : Maximum Dumping Height	*6570	*21' 7"
E : Overall Height	3030	9' 11"
F : Overall Length	9040	29' 8"
G : Minimum Swing Radius	3130	10' 3"

**NOTE:** \* The dimensions do not include height of the shoe lug.

## SPECIFICATIONS

### Shoe Types and Applications

#### ZX180LC-6N

Shoe Width		600 mm (20 in) Grouser Shoe	700 mm (24 in) Grouser Shoe	800 mm (28 in) Grouser Shoe
Application		For Ordinary Ground (Standard)	For Weak Footing (Option)	For Weak Footing (Option)
Operating Weight	kg (lb)	19000 (41900)	19400 (42800)	19700 (43500)
Base Machine Weight	kg (lb)	15100 (33300)	15500 (34200)	15700 (34700)
Cab Height	mm (ft-in)	3030 (9' 11")	3030 (9' 11")	3030 (9' 11")
Minimum Ground Clearance	mm (ft-in)	*450 (18")	*450 (18")	*450 (18")
Undercarriage Length	mm (ft-in)	4170 (13' 8")	4170 (13' 8")	4170 (13' 8")
Undercarriage Width	mm (ft-in)	2800 (9' 2")	2900 (9' 6")	3000 (9' 10")
Ground Pressure		42 kPa (0.43 kgf/cm <sup>2</sup> , 6.1 psi)	37 kPa (0.38 kgf/cm <sup>2</sup> , 5.4 psi)	33 kPa (0.34 kgf/cm <sup>2</sup> , 4.8 psi)


 NOTE:

- The specifications for the front-end attachment is for 2.71 m (8 ft 11 in) arm with PCSA 0.70 m<sup>3</sup> (0.92 yd<sup>3</sup>) reinforced bucket (heaped).
- Other than 600 mm (24 in) grouser shoe should not be used on gravel or rocky ground. Operating or digging on gravel ground may cause serious damage to shoe, shoe bolts and other parts such as rollers.
- \*The dimensions do not include the height of the shoe lug.

## SPECIFICATIONS

### Bucket Types and Applications

#### ZX180LC-6N

Bucket	Bucket Capacity m <sup>3</sup> (yd <sup>3</sup> )		Bucket Width mm (in) (With side cutter)	Application	Front-End Attachment
	PCSA (Heaped)	CECE (Heaped)			2.71 m (8' 11") Arm
Hoe Bucket	0.51 (0.67)	0.45	830 (33")		●
	0.70 (0.92)	0.6	1010 (40")		●
	0.80 (1.05)	0.7	1140 (45")		○
	0.91 (1.19)	0.8	1260 (50")		□
	1.10 (1.44)	0.9	1440 (57")		-
	1.20 (1.57)	1.0	1450 (57") (Without side cutter)		-
Reinforced Hoe Bucket	0.70 (0.92)	0.6	1010 (40")		●
	0.80 (1.05)	0.7	1140 (45")		●
	0.91 (1.19)	0.8	1260 (50")		○
Ripper Bucket	0.60 (0.79)	0.50	800 (31.5") (Without side cutter)		-
Slope-Finishing Blade	-		1800 (70")	Bank cutting finish	◇
V-type Bucket					○
Clamshell Bucket (Shell-push type)		0.60	Bucket width 870 (34")	Side ditching	●
Clamshell Bucket (Center-pull type)		0.60	Bucket width 940 (37")	Side ditching	●

 **NOTE:**


- Symbols in the above table have the following meanings.
  - : General excavating
  - : Light duty excavating
  - : Rock digging
  - : Loading work
  - ◇ : Slope-finishing work
  - : Not applicable (not warrantable)
- Hoe bucket is applicable to the following types of work.
  - General excavating:  
For digging and loading operation of sand, gravel, clay, ordinary earth and so on.
  - Light duty excavating:  
For digging and loading operation of dry, loosened earth, sand, mud and so on.  
Their bulk density shall be less than 1.60 t/m<sup>3</sup> (2700 lb/yd<sup>3</sup>) as a standard.
  - Loading:  
For loading operation of dry, loosened earth and sand.  
Their bulk density shall be less than 1.10 t/m<sup>3</sup> (1850 lb/yd<sup>3</sup>) as a standard.
  - Rock digging:  
For digging/loading operation of mountain gravels, blasted rock, hard clay, soft rock and so on.

**IMPORTANT: Using inapplicable buckets may cause serious damage to the front structure such as boom, arm and hydraulic cylinders.**

## SPECIFICATIONS

### Specifications

#### ZX210-6N, 210LC-6N



MDAA-12-007


Model	ZX210-6N	ZX210LC-6N
Type of Front-End Attachment	2.91 m (9 ft 7 in) Arm	
Bucket Capacity (Heaped)	PCSA 0.8 m <sup>3</sup> (1.05 yd <sup>3</sup> ), CECE 0.7 m <sup>3</sup>	
Operating Weight	20700 kg (45700 lb)	21200 kg (46800 lb)
Base Machine Weight	16200 kg (35800 lb)	16700 kg (36800 lb)
Engine	122 kW/2000 min <sup>-1</sup> (166 PS/2000 rpm)	
A: Overall Width (Excluding back mirrors)	2860 mm (9 ft 5 in)	2990 (9 ft 10 in)
B: Cab Height	2950 mm (9 ft 8 in)	
C: Rear End Swing Radius	2890 mm (9 ft 6 in)	
D: Minimum Ground Clearance	*450 mm (18 in)	
E: Counterweight Clearance	*1030 mm (3 ft 5 in)	
F: Engine Cover Height	*2360 mm (7 ft 9 in)	
G: Overall Width of Upperstructure	2710 mm (8 ft 11 in)	
H: Undercarriage Length	4170 mm (13 ft 8 in)	4460 mm (14 ft 8 in)
I: Undercarriage Width	2800 mm (9 ft 2 in)	2990 mm (9 ft 10 in)
J: Sprocket Center to Idler Center	3370 mm (11 ft 1 in)	3660 mm (12 ft 0 in)
K: Track Shoe Width	600 mm (24 in) (Grouser shoe)	
Ground Pressure	47 kPa (0.48 kgf/cm <sup>2</sup> , 6.8 psi)	45 kPa (0.46 kgf/cm <sup>2</sup> , 6.5 psi)
Swing Speed	13.3 min <sup>-1</sup> (rpm)	
Travel Speed (fast/slow)	5.5/3.5 km/h (3.4/2.2 mph)	
Gradeability	35 ° (tanθ = 0.70)	

NOTE: \* The dimensions do not include the height of the shoe lug.

## SPECIFICATIONS

### Working Ranges (Grouser Shoe)

ZX210-6N, 210LC-6N



MDAA-12-008

Model		ZX210-6N, 210LC-6N			
Item	Category	2.42 m (7 ft 11 in) Arm		4.0 m (13 ft 2 in) Arm	
		mm	ft-in	mm	ft-in
A : Maximum Digging Reach		9430	30' 11"	9920	32' 7"
B : Maximum Digging Depth		*6180	*20' 3"	*6670	*21' 11"
C : Maximum Cutting Height		*9670	*31' 9"	*10040	*32' 11"
D : Maximum Dumping Height		*6830	*22' 5"	*7180	*23' 7"
E : Overall Height		3180	10' 5"	3010	9' 11"
F : Overall Length		9605	31' 6"	9520	31' 3"
G : Minimum Swing Radius		3280	10' 9"	3180	10' 5"

**NOTE:** \* The dimensions do not include the height of the shoe lug.



## SPECIFICATIONS

### Shoe Types and Applications

#### ZX210LC-6N

Shoe Width		600 mm (24") Grouser Shoe	700 mm (28") Grouser Shoe	800 mm (31") Grouser Shoe	600 mm (24") Flat Shoe
Application		For Ordinary Ground (Standard)	For Weak Footing (Option)	For Weak Footing (Option)	For Paved Road (Option )
Operating Weight	kg (lb)	20700 (45700)	21100 (46600)	21300 (47000)	21500 (47400)
Base Machine Weight	kg (lb)	16200 (35800)	16600 (36600)	16800 (37090)	17000 (37500)
Cab Height	mm (ft-in)	2950 (9' 8")	2950 (9' 8")	2950 (9' 8")	2990 (9' 10")
Minimum Ground Clearance	mm (ft-in)	* 450 (18")	* 450 (18")	* 450 (18")	490 (19")
Undercarriage Length	mm (ft-in)	4170 (13' 8")	4170 (13' 8")	4170 (13' 8")	4190 (13' 9")
Undercarriage Width	mm (ft-in)	2800 (9' 2")	2900 (9' 6")	3000 (9' 10")	2800 (9' 2")
Ground Pressure		47 kPa (0.48 kgf/cm <sup>2</sup> , 6.8 psi)	40 kPa (0.41 kgf/cm <sup>2</sup> , 5.8 psi)	35 kPa (0.36 kgf/cm <sup>2</sup> , 5.1 psi)	48 kPa (0.49 kgf/cm <sup>2</sup> , 7.0 psi)

#### ZX210LC-6N

Shoe Width		600 mm (24") Grouser Shoe	700 mm (28") Grouser Shoe	800 mm (31") Grouser Shoe	600 mm (24") Flat Shoe
Application		For Ordinary Ground (Standard)	For Weak Footing (Option)	For Weak Footing (Option)	For Paved Road (Option )
Operating Weight	kg (lb)	21200 (46800)	21600 (47700)	21900 (48300)	22100 (48800)
Base Machine Weight	kg (lb)	16700 (36800)	17100 (37700)	17400 (38400)	17600 (38900)
Cab Height	mm (ft-in)	2950 (9' 8")	2950 (9' 8")	2950 (9' 8")	2990 (9' 10")
Minimum Ground Clearance	mm (ft-in)	* 450 (18")	* 450 (18")	* 450 (18")	490 (19")
Undercarriage Length	mm (ft-in)	4460 (14' 8")	4460 (14' 8")	4460 (14' 8")	4480 (14' 8")
Undercarriage Width	mm (ft-in)	2990 (9' 10")	3090 (9' 6")	3190 (10' 6")	2990 (9' 10")
Ground Pressure		45 kPa (0.46 kgf/cm <sup>2</sup> , 6.5 psi)	39 kPa (0.40 kgf/cm <sup>2</sup> , 5.7 psi)	35 kPa (0.36 kgf/cm <sup>2</sup> , 5.1 psi)	45 kPa (0.46 kgf/cm <sup>2</sup> , 6.5 psi)

 **NOTE:**

- The Specifications for the front-end attachment is for 2.91 m (9 ft 7 in) arm with PCSA 0.8 m<sup>3</sup> (1.05 yd<sup>3</sup>) bucket.
- \* The Specifications for the front-end attachment is for 2.91 m (9 ft 7 in) arm with PCSA 1.2 m<sup>3</sup> (1.57 yd<sup>3</sup>) bucket.
- 700, 800 mm (28, 31 in) grouser shoe and 600 mm (24 in) flat shoe should not be used on gravel or rocky ground.
- \* The dimensions do not include the height of the shoe lug.

## SPECIFICATIONS

### Bucket Types and Applications

#### ZX210-6N, 210LC-6N

Bucket	Bucket Capacity m <sup>3</sup> (yd <sup>3</sup> )		Bucket Width mm (in) (With side cutter)	Application	Front-End Attachment	
	PCSA (Heaped)	CECE (Heaped)			2.42 m (7' 11") Arm	2.91 m (9' 7") Arm
Hoe Bucket	0.51 (0.67)	0.45	830 (33")		●	●
	0.80 (1.05) H	0.7	1150 (45")		●	●
	0.80 (1.05)	0.7	1140 (45")		●	●
	0.91 (1.19)	0.8	1260 (50")		●	●
	1.10 (1.44)	0.9	1440 (57")		○	○
	1.20 (1.57)	1.0	1450 (57") (Without side cutter)		□	-
Bucket reinforcement can be welded in four places upon customers request	0.80 (1.05)	0.7	1140 (45")		●	●
	0.91 (1.19)	0.8	1260 (50")		●	●
Reinforced Hoe Bucket HD Type (Transverse-Type-Pin-Used Type)	0.80 (1.50)	0.7	1140 (45")		●	●
V-Type Bucket	-		90 °	Excavating V-trenches	○	○
Ripper Bucket		0.50 (0.65)	800 (31.5") (Without side cutter)		■	-
One Point Ripper	-		-		■	-
Clamshell Bucket		0.60 (0.78)	Bucket width 940 (37")	Side ditching	●	●
Slope-Finishing Blade	-		1800 (70")	Bank cutting finish	◇	◇

 **NOTE:**


- Symbols in the above table have the following meanings.
  - : General excavating
  - : Light duty excavating
  - : Rock digging
  - : Loading work
  - ◇ : Slope-finishing work
  - : Not applicable (not warrantable)
- Hoe bucket is applicable to the following types of work.
  - General excavating:  
For digging and loading operation of sand, gravel, clay, ordinary earth and so on.
  - Light duty excavating:  
For digging and loading operation of dry, loosened earth, sand, mud and so on.  
Their bulk density shall be less than 1.60 t/m<sup>3</sup> (2700 lb/yd<sup>3</sup>) as a standard.
  - Loading:  
For loading operation of dry, loosened earth and sand.  
Their bulk density shall be less than 1.10 t/m<sup>3</sup> (1850 lb/yd<sup>3</sup>) as a standard.
  - Rock digging:  
For digging/loading operation of mountain gravels, blasted rock, hard clay, soft rock and so on.

**IMPORTANT:** Using inapplicable buckets may cause serious damage to the front structure such as boom, arm and hydraulic cylinders.

## SPECIFICATIONS


### Specifications

#### ZX250LC-6N



MDAA-12-001


Model	ZX250LC-6N
Type of Front-End Attachment	2.96 m (9 ft 9 in) Arm
Bucket Capacity (Heaped)	PCSA 1.0 m <sup>3</sup> (1.3 yd <sup>3</sup> ), CECE 0.9 m <sup>3</sup>
Operating Weight	25600 kg (56400 lb)
Base Machine Weight	19900 kg (43900 lb)
Engine	Isuzu AQ-4HK1XASA-01 132 kW/2000 min <sup>-1</sup> (180 PS/2000 rpm)
A: Overall Width (Excluding back mirrors)	3190 mm (10 ft 6 in)
B: Cab Height	3010 mm (9 ft 11 in)
C: Rear End Swing Radius	3140 mm (10 ft 4 in)
D: Minimum Ground Clearance	*460 mm (18 in)
E: Counterweight Clearance	*1080 mm (3 ft 7 in)
F: Engine Cover Height	*2430 mm (8 ft)
G: Overall Width of Upperstructure	2870 mm (9 ft 5 in)
H: Undercarriage Length	4640 mm (15 ft 3 in)
I: Undercarriage Width	3190 mm (10 ft 6 in)
J: Sprocket Center to Idler Center	3850 mm (12 ft 8 in)
K: Track Shoe Width	600 mm (24 in) (Grouser shoe)
Ground Pressure	51 kPa (0.52 kgf/cm <sup>2</sup> , 7.4 psi)
Swing Speed	11.0 min <sup>-1</sup> (rpm)
Travel Speed (fast/slow)	5.5/3.4 km/h (3.4/2.1 mph)
Gradeability	35° (tanθ = 0.70)

 NOTE: \* The dimensions do not include the height of the shoe lug.

## SPECIFICATIONS

### Working Ranges

#### ZX250LC-6N



Backhoe

MDAA-12-002

Model	Category	ZX250LC-6N					
		2.5 m (8 ft 2 in) Arm		2.96 m (9 ft 9 in) Arm		3.61m (11 ft 10 in) Arm	
Item		mm	ft-in	mm	ft-in	mm	ft-in
A : Maximum Digging Reach		9880	32' 5"	10290	33' 9"	10910	35' 10"
B : Maximum Digging Depth		*6500	*21' 4"	*6960	*22' 10"	*7610	*25' 0"
C : Maximum Cutting Height		*9950	*32' 8"	*10160	*33' 4"	*10560	*34' 8"
D : Maximum Dumping Height		*6990	*22' 11"	*7200	*23' 8"	*7580	*24' 10"
E : Overall Height		3370	11' 1"	3070	10' 1"	3320	10' 11"
F : Overall Length		10270	33' 8"	10150	33' 4"	10200	33' 6"
G : Minimum Swing Radius		3480	11' 5"	3440	11' 3"	3430	11' 3"

**NOTE:** \* The dimensions do not include the height of the shoe lug.

## SPECIFICATIONS

### Shoe Types and Applications

#### ZX250LC-6N

Shoe Width		600 mm (24") Grouser Shoe	700 mm (28") Grouser Shoe	800 mm (31") Grouser Shoe	600 mm (24") Flat Shoe	760 mm (30") Triangular Shoe
Application		For Ordinary Ground (Standard)	For Weak Footing (Option)	For Weak Footing (Option)	For Paved Road (Option)	For Weak Footing (Option)
Operating Weight	kg (lb)	25600 (56500)	25900 (57100)	26200 (57800)	26300 (58000)	26500 (58500)
Base Machine Weight	kg (lb)	19900 (43900)	20200 (44600)	20500 (45200)	20600 (45500)	20900 (46100)
Cab Height	mm (ft-in)	3010 (9' 11")	3010 (9' 11")	3010 (9' 11")	3020 (9' 11")	3070 (10' 1")
Minimum Ground Clearance	mm (ft-in)	* 460 (18")	* 460 (18")	* 460 (18")	500 (20")	* 460 (18")
Undercarriage Length	mm (ft-in)	4640 (15' 3")	4640 (15' 3")	4640 (15' 3")	4660 (15' 4")	4750 (15' 7")
Undercarriage Width	mm (ft-in)	3190 (10' 6")	3290 (10' 10")	3390 (11' 2")	3190 (10' 6")	3350 (11' 0")
Ground Pressure		51 kPa (0.52 kgf/cm <sup>2</sup> , 7.4 psi)	44 kPa (0.45 kgf/cm <sup>2</sup> , 6.4 psi)	39 kPa (0.40 kgf/cm <sup>2</sup> , 5.7 psi)	52 kPa (0.53 kgf/cm <sup>2</sup> , 7.5 psi)	41 kPa (0.42 kgf/cm <sup>2</sup> , 5.9 psi)

 NOTE:

- The Specifications for the front-end attachment is for 2.96 m (9 ft 9 in) arm with PCSA 1.0 m<sup>3</sup> (1.3 yd<sup>3</sup>) bucket.
- 700, 800 mm (28, 31 in) grouser shoe, 600 mm (24 in) flat shoe and 760 mm (30 in) triangular shoe should not be used on gravel or rocky ground.
- \* The dimensions do not include the height of the shoe lug.

## SPECIFICATIONS

### Bucket Types and Applications

#### ZX250LC-6N

Bucket	Bucket Capacity m <sup>3</sup> (yd <sup>3</sup> )		Bucket Width mm (in) (With side cutter)	Application	Front-End Attachment		
	PCSA (Heaped)	CECE (Heaped)			2.5 m (8' 2") Arm	2.96 m (9' 9") Standard Arm	3.61 m (11' 10") Arm
Hoe Bucket	0.80 (1.05)	0.70	1080 (42.5")		●	●	●
	1.00 (1.31)	0.90	1260 (49.6")		●	●	●
	1.10 (1.44)	1.00	1350 (53.2")		○	○	○
	1.25 (1.64)	1.10	1490 (58.7")		○	○	□
	1.40 (1.83)	1.20	1630 (64.2")		□	-	-
Bucket reinforcement can be welded in four places upon customer's request	1.00 (1.31)	0.90	1260 (49.6")		●	●	●
	1.10 (1.44)	1.00	1350 (53.2")		○	○	○
Reinforced Hoe Bucket (HD Type)	1.00 (1.31)	0.90	1270 (50.0")		●	●	●
Reinforced Hoe Bucket HD Type (Transverse-Type-Pin-Used Type)	1.00 (1.31)	0.90	1270 (50.0")		●	●	●
Rock Bucket	0.92 (1.20)	0.80	1210 (47.6")		■	■	●
Ripper Bucket	0.80 (1.05)	0.70 (0.92)	1000 (39.4") (Without side cutter)		■	■	-
One Point Ripper	-	-	-		■	■	-
Clamshell Bucket		0.80 (1.05)	Bucket width 975 (38.4")	Side ditching	●	●	-

 NOTE:


- Symbols in the above table have the following meanings.
  - : General excavating
  - : Light duty excavating
  - : Rock digging
  - : Loading work
  - ◇ : Slope-finishing work
  - : Not applicable (not warrantable)
- Hoe bucket is applicable to the following types of work.
  - General excavating:  
For digging and loading operation of sand, gravel, clay, ordinary earth and so on.
  - Light duty excavating:  
For digging and loading operation of dry, loosened earth, sand, mud and so on.  
Their bulk density shall be less than 1.60 t/m<sup>3</sup> (2700 lb/yd<sup>3</sup>) as a standard.
  - Loading:  
For loading operation of dry, loosened earth and sand.  
Their bulk density shall be less than 1.10 t/m<sup>3</sup> (1850 lb/yd<sup>3</sup>) as a standard.
  - Rock digging:  
For digging/loading operation of mountain gravels, blasted rock, hard clay, soft rock and so on.

**IMPORTANT: Using inapplicable buckets may cause serious damage to the front structure such as boom, arm and hydraulic cylinders.**

## SPECIFICATIONS

### Specifications

#### ZX300LC-6N



MDAA-12-001


Model	ZX300LC-6N
Type of Front-End Attachment	3.11 m (10 ft 2 in) Arm
Bucket Capacity (Heaped)	PCSA 1.25 m <sup>3</sup> (1.64 yd <sup>3</sup> ), CECE 1.10 m <sup>3</sup>
Operating Weight	29200 kg (64400 lb)
Base Machine Weight	23000 kg (50800 lb)
Engine	Isuzu AQ-6HK1XASA-02S 186kW/1900 min <sup>-1</sup> (253 PS/1900 rpm)
A : Overall Width (Excluding back mirrors)	3190 mm (10 ft 6 in)
B : Cab Height	3110 mm (10 ft 2 in)
C : Rear End Swing Radius	3250 mm (10 ft 8 in)
D : Minimum Ground Clearance	*510 mm (20 in)
E : Counterweight Clearance	*1170 mm (3 ft 10 in)
F : Engine Cover Height	*2750 mm (9 ft 0 in)
G : Overall Width of Upperstructure	2990 mm (9 ft 10 in)
H : Undercarriage Length	4940 mm (16 ft 3 in)
I : Undercarriage Width	3190 mm (10 ft 6 in)
J : Sprocket Center to Idler Center	4052 mm (13 ft 4 in)
K : Track Shoe Width	600 mm (24 in) (Grouser shoe)
Ground Pressure	55 kPa (0.56 kgf/cm <sup>2</sup> , 8.0 psi)
Swing Speed	10.3 min <sup>-1</sup> (rpm)
Travel Speed (fast/slow)	5.5/3.3 km/h (3.4/2.0 mph)
Gradeability	35 ° (tanθ = 0.70)

NOTE: \* The dimensions do not include the height of the shoe lug.

# SPECIFICATIONS

## Working Ranges

ZX300LC-6N



Backhoe

MDAA-12-002

Category	2.42 m (7 ft 10 in) Arm		3.11 m (10 ft 2 in) Arm		3.76 m (12 ft 4 in) Arm	
	Backhoe		Backhoe		Backhoe	
Item	mm	ft-in	mm	ft-in	mm	ft-in
A: Maximum Digging Reach	10060	33' 0"	10710	35' 2"	11270	37' 0"
B: Maximum Digging Depth	*6530	*21' 5"	*7220	*23' 8"	*7870	*25' 10"
C: Maximum Cutting Height	*9910	*32' 6"	*10270	*33' 8"	*10470	*34' 4"
D: Maximum Dumping Height	*6980	*22' 11"	*7330	*24' 1"	*7540	*24' 9"
E: Overall Height	3450	11' 4"	3200	10' 6"	3380	11' 1"
F: Overall Length	10550	34' 7"	10660	35' 0"	10710	35' 2"
G: Minimum Swing Radius	4060	13' 4"	3900	12' 10"	3890	12' 9"

NOTE: \* The dimensions do not include the height of the shoe lug.



## SPECIFICATIONS

### Shoe Types and Applications

#### ZX300LC-6N

Shoe Width		600 mm (24") Grouser Shoe	700 mm (28") Grouser Shoe	800 mm (31") Grouser Shoe	600 mm (24") Flat Shoe	900 mm (35") Triangular Shoe
Application		For Ordinary Ground (Standard)	For Weak Footing (Option)	For Weak Footing (Option)	For Paved Road (Option)	For Weak Footing (Option)
Operating Weight	kg (lb)	29200 (64400)	29700 (65500)	30100 (66400)	30000 (66200)	30800 (68000)
Base Machine Weight	kg (lb)	23000 (50800)	23600 (52100)	24000 (53000)	23900 (52700)	24600 (54300)
Cab Height	mm (ft-in)	3110 (10' 2")	3110 (10' 2")	3110 (10' 2")	3120 (10' 3")	3180 (10' 5")
Minimum Ground Clearance	mm (ft-in)	* 510 (20")	* 510 (20")	* 510 (20")	550 (22")	* 510 (20")
Undercarriage Length	mm (ft-in)	4940 (16' 3")	4940 (16' 3")	4940 (16' 3")	4940 (16' 3")	4940 (16' 3")
Undercarriage Width	mm (ft-in)	3190 (10' 6")	3290 (10' 10")	3390 (11' 2")	3190 (10' 6")	3490 (11' 5")
Ground Pressure		55 kPa (0.56 kgf/cm <sup>2</sup> , 8.0 psi)	48 kPa (0.49 kgf/cm <sup>2</sup> , 7.0 psi)	42 kPa (0.43 kgf/cm <sup>2</sup> , 6.1 psi)	56 kPa (0.57 kgf/cm <sup>2</sup> , 8.1 psi)	38 kPa (0.39 kgf/cm <sup>2</sup> , 5.5 psi)

 **NOTE:**

- The Specifications for the front-end attachment is for 3.11 m (10 ft 2 in) arm with PCSA 1.25 m<sup>3</sup> (1.64 yd<sup>3</sup>) bucket.
- 700, 800 mm (28, 31 in) grouser shoe, 600 mm (24 in) flat shoe and 900 mm (35 in) triangular shoe should not be used on gravel or rocky ground.
- \* The dimensions do not include the height of the shoe lug.

## SPECIFICATIONS

### Bucket Types and Applications

#### ZX300LC-6N

Bucket	Bucket Capacity m <sup>3</sup> (yd <sup>3</sup> )		Bucket Width mm (in) (With side cutter)	Application	Front-End Attachment		
	PCSA (Heaped)	CECE (Heaped)			2.42 m (7' 11") Arm	3.11 m (10' 2") Arm	3.76 m (12' 4") Arm
Hoe Bucket	1.00 (1.31)	0.90	1260 (49.6")		●	●	●
	1.10 (1.44)	1.00	1350 (53.2")		●	●	●
	1.25 (1.64)	1.10	1490 (59.0")		●	●	●
	1.40 (1.83)	1.20	1630 (64.2")		○	○	□
	1.62 (2.12)	1.40	1830 (72.0")		□	-	-
Bucket reinforcement can be welded in four places upon customer's request	1.10 (1.44)	1.00	1350 (53.2")		●	●	●
	1.40 (1.83)	1.20	1630 (64.2")		○	○	□
Reinforced Hoe Bucket (HD Type)	1.10 (1.44)	1.00	1360 (53.5")		●	●	●
Rock Bucket	0.92 (1.20)	0.80	1210 (47.6")		■	■	-
Ripper Bucket	0.80 (1.05)	0.70 (0.92)	1000 (39.4") (Without side cutter)		■	■	-
One Point Ripper	-	-	-		■	■	-
Clamshell Bucket		0.80 (1.05)	Bucket width 975 (38.4")	Side ditching	●	●	-

 **NOTE:**


- Symbols in the above table have the following meanings.
  - : General excavating
  - : Light duty excavating
  - : Rock digging
  - : Loading work
  - ◇ : Slope-finishing work
  - : Not applicable (not warrantable)
- Hoe bucket is applicable to the following types of work.
  - General excavating:  
For digging and loading operation of sand, gravel, clay, ordinary earth and so on.
  - Light duty excavating:  
For digging and loading operation of dry, loosened earth, sand, mud and so on.  
Their bulk density shall be less than 1.60 t/m<sup>3</sup> (2700 lb/yd<sup>3</sup>) as a standard.
  - Loading:  
For loading operation of dry, loosened earth and sand.  
Their bulk density shall be less than 1.10 t/m<sup>3</sup> (1850 lb/yd<sup>3</sup>) as a standard.
  - Rock digging:  
For digging/loading operation of mountain gravels, blasted rock, hard clay, soft rock and so on.

**IMPORTANT:** Using inapplicable buckets may cause serious damage to the front structure such as boom, arm and hydraulic cylinders.

## SPECIFICATIONS

### Specifications

#### ZX350LC-6N



MDAA-12-011


Model	ZX350LC-6N
Type of Front-End Attachment	3.20 m (10 ft 6 in) Arm
Bucket Capacity (Heaped)	PCSA 1.4 m <sup>3</sup> (1.83 yd <sup>3</sup> ), CECE 1.2 m <sup>3</sup> (1.57 yd <sup>3</sup> )
Operating Weight	33900 kg (74800 lb)
Base Machine Weight	26000 kg (57400 lb)
Engine	Isuzu AQ-6HK1XASA-01 202 kW/1900 min <sup>-1</sup> (275 PS/1900 rpm)
A : Overall Width (Excluding back mirrors)	3190 mm (10 ft 6 in)
B : Cab Height	3150 mm (10 ft 4 in)
C : Rear End Swing Radius	3600 mm (11 ft 10 in)
D : Minimum Ground Clearance	*500 mm (20 in)
E : Counterweight Clearance	*1160 mm (3 ft 10 in)
F : Engine Cover Height	*2830 mm (9 ft 3 in)
G : Overall Width of Upperstructure	2990 mm (9 ft 10 in)
H : Undercarriage Length	4950 mm (16 ft 3 in)
I : Undercarriage Width	3190 mm (10 ft 6 in)
J : Sprocket Center to Idler Center	4050 mm (13 ft 3 in)
K : Track Shoe Width	600 mm (24 in) (Grouser shoe)
Ground Pressure	64 kPa (0.65 kgf/cm <sup>2</sup> , 9.1 psi)
Swing Speed	10.7 min <sup>-1</sup> (rpm)
Travel Speed (fast/slow)	5.0/3.2 km/h (3.1/2.0 mph)
Gradeability	35 ° (tanθ = 0.70)

NOTE: \* The dimensions do not include the height of the shoe lug.

# SPECIFICATIONS

## Working Ranges (Grouser Shoe)

ZX350LC-6N



MDAA-12-012

Model		ZX350LC-6N					
Item	Category	2.67 m (8 ft 9 in) Arm		3.2 m (10 ft 6 in) Arm		4.0 m (13 ft 2 in) Arm	
		mm	ft-in	mm	ft-in	mm	ft-in
A : Maximum Digging Reach		10570	34' 8"	11100	36' 5"	11860	38' 11"
B : Maximum Digging Depth		*6840	*22' 5"	*7380	*24' 3"	*8180	*26' 10"
C : Maximum Cutting Height		*9990	*32' 9"	*10360	*34' 0"	*10750	*35' 3"
D : Maximum Dumping Height		*6940	*22' 9"	*7240	*23' 9"	*7630	*25' 0"
E : Overall Height		3470	11' 5"	3270	10' 9"	3600	11' 10"
F : Overall Length		11350	37' 3"	11220	36' 10"	11310	37' 1"
G : Minimum Swing Radius		4610	15' 2"	4460	14' 8"	4470	14' 8"

NOTE: \* The dimensions do not include the height of the shoe lug.

## SPECIFICATIONS

### Shoe Types and Applications

#### ZX350LC-6N

Shoe Width		600 mm (24") Grouser Shoe	700 mm (28") Grouser Shoe	800 mm (31") Grouser Shoe
Application		For Ordinary Ground (Standard)	For Weak Footing (Option)	For Weak Footing (Option)
Operating Weight	kg (lb)	33900 (74800)	35800 (79000)	34900 (77000)
Base Machine Weight	kg (lb)	26000 (57400)	27900 (61600)	27000 (59600)
Cab Height	mm (ft.in)	3150 (10' 4")	3150 (10' 4")	3150 (10' 4")
Minimum Ground Clearance	mm (ft.in)	* 500 (20")	* 500 (20")	* 500 (20")
Undercarriage Length	mm (ft.in)	4950 (16' 3")	4950 (16' 3")	4950 (16' 3")
Undercarriage Width	mm (ft.in)	3190 (10' 6")	3290 (10' 10")	3390 (11' 2")
Ground Pressure		64 kPa (0.65 kgf/cm <sup>2</sup> , 9.3 psi)	58 kPa (0.59 kgf/cm <sup>2</sup> , 8.4 psi)	49 kPa (0.50 kgf/cm <sup>2</sup> , 7.1 psi)

 **NOTE:**

- The Specifications for the front-end attachment is for 3.2 m (10 ft 6 in) arm with PCSA 1.4 m<sup>3</sup> (1.83 yd<sup>3</sup>) bucket.
- 700, 800 mm (28, 31 in) grouser shoe should not be used on gravel or rocky ground.
- \* The dimensions do not include the height of the shoe lug.

## SPECIFICATIONS

### Bucket Types and Applications

#### ZX350LC-6N

Bucket	Bucket Capacity m <sup>3</sup> (yd <sup>3</sup> )		Bucket Width mm (in) (With side cutter)	Application	Front-End Attachment			
	PCSA (Heaped)	CECE (Heaped)			ZX350LC-5N			
					2.67 m (8' 9") Arm	3.2 m (10' 6") Arm	4.0 m (13' 2") Arm	
Hoe Bucket	1.15 (1.50)	1.00	1230 (48.4")		●	●	●	
	1.40 (1.83)	1.20	1410 (55.5")		●	●	●	
	1.62 (2.12)	1.40	1590 (62.6")		○	○	-	
	1.86 (2.43)	1.60	1640 (64.6")		□	-	-	
	(Super V)	1.40 (1.83)	1.20	1410 (55.5")		●	●	○
	(Transverse-Type-Pin)	1.40 (1.83)	1.20	1410 (55.5")		●	●	○
Bucket reinforcement can be welded in four places upon customers request	1.40 (1.83)	1.20	1410 (55.5")		●	●	○	
	1.62 (2.12)	1.40	1590 (62.6")		○	○	-	
Rock Bucket	1.15 (1.50)	1.00	1200 (47.2")		■	■	-	
(Super V)	1.38 (1.81)	1.20	1360 (53.5")		●	●	-	
(Transverse-Type-Pin)	1.38 (1.81)	1.20	1360 (53.5")		●	●	-	
(Super V)	1.50 (1.96)	1.30	1470 (57.9")		○	○	-	
(Transverse-Type-Pin)	1.50 (1.96)	1.30	1470 (57.9")		○	○	-	
Ripper Bucket	0.90 (1.18)	0.80 (1.05)	1010 (39.8") (Without side cutter)		■	■	-	
One Point Ripper	-	-	-		■	■	-	
Clamshell Bucket	1.00 (1.31)		Bucket width 975 (38.4")	Side ditching	●	●	○	

 **NOTE:**


- Symbols in the above table have the following meanings.
  - : General excavating
  - : Light duty excavating
  - : Rock digging
  - : Loading work
  - ◇ : Slope-finishing work
  - : Not applicable (not warrantable)
- Hoe bucket is applicable to the following types of work.
  - General excavating:  
For digging and loading operation of sand, gravel, clay, ordinary earth and so on.
  - Light duty excavating:  
For digging and loading operation of dry, loosened earth, sand, mud and so on.  
Their bulk density shall be less than 1.60 t/m<sup>3</sup> (2700 lb/yd<sup>3</sup>) as a standard.
  - Loading:  
For loading operation of dry, loosened earth and sand.  
Their bulk density shall be less than 1.10 t/m<sup>3</sup> (1850 lb/yd<sup>3</sup>) as a standard.
  - Rock digging:  
For digging/loading operation of mountain gravels, blasted rock, hard clay, soft rock and so on.

**IMPORTANT:** Using inapplicable buckets may cause serious damage to the front structure such as boom, arm and hydraulic cylinders.

## SPECIFICATIONS

### Specifications

#### ZX380LC-6N



MDAA-12-011


Model	ZX380LC-6N
Type of Front-End Attachment	3.20 m (10 ft 6 in) Arm
Bucket Capacity (Heaped)	PCSA 1.4 m <sup>3</sup> (1.83 yd <sup>3</sup> ), CECE 1.2 m <sup>3</sup> (1.57 yd <sup>3</sup> )
Operating Weight	37400 kg (82500 lb)
Base Machine Weight	29000 kg (64000 lb)
Engine	Isuzu AQ-6HK1XASA-01 202 kW/1900 min <sup>-1</sup> (275 PS/1900 rpm)
A : Overall Width (Excluding back mirrors)	3390 mm (11 ft 2 in)
B : Cab Height	3150 mm (10 ft 4 in)
C : Rear End Swing Radius	3600 mm (11 ft 10 in)
D : Minimum Ground Clearance	*500 mm (20 in)
E : Counterweight Clearance	*1160 mm (3 ft 10 in)
F : Engine Cover Height	*2830 mm (9 ft 3 in)
G : Overall Width of Upperstructure	2990 mm (9 ft 10 in)
H : Undercarriage Length	4950 mm (16 ft 3 in)
I : Undercarriage Width	3390 mm (11 ft 2 in)
J : Sprocket Center to Idler Center	4050 mm (13 ft 3 in)
K : Track Shoe Width	800 mm (31 in) (Grouser shoe)
Ground Pressure	53 kPa (0.54 kgf/cm <sup>2</sup> , 7.7 psi)
Swing Speed	10.7 min <sup>-1</sup> (rpm)
Travel Speed (fast/slow)	5.0/3.2 km/h (3.1/2.0 mph)
Gradeability	35 ° (tanθ = 0.70)

NOTE: \* The dimensions do not include the height of the shoe lug.

## SPECIFICATIONS


### Working Ranges (Grouser Shoe)

ZX380LC-6N



MDAA-12-012

Model		ZX380LC-6N			
Item	Category	3.2 m (10 ft 6 in) Arm		4.0 m (13 ft 2 in) Arm	
		mm	ft·in	mm	ft·in
A : Maximum Digging Reach		11100	36' 5"	11860	38' 11"
B : Maximum Digging Depth		*7380	*24' 3"	*8180	*26' 10"
C : Maximum Cutting Height		*10360	*34' 0"	*10750	*35' 3"
D : Maximum Dumping Height		*7240	*23' 9"	*7630	*25' 0"
E : Overall Height		3270	10' 9"	3600	11' 10"
F : Overall Length		11220	36' 10"	11290	37' 1"
G : Minimum Swing Radius		4460	14' 8"	4470	14' 8"

 NOTE: \* The dimensions do not include the height of the shoe lug.



## SPECIFICATIONS

### Shoe Types and Applications

#### ZX380LC-6N

Shoe Width		700 mm (28") Grouser Shoe	800 mm (31") Grouser Shoe
Application		For Weak Footing (Option)	For Weak Footing (Standard)
Operating Weight	kg (lb)	36100 (79600)	37400 (82500)
Base Machine Weight	kg (lb)	27800 (61300)	29000 (64000)
Cab Height	mm (ft·in)	3150 (10' 4")	3150 (10' 4")
Minimum Ground Clearance	mm (ft·in)	* 500 (20")	* 500 (20")
Undercarriage Length	mm (ft·in)	4950 (16' 3")	4950 (16' 3")
Undercarriage Width	mm (ft·in)	3290 (10' 10")	3390 (11' 2")
Ground Pressure		58 kPa (0.59 kgf/cm <sup>2</sup> , 8.4 psi)	53 kPa (0.54 kgf/cm <sup>2</sup> , 7.7 psi)

 **NOTE:**

- The Specifications for the front-end attachment is for 3.2 m (10 ft 6 in) arm with PCSA 1.4 m<sup>3</sup> (1.83 yd<sup>3</sup>) bucket.
- 700, 800 mm (28, 31 in) grouser shoe should not be used on gravel or rocky ground.
- \* The dimensions do not include the height of the shoe lug.

## SPECIFICATIONS

### Bucket Types and Applications

#### ZX380LC-6N

Bucket	Bucket Capacity m <sup>3</sup> (yd <sup>3</sup> )		Bucket Width mm (in) (With side cutter)	Application	Front-End Attachment		
	PCSA (Heaped)	CECE (Heaped)			ZX350LC-5N		
					2.67 m (8' 9") Arm	3.2 m (10' 6") Arm	4.0 m (13' 2") Arm
Hoe Bucket  (Super V) (Transverse-Type-Pin)	1.15 (1.50)	1.00	1230 (48.4")		●	●	●
	1.40 (1.83)	1.20	1410 (55.5")		●	●	●
	1.62 (2.12)	1.40	1590 (62.6")		○	○	□
	1.86 (2.43)	1.60	1640 (64.6")		□	-	-
	1.40 (1.83)	1.20	1410 (55.5") (Without side cutter)		●	●	●
	1.40 (1.83)	1.20	1410 (55.5")		●	●	●
Bucket reinforcement can be welded in four places upon customers request	1.40 (1.83)	1.20	1410 (55.5")		●	●	●
	1.62 (2.12)	1.40	1590 (62.6")		○	○	□
Rock Bucket  (Super V) (Transverse-Type-Pin) (Super V) (Transverse-Type-Pin)	1.15 (1.50)	1.00	1200 (47.2")		■	■	-
	1.38 (1.81)	1.20	1360 (53.5")		●	●	-
	1.38 (1.81)	1.20	1360 (53.5")		●	●	-
	1.50 (1.96)	1.30	1470 (57.9")		○	○	-
	1.50 (1.96)	1.30	1470 (57.9")		○	○	-
Ripper Bucket	0.90 (1.18)	0.80 (1.05)	1010 (39.8") (Without side cutter)		■	■	-
One Point Ripper	-	-	-		■	■	-
Clamshell Bucket	1.00 (1.31)		Bucket width 975 (38.4")	Side ditching	●	●	○

 **NOTE:**

- Symbols in the above table have the following meanings.
  - : General excavating
  - : Light duty excavating
  - : Rock digging
  - : Loading work
  - ◇ : Slope-finishing work
  - : Not applicable (not warrantable)
- Hoe bucket is applicable to the following types of work.
  - General excavating:  
For digging and loading operation of sand, gravel, clay, ordinary earth and so on.
  - Light duty excavating:  
For digging and loading operation of dry, loosened earth, sand, mud and so on.  
Their bulk density shall be less than 1.60 t/m<sup>3</sup> (2700 lb/yd<sup>3</sup>) as a standard.
  - Loading:  
For loading operation of dry, loosened earth and sand.  
Their bulk density shall be less than 1.10 t/m<sup>3</sup> (1850 lb/yd<sup>3</sup>) as a standard.
  - Rock digging:  
For digging/loading operation of mountain gravels, blasted rock, hard clay, soft rock and so on.

**IMPORTANT: Using inapplicable buckets may cause serious damage to the front structure such as boom, arm and hydraulic cylinders.**

## OPTIONAL ATTACHMENTS AND DEVICES

### PAD CRAWLER SHOE

---

#### Using Pad Crawler Shoe

##### ZX130-6N


Pad crawler is a track link on which a rubber pad is installed so the machine does not damage road surfaces when traveling. Be sure to observe all precautions for handling pad crawler. Avoid operating the machine in the following conditions:

##### Forbidden Operations

Do not operate on sharp, rocky, uneven surfaces, such as river rock, gravel, etc.

Do not allow engine oil, gasoline, etc. to remain on the track, and avoid traveling in oil in order to reduce the danger of slipping.

While raising the machine using the front attachment do not allow the other side track to drive, possibly causing personal injury, damaging or displacing pad crawler.



M107-05-051

## OPTIONAL ATTACHMENTS AND DEVICES

### PAD CRAWLER SHOE

---

#### Traveling and Other Cautions

Do not keep the pad crawler shoe under direct sunlight for more than three months.


Avoid reckless steering operations on concrete road to the extent possible, as this will cause wear to the shoe lug. Also, avoid running on asphalt road of more than 60 °C (140 °F) in temperature, as this will cause wear to the shoe as well as damage to the road surface.

Ease the machine down from the jacked-up position. Do not let it drop.

Pad crawler has large friction force. Therefore to avoid damaging the pad crawler slowly operate the control levers to gradually turn the machine.

After raising one side track with the front attachment, slowly lower the pad crawler equipped machine.

If the pad crawler becomes severely damaged, contact your nearest Hitachi Dealer for replacement.



M107-05-052

## OPTIONAL ATTACHMENTS AND DEVICES

### PAD CRAWLER SHOE

#### Transporting

##### Transporting

**⚠ CAUTION:** Fasten chains or cables to the machine frame. Do not place chains or cables over or against the hydraulic lines or hoses.


1. Place blocks in front of and behind the tracks.
2. Fasten each corner of the machine and front attachment to the trailer with a chain or cable.



M107-06-013

#### Precautions for Transporting Machines with Pad Crawler Shoes

When transporting a machine with pad crawler shoes, be sure to fasten the right and left track frames securely to the flatbed with wire ropes and soft protectors, as shown. Do not allow wire ropes to come into direct contact with pad crawler shoes.



M102-06-004

## OPTIONAL ATTACHMENTS AND DEVICES

### PAD CRAWLER SHOE

#### Check Track Sag --- every 50 hours


Swing the upperstructure 90 ° and lower the bucket to raise the track off the ground as shown.


Keep the angle between the boom and arm 90 to 110 ° and position the bucket's round side on the ground. Place blocks under the machine frame to support the machine. Rotate the raised track in reverse two full rotations and then forward two full rotations.

Measure distance (A) at the middle of the track frame from the bottom of the track frame to the back face of the track shoe.


#### Track sag specifications

Model	A
ZX130-6N	250 to 280 mm (9.8 to 11.0 in)

 **NOTE:** Check track sag after thoroughly removing soil stuck on the track area by washing.



M104-07-067



M107-07-068

#### Adjust Track Sag

##### Precautions for Adjusting Track Sag

1. If track sag is not within specifications, loosen or tighten the track following the procedures shown on the next page.
2. When adjusting track sag, lower the bucket to the ground to raise one track off the ground. Repeat this procedure to raise the other track. Each time, be sure to place blocks under the machine frame to support the machine.
3. After adjusting track sag of both tracks, move the machine back and forth several times.
4. Check track sag again. If track sag is not within specifications, repeat adjustment until correct sag is obtained.

## OPTIONAL ATTACHMENTS AND DEVICES

### PAD CRAWLER SHOE

#### Loosen the Track

**CAUTION:** Do not loosen valve (1) quickly or loosen it too much as high-pressure grease in the adjusting cylinder may spout out. Loosen carefully, keeping body parts and face away from valve (1). Never loosen grease fitting (2).


**IMPORTANT:** When gravel or mud is packed between sprockets and track links, remove it before loosening.

1. To loosen the track, slowly turn valve (1) counterclockwise using long socket 19; grease will escape from the grease outlet.
2. Between 1 to 1.5 turns of valve (1) is sufficient to loosen the track.
3. If grease does not drain smoothly, slowly rotate the raised track.
4. When proper track sag is obtained, turn valve (1) clockwise and tighten to 90 N·m (9 kgf·m, 66 lbf·ft).


#### Tighten the Track

**CAUTION:** It is abnormal if the track remains tight after turning valve (1) counterclockwise or if the track is still loose after charging grease to fitting (2). In such cases, NEVER ATTEMPT TO DISASSEMBLE the track or track adjuster, because of dangerous high-pressure grease inside the track adjuster. See your authorized dealer immediately.

To tighten the track, connect a grease gun to grease fitting (2) and add grease until the sag is within specifications.



M107-07-075



M104-07-119

## OPTIONAL ATTACHMENTS AND DEVICES

### LONG ARM

#### Long Arm Operation --- If Equipped

##### ZX130-6N

1. The optional [3.01 m (9' 11")] long arm is only for light works such as loam loading, sludge handling, etc.. Do not use it for heavy works such as digging gravel. When the arm is used for digging, apply shallow cut to the ground to avoid tough digging, or arm damage may result.
2. When the machine is equipped with the [3.01 m (9' 11")] long arm, the hoe-bucket size must be limited to the followings due to stability and strength of the machine;
  - \* PCSA 0.45 m<sup>3</sup> (0.59 yd<sup>3</sup>)
  - PCSA 0.50 m<sup>3</sup> (0.65 yd<sup>3</sup>)
  - \* with 700 mm (28 in) shoe
3. When the machine is equipped with the long arm, connect the arm cylinder end to:
  - Pin bore A (when the machine is in operation)
  - Pin bore B (when the machine is transported)

**IMPORTANT: Connect the arm cylinder rod end to pin bore B only when the machine is transported. Do not operate the digging or loading function with the arm cylinder connected to pin bore B as the bucket may hit the cab accidentally with this connection.**

When transporting the machine, follow the procedure shown below to convert it into the transporting posture.

- (a) Position the bucket cylinder with rod retracted a little from the fully extended position.
- (b) Position the arm cylinder with rod retracted a little from the fully extended position.
- (c) Lower the boom until the arm top comes into contact with the ground.

Unit: mm (ft·in)

Arm Cylinder Rod End Connected To:	Height of Front Attachment (H)	
	ZX130-6N	
	Without Bucket	With Bucket
Pin Bore A	2830 (9' 3")	3120 (10' 3")
Pin Bore B	2560 (8' 5")	2700 (8' 10")

Dimensions include shoe lug height.



M163-05-001



# OPTIONAL ATTACHMENTS AND DEVICES

## BLADE


### Blade Lever

#### ZX130-6N

Use blade lever (1) on the operator's right to raise and lower the blade.

When the lever is released, it automatically returns to neutral, keeping the blade in its position until the lever is operated again.

- 1- Blade Lever
- 2- Blade Raise
- 3- Neutral
- 4- Blade Lower



MDAA-13-001

### Precautions for Blade Operation

This blade is designed as a light service attachment for the hydraulic excavator. Please keep the following points in mind:

1. This blade is designed to be used for dozing work only. Do not attempt to dig deeply with the blade. Doing so will damage not only the blade but the undercarriage as well.
2. Do not apply intensive or uneven loads. Never apply high-speed impact to the blade by running the machine into a load.
3. Jacking up the machine with this blade, the surface beneath the blade comes under high pressure, increasing the risk of surface collapse.  
  
Always be sure that the surface is strong enough to support the weight of the machine during operation.  
  
Avoid dangerously uneven distribution of weight on the blade by maintaining even contact between the blade and the ground.
4. Never use this blade as an outrigger.
5. Avoid contact between the bucket and the blade while digging.



M155-14-008

## OPTIONAL ATTACHMENTS AND DEVICES

### BLADE

#### Avoid Hitting Blade with Front-End Attachment

When operating the machine with the blade positioned towards the front, the bucket or boom cylinder may come into contact with the blade if you are not careful. Be sure to prevent this from happening.



MZX5-12-025



MZX5-12-026

#### Avoid Hitting Blade with Bucket

When crowding the arm into a traveling or transporting position, be careful not to let the bucket hit the blade.



MZX5-12-026

#### Avoid Striking the Blade into a Rock

Do not attempt to strike large rocks with the blade, as doing so will damage the blade and the blade cylinders, shortening their operating lives.



MZX5-12-027

## OPTIONAL ATTACHMENTS AND DEVICES


### BLADE

#### Blade Maintenance

##### Greasing --- every 250 hours

Lubricate all fittings shown in the figure.

- Blade Joint Pins (2 points)
- Blade Cylinder Rod (2 points)
- Blade Cylinder Bottom (2 points)



M175-13-002

#### Transportation Figure for Machine Equipped with Blade

When transporting the machine equipped with a blade and a long arm front attachment on a trailer, place the blade in the opposite position toward the front attachment. Otherwise, the bucket may come in contact with the blade.




M175-13-005

## OPTIONAL ATTACHMENTS AND DEVICES

### BLADE


#### Specifications

##### ZX130-6N with Blade



MDC1-13-005

Model	ZX130-6N with Blade
Type of Front-End Attachment	2.52 m (8 ft 3 in) Arm
Bucket Capacity (Heaped)	PCSA 0.50 m <sup>3</sup> (0.65 yd <sup>3</sup> ), CECE 0.45 m <sup>3</sup>
Operating Weight	13500 kg (29800 lb)
Base Machine Weight	11000 kg (24300 lb)
Engine	Isuzu AR-4JJ1XASA-02 74.9 kW/200 min <sup>-1</sup> (102 PS/2000 rpm)
A: Overall Width (Excluding back mirrors)	2490 mm (8 ft 2 in)
B: Cab Height	2790 mm (9 ft 2 in)
B': Cab Top Handrail Height	2870 mm (9 ft 5 in)
C: Rear End Swing Radius	2190 mm (7 ft 2 in)
D: Minimum Ground Clearance	*410 mm (1 ft 4 in)
E: Counterweight Clearance	*840 mm (2 ft 9 in)
F: Engine Cover Height	*2270 mm (7 ft 5 in)
F': Handrail Height	2870 mm (9 ft 5 in)
G: Overall Width of Upperstructure	2460 mm (8 ft 1 in)
H: Undercarriage Length	3580 mm (11 ft 9 in)
I: Undercarriage Width	2490 mm (8 ft 2 in)
J: Sprocket Center to Idle Center	2880 mm (9 ft 5 in)
K: Track Shoe Width	500 mm (Grouser Shoe) (20 in)
Ground Pressure	43 kPa (0.44 kgf/cm <sup>2</sup> , 6.2 psi)
Swing Speed	13.3 min <sup>-1</sup> (rpm)
Travel Speed (fast/slow)	5.5/3.3 km/h (3.4/2.1 mph)
Gradeability	35 ° (tanθ = 0.70)


 NOTE: \* The dimensions do not include the height of the shoe lug.

# OPTIONAL ATTACHMENTS AND DEVICES

## BLADE

### Working Ranges

#### ZX130-6N with Blade



MDC1-13-006

Model		ZX130-6N with Blade	
Item	Category	2.52 m (8 ft 3 in) Arm	3.01 m (9 ft 11 in) Arm
A: Maximum Digging Reach	mm (ft-in)	8300 (27' 3")	8770 (28' 9")
B: Maximum Digging Depth	mm (ft-in)	5540 (18' 2")	6030 (19' 9")
C: Maximum Cutting Height	mm (ft-in)	8600 (28' 3")	8930 (29' 4")
D: Maximum Dumping Height	mm (ft-in)	6190 (20' 4")	6520 (21' 5")
E: Overall Height	mm (ft-in)	2870 (9' 5")	*2870 (9' 5")
F: Overall Length	mm (ft-in)	8030 (26' 4")	*8040 (26' 5")
G: Minimum Swing Radius	mm (ft-in)	2400 (7' 11")	2620 (8' 7")
H: Max. Raising Height	mm (ft-in)	480 (1' 7")	
I: Max. Digging Depth	mm (ft-in)	530 (1' 9")	
J: Blade Angle	degree	25	

**NOTE:** The dimensions do not include height of the shoe lug (except Item E). \* The dimensions asterisked are for transport pin position.

## OPTIONAL ATTACHMENTS AND DEVICES

### BLADE

#### Shoe Types and Applications

##### ZX130-6N with Blade

Shoe Width	500 mm (20 in) Grouser Shoe	600 mm (24 in) Grouser Shoe	700 mm (28 in) Grouser Shoe
Application	For Ordinary Ground (Standard)	For Weak Footing (Option)	For Weak Footing (Option)
Operating Weight	kg (lb)	13500 (29800)	13800 (30500)
Base Machine Weight	kg (lb)	11000 (24300)	11300 (25000)
Cab Height	mm (ft-in)	2870 (9' 5")	2870 (9' 5")
Minimum Ground Clearance	mm (ft-in)	*410 (16")	*410 (16")
Undercarriage Length	mm (ft-in)	3580 (11' 9")	3580 (11' 9")
Undercarriage Width	mm (ft-in)	2490 (8' 2")	2590 (8' 6")
Ground Pressure	43 kPa (0.44 kgf/cm <sup>2</sup> , 6.2 psi)	36 kPa (0.37 kgf/cm <sup>2</sup> , 5.2 psi)	31 kPa (0.32 kgf/cm <sup>2</sup> , 4.5 psi)

 NOTE:

- The specifications for the front-end attachment is for 2.52 m (8 ft 3 in) arm with PCSA 0.50 m<sup>3</sup> (0.65 yd<sup>3</sup>) bucket.
- Other than 500 mm (20 in) grouser shoe should not be used on gravel or rocky ground. Operating or digging on gravel ground may cause serious damage to shoe, shoe bolts and other parts such as rollers.
- \*The dimensions do not include the height of the shoe lug.

## OPTIONAL ATTACHMENTS AND DEVICES

### BUCKET TEETH

---

#### Bucket Teeth (Transverse-Type-Pin-Used Type)

ZX210-6N, 210LC-6N, 250LC-6N, 300LC-6N, 350LC-6N,  
380LC-6N


#### Replacement Procedure

**CAUTION:** Guard against injury from flying pieces of metal. Wear goggles or safety glasses.

1. Securely lower the bucket to the ground.
2. Use hammer (3) and drift (2) to drive out transverse-type lock pin (1) to remove tooth (4).

**NOTE:** Be sure to use drift (2) thinner than lock pin (1).

3. Clean shank (5) surface. Attach a new tooth (4) onto shank (5). Insert lock pin (1) as deep as it goes. Then, drive lock pin (1) using hammer (3) and drift (2) to securely lock tooth (4).



M157-14-013

# OPTIONAL ATTACHMENTS AND DEVICES

## ATTACHMENT PEDAL

### Attachment Pedal (Hydraulic Breaker) (Optional)


The breaker can be operated using attachment pedal (1) located on the right front of the seat, as illustrated.

**CAUTION:** Be sure to lock attachment pedal (1) with pedal lock (2) when attachment pedal (1) is not in use. Do not allow your foot to rest on pedal (1) when attachment pedal (1) is not in use. When changing the position of pedal lock (2), pull the pilot control shut-off lever up to the LOCK position.


1. Select the hydraulic breaker icon on monitor work mode screen (3). Refer to the descriptions about the work mode on page 5-14 for work mode setting procedures.
2. Move pedal lock (2) forward to the UNLOCK position.
3. Push down on attachment pedal (1) to operate the breaker.

Loosen stopper bolt (4) until stopper bolt (4) comes in contact with the bracket in attachment pedal (1) neutral to prevent attachment pedal (1) from being stepped backward.


4. Remove foot from attachment pedal (1) to stop the breaker.
5. Always keep attachment pedal (1) locked with pedal lock (2) when attachment pedal (1) is not in use.



MDAA-05-001




MDAA-01-101EN



M1J1-13-002

Locked Attachment Pedal



M1J1-13-003

Unlocked Attachment Pedal



# OPTIONAL ATTACHMENTS AND DEVICES


## ATTACHMENT PEDAL

### Attachment Pedal (Hydraulic Crusher) (Optional)


The crusher can be operated using attachment pedal (1) located on the right front of the seat, as illustrated.

**CAUTION:** Be sure to lock attachment pedal (1) with pedal lock (2) when attachment pedal (1) is not in use. Do not allow your foot to rest on pedal (1) when attachment pedal (1) is not in use. When changing the position of pedal lock (2) pull the pilot control shut-off lever up to the LOCK position.


1. Select the proper hydraulic crusher icon on work mode screen (3). Refer to the descriptions about the work mode on page 5-14 for work mode setting procedures.
2. Move pedal lock (2) forward to the UNLOCK position.
3. Push down on attachment pedal (1) either forward or backward to open or close the crusher.
4. Remove foot from attachment pedal (1) to stop the crusher.
5. Always keep attachment pedal (1) locked with pedal lock (2) when attachment pedal (1) is not in use.



MDAA-05-001




MDAA-01-101EN



Locked Attachment pedal (Crusher)

M1J1-13-012



Unlocked Attachment pedal (Crusher)

M1J1-13-006

## **OPTIONAL ATTACHMENTS AND DEVICES**

### **HYDRAULIC BREAKER, HYDRAULIC CRUSHER AND QUICK COUPLER**

---

#### **Hydraulic Breaker, Hydraulic Crusher and Quick Coupler**

##### **Selecting a Breaker, Crusher or Quick Coupler**

Select a breaker, crusher or quick coupler with the correct size and weight for your machine, considering the stability of the machine, hydraulic oil pressure and flow rate of the breaker, crusher or quick coupler. See your authorized dealer for correct breaker information.

##### **Precautions for Operation**

Thoroughly read and understand the operator's manuals of the breaker, crusher and quick coupler.

To avoid damaging the machine, hydraulic breaker, crusher or quick coupler, follow the precautions given below.

##### **Precautions for Connecting Breaker, Crusher or Quick Coupler Piping.**

Do not allow impurities to enter into the system when switching the breaker, crusher or the quick coupler with the bucket.

When the breaker, crusher or quick coupler is not used, apply the cover to the pipe opening on the arm top and install the plug or cap into the hose end of the breaker, crusher or the quick coupler to prevent impurities from entering the system.

Be sure to provide spare caps and plugs in the tool box so that they will be available when needed.


After connecting, check the connecting seal fitting for oil leakage, and pipe clamp bolts for looseness.

# OPTIONAL ATTACHMENTS AND DEVICES

## HYDRAULIC BREAKER, HYDRAULIC CRUSHER AND QUICK COUPLER

### Piping for Breaker and Crusher

#### Operational Procedures for Stop Valves and Selector Valve.




Stop Valves A	Close
Stop Valves A	Open

Stop Valve A

Close: When attachment is detached or not in use.

Open: When using attachment

M1U1-05-007



MDAA-05-006

## **OPTIONAL ATTACHMENTS AND DEVICES**

### **HYDRAULIC BREAKER, HYDRAULIC CRUSHER AND QUICK COUPLER**

---

---

#### **Secondary Relief Pressure Adjustment**

Depending on the breaker model, the secondary relief valve relief set pressure differs.

Consult your nearest Hitachi dealer for installing a breaker.

## OPTIONAL ATTACHMENTS AND DEVICES

### HYDRAULIC BREAKER, HYDRAULIC CRUSHER AND QUICK COUPLER

#### Precautions for Breaker Operation

**⚠ WARNING:** Machine stability is reduced as the breaker is much heavier than the bucket. When using a breaker, the machine is more likely to tip over. Also, flying objects may hit the cab or other parts of the machine. Observe the following precautions and take any other precautions necessary to prevent accidents and machine damage from occurring.

#### Avoid Hitting Objects with Breaker

The breaker is heavier than the bucket, causing the breaker to lower faster.

Take care not to hit any objects with breaker. Doing so will result in damage to the breaker, the front attachment, and/or the upperstructure. Always move (lower) the breaker slowly to position the tip of the chisel on the object to be broken before starting breaker operation.



MZX5-13-019

#### Avoid Moving Objects with Breaker

Do not use the breaker and/or the bracket to move objects. Damage to the boom, arm, and/or breaker may result.

Do not use the breaker and/or the swing function to move objects. Damage to the boom, arm, and/or breaker may result.




MZX5-13-020

#### Avoid Operating Breaker at Cylinder Stroke End

Always operate the breaker by positioning the cylinder rods 100 mm or longer before the stroke end position.

When operating the breaker with cylinders fully retracted or extended, hydraulic cylinders, arm or boom may be damaged.




MZX5-13-021

## OPTIONAL ATTACHMENTS AND DEVICES

### HYDRAULIC BREAKER, HYDRAULIC CRUSHER AND QUICK COUPLER

#### Stop Operation If Breaker Hydraulic Hoses Jump Abnormally


Change in breaker accumulator pressure or a damaged accumulator will cause abnormal hose jumping and may cause breaker and/or machine damage. Immediately stop the machine operation. Failure to do so may result in serious failure in the hydraulic system including pumps. Contact your nearest Hitachi dealer.



M104-05-058

#### Do Not Operate the Breaker in Water


Doing so will cause rust and seal damage, resulting in damage to the hydraulic system components. Rust, dust and water may enter into the hydraulic oil through the broken seal, damage to the hydraulic system may result.



MZX5-13-017

#### Do Not Use Breaker for Lifting Operation


The machine tipping over and/or breaker damage may result.



MZX5-13-022

#### Do Not Operate the Breaker to the Side of the Machine

The machine may become unstable and undercarriage component life may shorten as a result from operating the breaker to the side of the machine.




MZX5-13-023

## OPTIONAL ATTACHMENTS AND DEVICES

### HYDRAULIC BREAKER, HYDRAULIC CRUSHER AND QUICK COUPLER


#### Operate the Hydraulic Excavator Carefully to Avoid Hitting the Boom

When the arm rolled in with the breaker equipped, the chisel may come in contact with the boom.



#### Do Not Operate Breaker with the Arm Positioned Vertically

Excessive vibration to the arm cylinder will occur, causing oil leakage.




#### Press the Breaker so Chisel Axis Is Positioned Vertically Over the Object

Failure to do so may damage the chisel or may cause a piston to seize.




#### Do Not Continuously for Operate the Breaker Longer than One Minute

Failure to do so may result in premature wear of the chisel. If an object cannot be broken within one minute, apply the chisel to other locations for less than one minute in each location.



**IMPORTANT:** When the breaker is operated longer than one minute, a diagonal line will be displayed on work mode display (1) and the buzzer will sound. If so, immediately stop operation and wait a while to restart.



MDC1-13-001


## OPTIONAL ATTACHMENTS AND DEVICES

### HYDRAULIC BREAKER, HYDRAULIC CRUSHER AND QUICK COUPLER

---

#### **Raising the Front Part of the Undercarriage by Pressing Down the Breaker May Cause Damage to the Front Attachment**

Never raise the front edge of the undercarriage higher than 150 mm (6 in) by pressing the breaker down.



M147-05-016



## OPTIONAL ATTACHMENTS AND DEVICES

### HYDRAULIC BREAKER, HYDRAULIC CRUSHER AND QUICK COUPLER


---

#### **Change Hydraulic Oil and Replace Full-Flow Filter Element**

Hydraulic breaker operation results in faster contamination of the hydraulic system, and faster deterioration of hydraulic oil. Failure to comply with proper maintenance intervals may result in damage to the base machine and the breaker. Change the hydraulic oil and the full-flow filter element in order to extend the service life particularly of the hydraulic pump. (Refer to the section "Hydraulic System" in the "MAINTENANCE" chapter.)

Change intervals differ depending on the brand of hydraulic oil used. Refer to the "Hydraulic System" in the "MAINTENANCE" chapter.

Use the high performance element (micro-glass) on excavators engaged in demolition and logging work.

 **NOTE:** *Hydraulic oil filter restriction alarm indicator is optional. If a filter-paper element is used, this indicator does not operate. (Refer to the section "Hydraulic System" in the "MAINTENANCE" chapter.)*

## OPTIONAL ATTACHMENTS AND DEVICES


### HYDRAULIC BREAKER, HYDRAULIC CRUSHER AND QUICK COUPLER

#### Precautions for Crusher Operation

Prevent machine tipping over and damage to the front attachment. Observe the following precautions for crusher operation.

**⚠ WARNING: Machine stability is reduced as the crusher is much heavier than bucket. When operating with a crusher, the machine is more likely to tip over. Falling or flying objects may hit the cab or other parts of the machine. Observe the following precautions and take any other precautions necessary to prevent accidents and machine damage from occurring.**

- Do not allow the machine's weight to be supported by the crusher or bucket cylinder with the bucket cylinder fully extended or retracted. Failure to do so may result in damage to the front attachment. In particular, avoid supporting the machine's weight with the bucket cylinder fully extended, as the front attachment will be easily damaged. Take care to prevent this happening when dismantling foundation structures using the crusher.
- Using the front attachment, do not raise the base machine off the ground with the arm cylinder fully extended. Failure to do so may result in damage to the arm cylinder.
- When a heavyweight attachment such as a crusher is installed, avoid quickly starting or stopping the front attachment. Failure to do so may result in damage to the front attachment.
- Do not attempt to perform crushing on either side of the machine. Always perform crushing operations to the front or rear, parallel with the tracks. Failure to do so may result in the machine tipping over.



MZX5-13-008




MZX5-13-009

## OPTIONAL ATTACHMENTS AND DEVICES

### HYDRAULIC BREAKER, HYDRAULIC CRUSHER AND QUICK COUPLER

- When the arm is rolled in with the crusher equipped, the crusher may come into contact with the boom.




MZX5-13-010

- When operating the crusher with the boom fully raised, be careful of falling objects.



MZX5-13-011

- When operating the crusher on the floor in a building, first confirm that the floor has sufficient strength to support the load caused by crushing, in addition to the machine weight.  
Depending on the operation method, a load higher than the machine weight may be applied to the floor.



MZX5-13-012

## **OPTIONAL ATTACHMENTS AND DEVICES**

### **HYDRAULIC BREAKER, HYDRAULIC CRUSHER AND QUICK COUPLER**

---

- Always operate the crusher on a stable, level surface, not on a slope or on crushed debris.
- Do not use the crusher to haul or load crushed debris.
- If a multiple number of attachments, such as crusher and bucket, or crusher and breaker, are used, replacing them with each other at intervals, impurities are more apt to enter the hydraulic system and the hydraulic oil deteriorates quickly. For this reason, replace the hydraulic oil tank filter and change the hydraulic oil at the intervals specified in the breaker time sharing diagram in the previous section.
- Always remove the crusher from the excavator before transporting the machine. Do not fully extend the bucket cylinder when transporting, as this may damage the front attachment, when vibrations arise during transportation.

## OPTIONAL ATTACHMENTS AND DEVICES

### HYDRAULIC BREAKER, HYDRAULIC CRUSHER AND QUICK COUPLER

#### Attachment

##### Allowable Weight Limits of Installed Attachment

**⚠ WARNING:**

- Before installing attachments such as hydraulic breaker, crusher (concrete crusher), or pulverizer, take machine controllability into account when selecting the weight of the attachment by referring to the table below.
- When an attachment other than the standard bucket is installed on the machine, the machine stability will be different.
- According to the specifications of installed attachment and the base machine, the machine weight may exceed the allowable maximum operating weight of the ROPS, making the ROPS unable to assure the protective function for operator. Refer to the ROPS certification affixed in the cab for the allowable maximum operating weight.

**If a heavy attachment is used, not only will controllability be affected but also machine stability will be reduced, possibly causing safety hazard.**

Unit: kg (lb)

Specification	Base Machine		Breaker		Crusher/Pulverizer	
	Model	Arm	Std.Weight	Max.Weight	Std.Weight	Max.Weight
Std. Model	ZX130-6N	Std.	1000 (2210)	1150 (2540)	1250 (2760)	1450 (3200)
	ZX160LC-6N	Std.	1250 (2760)	1350 (2980)	1500 (3310)	1750 (3860)
	ZX180LC-6N	Std.	1400 (3090)	1550 (3420)	1700 (3750)	2000 (4410)
	ZX210-6N	Std.	1550 (3420)	1750 (3860)	1900 (4190)	2200 (4850)
	ZX210LC-6N	Std.	1750 (3860)	1950 (4300)	2100 (4630)	2450 (5400)
	ZX250LC-6N	Std.	2150 (4740)	2400 (5290)	2600 (5730)	3050 (6720)
	ZX300LC-6N	Std.	2400 (5290)	2650 (5840)	2900 (6390)	3400 (7500)
	ZX350LC-6N	Std.	2650 (5840)	2900 (6390)	3150 (6940)	3700 (8160)
	ZX380LC-6N	HD (Heavy Duty)	3000 (6610)	3300 (7280)	3600 (7940)	4200 (9260)

## **OPTIONAL ATTACHMENTS AND DEVICES**

### **HYDRAULIC BREAKER, HYDRAULIC CRUSHER AND QUICK COUPLER**

---

- Breaker operation speed is faster than crusher operation, so the recommended maximum weight for breakers are lower than those for crushers.
- Weight is not the only factor to be considered when selecting a breaker. Select manufacturer's breaker models referring to the table on the next page.
- Avoid installing an attachment with a long overall length. Damage to the front attachment may result.
- When an attachment of the maximum weight is installed, always operate the attachment over the front or rear side of the machine. Avoid operating the attachment at maximum reach.
- Crushers are heavier than breakers. Slowly move the control lever when operating a crusher.
- Always contact your authorized dealer before installing attachments of other manufacturers.

# OPTIONAL ATTACHMENTS AND DEVICES


## HYDRAULIC BREAKER, HYDRAULIC CRUSHER AND QUICK COUPLER

### Attachment Connection Parts

The attachment hydraulic line and connection parts are located as illustrated below. When the attachment is disconnected, be sure to install caps or plugs to the ends of both the arm and attachment side hydraulic lines to prevent dust from entering or from sticking.

Adapter tightening torque:

- PF1 210 N·m (21 kgf·m)
- PF1-1/4 340 N·m (34 kgf·m)  
(ZX350LC-6N, 380LC-6N only right side piping)



Plug Thread Size : JIS B2351 O-Type PF1  
: JIS B2351 O-Type PF1-1/4  
(ZX350LC-6N, 380LC-6N only right side piping)

When the attachment is disconnected:

M175-05-005

Part No. List (Fill attachment manufacturer's part Nos. in the blank spaces.)

	Adapter Size	Adapter	Cap	Plug	Hose
Form/ Size	PF-UNF Male-Type				
ZX130-6N	PF1-1-1/16UN	4456399	4222711	4222264	
ZX160LC-6N, 180LC-6N, 210-6N, 210LC-6N, 250LC-6N, 290LC-6N left side piping	PF1X1-5/16UN	4214444	4222712	4222265	
ZX350LC-6N, 380LC-6N right side piping	PF1-1/4X1-5/16UN	4314094			
Form/ Size	PF-PF30° Female-Type				
ZX130-6N	PF1-PF3/4	4129457	9718916	4222047	
ZX160LC-6N, 180LC-6N, 210-6N, 210LC-6N, 250LC-6N, 290LC-6N left side piping	PF1XPF1	4042034	9718917	4168177	
ZX350LC-6N, 380LC-6N right side piping	PF1-1/4XPF1	4317614			
Form/ Size	PF-PF30° Male-Type				
ZX130-6N	PF1-PF3/4	4456120	4222715	4222044	
ZX160LC-6N, 180LC-6N, 210-6N, 210LC-6N, 250LC-6N, 290LC-6N left side piping	PF1XPF1	4456118	4222716	4222045	
ZX350LC-6N, 380LC-6N right side piping	PF1-1/4XPF1	4653961			

## OPTIONAL ATTACHMENTS AND DEVICES


### HYDRAULIC BREAKER, HYDRAULIC CRUSHER AND QUICK COUPLER

---

#### Precautions for Arm Roll-In/Bucket Roll-In Combined Operation

##### When Installing an Attachment Longer Than Standard Bucket

- ⚠ WARNING:** If an attachment (such as a hydraulic breaker, crusher or quick coupler) is installed that has a longer overall length than that of the bucket, the attachment may come into contact with the cab and/or the boom. Do not to allow the tip of the front attachment to hit the cab and/or the boom while rolling in the front attachment.



MZX5-13-010



## INDEX

- A**
- About Aftertreatment Device .....1-3
  - Actual operation ..... 1-85
  - Adjust Bucket Linkage .....7-102
  - Adjust the Operator's Seat .....5-6
  - Adjusting Operator's Seat ..... 1-132, 1-134
  - Adjusting Operator's Seat (Optional) ..... 1-136, 1-138
  - Adjusting Procedures.....1-140
  - Adjusting Seat Height.....1-138
  - After the First 100 Hours.....2-1
  - After the First 50 Hours .....2-1
  - Aftertreatment Device..... 1-25, 7-136
  - Aftertreatment Device Condition Display ..... 1-25
  - Aftertreatment Device Manual Regeneration ..... 5-10
  - Aftertreatment Device Manual
    - Regeneration Request..... 1-26
  - Aftertreatment Device Regeneration Inhibited ..... 1-55
  - Air Cleaner .....7-71
  - Air Conditioner ..... 1-33
  - Air Conditioner ON/OFF..... 1-33
  - Alarm Occurrence Screen..... 1-18
  - Allowable Weight Limits of Installed Attachment.....13-27
  - AM/FM Radio Operation.....1-119
  - AM/FM Selector/Tuning Switch (Radio) ..... 1-97
  - Angle Adjustment of Seat Surface .....1-139
  - Armrest Adjustment..... 1-133, 1-135, 1-137, 1-139
  - Attachment.....13-27
  - Attachment Adjustment..... 1-45
  - Attachment Connection Parts .....13-29
  - Attachment Name Input..... 1-51
  - Attachment Operation ..... 1-81
  - Attachment Pedal (Hydraulic Breaker) (Optional) .....13-14
  - Attachment Pedal (Hydraulic Crusher) (Optional).....13-15
  - Attachment Selection..... 1-35
  - Audio Input (Optional) .....1-123
  - Auto Air Conditioner .....1-111
  - Auto Shut-Down ..... 1-53, 5-7
  - Auto Shut-Down: ON/OFF..... 1-53
  - Auto Shut-Down: Setting Time..... 1-54
  - AUTO/OFF Switch/Fan Switch (Air Conditioner) ..... 1-96
  - Auto-Idle.....5-5
  - Auto-Idle ON/OFF.....5-6
  - Auto-Idle Switch ..... 1-98
  - AUX Function Lever 3.....1-106
  - Avoid Abusive Operation ..... 5-21
  - Avoid Applying Heat to Lines Containing
    - Flammable Fluids..... S-35
  - Avoid Hammer Work .....5-20
  - Avoid Heating Near Pressurized Fluid Lines ..... S-35
  - Avoid High-Pressure Fluids ..... S-30
  - Avoid Hitting Blade with Front-End Attachment..... 13-8
  - Avoid Injury from Attachment Falling Accident ..... S-29
  - Avoid Injury from Back-Over and Swing Accidents ..... S-17
  - Avoid Injury from Rollaway Accidents..... S-16
  - Avoid Power Lines..... S-21
  - Avoid Tipping..... S-19
- B**
- Avoid Undercutting ..... S-19
  - BREAK-IN.....2-1
  - Backrest Adjustment ..... 1-132, 1-135, 1-137, 1-139
  - Basic Screen.....1-9
  - Battery ..... 7-86
  - Battery Disconnect Switch .....1-143
  - Before Starting Engine .....3-2
  - Beware of Asbestos and Silica Dust and
    - Other Contamination ..... S-36
  - Beware of Exhaust Fumes..... S-33
  - Blade Lever ..... 13-7
  - Blade Maintenance ..... 13-9
  - Bleed Air from the Hydraulic System ..... 7-49
  - Breaker Operation ..... 1-79
  - Brightness Adjustment..... 1-65
  - Bucket Teeth (Transverse-Type-Pin-Used Type) .....13-13
  - Bucket Types and Applications ..... 12-4, 12-8, 12-12, 12-16,  
..... 12-20, 12-24, 12-28, 12-32
    - ZX130-6N ..... 12-4
    - ZX160LC-6N ..... 12-8
    - ZX180LC-6N .....12-12
    - ZX210-6N, 210LC-6N.....12-16
    - ZX250LC-6N .....12-20
    - ZX300LC-6N .....12-24
    - ZX350LC-6N .....12-28
    - ZX380LC-6N .....12-32
- C**
- Cab Door Release Lever .....1-124
  - Cab Features.....1-6
  - Cab Heater Operation.....1-115
  - Cab Light Switch.....1-108
  - Change Bucket .....7-100
  - Change Coolant ..... 7-79
  - Change DEF/AdBlue® .....7-143
  - Change Engine Oil ..... 7-34
  - Change Hydraulic Oil ..... 7-47
  - Change Hydraulic Oil and Replace Full-Flow
    - Filter Element .....13-23
  - Check Air Conditioner.....7-110
  - Check and Adjust Fan Belt Tension ..... 7-77
  - Check and Clean Aftertreatment Device .....7-136
  - Check and Clean Around the Engine ..... 7-37
  - Check and Clean Injector.....7-114
  - Check and Replace Bucket Teeth ..... 7-94
  - Check and Replace EGR Device.....7-113
  - Check and Replace Seat Belt.....7-103
  - Check Coolant Level ..... 7-75
  - Check DEF/AdBlue® .....7-139
  - Check Electrolyte Specific Gravity ..... 7-90
  - Check Engine Oil Level ..... 7-32
  - Check Fuel Hoses..... 7-70
  - Check Gas Damper .....7-114
  - Check Hoses and Lines..... 7-54
  - Check Hydraulic Oil Level ..... 7-46

## INDEX

Check Instruments After Starting.....	3-9	Engine.....	7-32
Check Starter and Alternator.....	7-113	Engine Auto-Stop in Extremely Low Temperature.....	3-13
Check the Hour Meter Regularly.....	7-4	Engine Control Dial.....	1-97
Check Track Sag.....	7-105	Engine Output Restriction Suspend.....	1-29
Check Turbo Charger.....	7-113	Engine Speed Control.....	5-4
Check Windshield Washer Fluid Level.....	7-104	Engine Stop Switch.....	1-109
Cigar Lighter.....	1-107	Ensure Safety Before Rising from or Leaving Operator's Seat.....	S-7
Circulation Air Mode.....	1-33	Evacuating in Case of Fire.....	S-33
Clean Air Conditioner Condenser.....	7-83	Every 8 Hours or Daily.....	2-1
Clean and Replace Air Cleaner Element (Outer).....	7-71	Extendable Filler Neck.....	7-141
Clean and Replace Air Conditioner Filter.....	7-108	Extending Password Duration Time.....	1-17
Clean Cab Floor.....	7-112	<b>F</b>	
Clean Filler Port Strainer.....	7-142	Fasten Your Seat Belt.....	S-7
Clean Fuel Oil Cooler.....	7-83	Fastening Machine for Transporting.....	6-5
Clean Oil Cooler, Radiator and Inter Cooler Front Screen.....	7-83	Features:.....	1-111
Clean Radiator/Oil Cooler/Inter Cooler Core.....	7-81	Flow Rate Adjustment.....	1-45
Clock.....	1-13	Follow Safety Instructions.....	S-2
Confirm Direction of Machine to Be Driven.....	S-13	For Rapid Cooling.....	1-118
Console and Seat Fore-aft Adjustment.....	1-132, 1-134, 1-136, 1-138	Fore-Aft Position Adjustment of Seat Surface.....	1-139
Console Height Adjustment.....	1-140	Front Joint Pins.....	7-28
Control Lever (ISO Pattern).....	5-1	Fuel Consumption.....	1-77
Controller Part Name and Function.....	1-113	Fuel Gauge.....	1-13
Controls on the Radio.....	1-119	Fuel System.....	7-58
Convert Bucket Connection Into Face Shovel.....	7-101	Fuse Box.....	1-110, 7-92
Cool Head/Warm Feet Operation.....	1-117	<b>G</b>	
Coolant Temperature Gauge.....	1-15	GETTING ON AND OFF THE MACHINE.....	1-2
Cooling Operation.....	1-116	General Precautions for the Cab.....	S-5
Cooling System.....	7-74	Grading Operation.....	5-19
Correct Maintenance and Inspection Procedures.....	7-1	Greasing.....	7-28
<b>D</b>		<b>H</b>	
DRIVING THE MACHINE.....	4-1	Handle Chemical Products Safely.....	S-38
Date Adjustment.....	1-41	Handle Fluids Safely—Avoid Fires.....	S-24
Date and Time.....	1-39	Hood and Access Covers.....	7-8
DEF/AdBlue® Gauge.....	1-14	Horn Switch.....	1-104
DEF/AdBlue® Level Alarm.....	1-14	Hour Meter.....	1-13
Default Setting.....	1-8	How to Lower Boom in Case of Emergency and When Engine Stops.....	5-25
Defroster Operation.....	1-117	How to Use Screens.....	1-10
Dig with Caution.....	S-20	Hydraulic Breaker, Hydraulic Crusher and Quick Coupler.....	13-16
Display Item Selection (Rear View Camera OFF).....	1-72	Hydraulic System.....	7-42
Display Mode Setting.....	1-43	<b>I</b>	
Displaying Basic Screen.....	1-10	Information Menu.....	1-76
Dispose of Waste Properly.....	S-38	Input Password.....	1-16
Do Not Strike the Ground with Bucket Teeth.....	5-20	Inspect and Adjust Valve Clearance.....	7-113
Do Not Use Wide Track Shoes on Rough Ground.....	5-22	Inspect Machine.....	S-4
Drain Fuel Pre-Filter.....	7-61	Inspect Machine Daily Before Starting.....	3-1
Drain Fuel Tank Sump.....	7-60	Inspection and Maintenance of Hydraulic Equipment... ..	7-42
Drain Intercooler (only ZX130-6N).....	7-84	Install OPG Guard.....	S-12
Drive Machine Safely.....	S-14	Installation and Adjustment of Mirrors.....	1-141
<b>E</b>		Installing Fire Extinguisher (Optional).....	1-108
EGR Cooler Cleaning.....	7-113	Investigate Job Site Beforehand.....	S-11
Electrical Control Main Switch (Optional).....	1-103, 1-105		
Electrical System.....	7-85		
Emergency Exit.....	1-131		

## INDEX

<b>J</b>	
Jump Starting .....	S-9
<b>K</b>	
Keep People Clear from Working Area .....	S-18
Keep Riders off Machine .....	S-9
Key Switch .....	1-104
Kind of Oils .....	7-17
<b>L</b>	
Language Settings .....	1-67
Layout .....	7-3
Lifting Machine .....	6-7
List of Consumable Parts .....	7-20
Lists of Display Language .....	1-69
Loading/Unloading on a Trailer .....	6-2
Long Arm Operation --- If Equipped .....	13-6
<b>M</b>	
MACHINE NUMBERS .....	1
MAINTENANCE UNDER SPECIAL ENVIRONMENTAL CONDITIONS .....	9-1
Mail (Optional) .....	1-36
Main Menu .....	1-28
Main Menu Sequence Change .....	1-74
Maintenance .....	1-87, 7-1
Maintenance Guide .....	7-11
Maintenance Guide Table .....	7-5
Manual Regeneration Procedure .....	1-27
Measure Engine Compression Pressure .....	7-113
Miscellaneous .....	7-94
Monitoring .....	1-93
Move and Operate Machine Safely .....	S-8
Multi Function Monitor .....	1-7
<b>N</b>	
NAME OF COMPONENTS .....	1-1, 1-112
Never Move an Object Sideways with the Bucket .....	S-21
Never Position the Bucket Over Anyone .....	S-18
Never Ride Attachment .....	S-39
Never Undercut a High Bank .....	S-20
Notes on Aftertreatment Device .....	S-39
Notes on Protection of Operator's Station when the Machine Rolls Over .....	S-40
Numeric Keypad .....	1-101
<b>O</b>	
OPERATING THE ENGINE .....	3-1
OPERATING THE MACHINE .....	5-1
OPERATOR'S STATION .....	1-3
OPTIONAL ATTACHMENTS AND DEVICES .....	13-1
Object Handling .....	S-22
Observe Engine Operation Closely .....	2-1
Off-Season Air Conditioner Maintenance .....	1-118
ON/OFF Operation Switch (Optional) .....	1-103, 1-106
Opening Side Window .....	1-128
Opening Upper Front Window .....	1-126
Opening/Closing and Removing Cab Inside Window .....	1-125
Opening/Closing Overhead Window .....	1-129
Opening/Closing Overhead Window (Clear Hatch: If Equipped) .....	1-130
Operate Only from Operator's Seat .....	S-8
Operate with Caution .....	S-20
Operating Backhoe .....	5-17
Operating in Water or Mud .....	4-6
Operating on Soft Ground .....	4-4
Operating Status Icon Display .....	1-15
Operation .....	1-77
Operational Procedures for Stop Valves and Selector Valve .....	13-17
<b>P</b>	
Park Machine Safely .....	S-24
Parking the Machine .....	4-7
Parking the Machine on Slopes .....	4-7
Password Change (Optional) .....	1-57
Periodic Replacement of Parts .....	7-16
Pilot Accumulator Functions .....	5-24
Pilot Control Shut-Off Lever .....	1-109, 5-2
Piping for Breaker and Crusher .....	13-17
Power Boost Switch .....	1-104, 5-15
Power Mode .....	5-16
Power Mode Switch .....	1-99
Power Switch/Volume Control Knob (Radio) .....	1-97
Practice Safe Maintenance .....	S-26
Precautions for After Operations .....	5-26
Precautions for Arm Roll-In/Bucket Roll-In Combined Operation .....	13-30
Precautions for Breaker Operation .....	13-19
Precautions for Communication Terminal .....	S-39
Precautions for Crusher Operation .....	13-24
Precautions for Handling Accumulator and Gas Damper .....	S-35
Precautions for Lightning .....	S-21
Precautions for Operations .....	S-10
Precautions for Transporting Machines with Pad Crawler Shoes .....	13-3
Precautions for Welding and Grinding .....	S-34
Preparations for Inspection and Maintenance .....	7-7
Prepare for Emergencies .....	S-3
Prevent Battery Explosions .....	S-37
Prevent Burns .....	S-29
Prevent Fires .....	S-31
Prevent Parts from Flying .....	S-28
Priority (arm roll-in) (Except ZX350LC-6N, 380LC-6N) .....	1-49
Priority (arm roll-out) .....	1-47
Procedures: .....	7-68
Protect Against Flying Debris and Falling Object .....	S-23
Protect Against Noise .....	S-4
Provide Signals for Jobs Involving Multiple Machines .....	S-13
Pump Transmission (Except ZX130-6N) .....	7-38

## INDEX

- 
- R**
- Radio ..... 1-34
  - Raise One Track Using Boom and Arm ..... 4-4
  - Rear Light Switch (Optional) ..... 1-103
  - Rear View Camera Monitor ..... 1-63
  - Rear View Camera ON/OFF ..... 1-63
  - Recognize Safety Information ..... S-1
  - Recommended Engine Oil ..... 7-17
  - Recommended Fuel ..... 7-58
  - Refill DEF/AdBlue® ..... 7-139
  - Remaining Time and Maintenance Interval ..... 1-89
  - Remedy ..... 1-20
  - Remove Paint Before Welding or Heating ..... S-36
  - Remove Travel Levers ..... 7-103
  - Removing and Storing Lower Front Window ..... 1-127
  - Replace Air Breather Element ..... 7-53
  - Replace Air Cleaner Element (Inner) ..... 7-73
  - Replace Battery ..... 7-89
  - Replace DEF/AdBlue® Supply Module Main Filter ..... 7-144
  - Replace DEF/AdBlue® Tank Water Supply Inlet Filter ..... 7-146
  - Replace Engine Oil Filter ..... 7-34
  - Replace Fuel Main Filter Element ..... 7-64
  - Replace Fuel Pre-Filter Element ..... 7-66
  - Replace Fuel Solenoid Pump Filter Element ..... 7-68
  - Replace Full-Flow Filter ..... 7-51
  - Replace Oil Separator Element  
(ZX130-6N, 160LC-6N, 180LC-6N) ..... 7-37
  - Replace Pilot Oil Filter ..... 7-52
  - Replace Rubber Hoses Periodically ..... S-30
  - Replace the DEF/AdBlue® back flow line filter ..... 7-147
  - Replacing Fuses ..... 7-91
  - Restriction of Attachment Installation ..... S-12
  - Retighten Cylinder Head Bolt ..... 7-113
  - Return to Basic Screen Switch (Monitor) ..... 1-96
  - Return to Previous Screen Switch (Monitor) ..... 1-96
- S**
- SAFETY ..... S-1
  - SAFETY SIGNS ..... S-41
  - SPECIFICATIONS ..... 12-1, 12-5, 12-9, 12-13, 12-17,  
..... 12-21, 12-25, 12-29, 13-10
  - ZX130-6N ..... 12-1
  - ZX160LC-6N ..... 12-5
  - ZX180LC-6N ..... 12-9
  - ZX210-6N, 210LC-6N ..... 12-13
  - ZX250LC-6N ..... 12-17
  - ZX300LC-6N ..... 12-21
  - ZX350LC-6N ..... 12-25
  - ZX380LC-6N ..... 12-29
  - ZX130-6N with Blade ..... 13-10
  - STORAGE ..... 10-1
  - Seat Belt ..... 1-142
  - Seat Fore-Aft Adjustment ..... 1-132, 1-134, 1-136, 1-138
  - Seat Height and Angle Adjustment ..... 1-132, 1-134, 1-136
  - Secondary Relief Pressure Adjustment ..... 13-18
  - Security Functions (Optional) ..... 1-16
  - Selector Knob (Monitor) ..... 1-96
  - Service Air Conditioning System Safely ..... S-37
  - Setting Menu ..... 1-38
  - Setting Procedure ..... 1-55
  - Shackle Hole Usage ..... 5-23
  - Shoe Types and Applications ..... 12-3, 12-7, 12-11, 12-15,  
..... 12-19, 12-23, 12-27, 12-31, 13-12
  - ZX130-6N ..... 12-3
  - ZX160LC-6N ..... 12-7
  - ZX180LC-6N ..... 12-11
  - ZX210LC-6N ..... 12-15
  - ZX250LC-6N ..... 12-19
  - ZX300LC-6N ..... 12-23
  - ZX350LC-6N ..... 12-27
  - ZX380LC-6N ..... 12-31
  - ZX130-6N with Blade ..... 13-12
  - Shovel ..... 5-18
  - Starting the Engine ..... 3-3
  - Station Auto-Presetting Procedure ..... 1-121
  - Station Presetting Procedure ..... 1-120
  - Stay Clear of Moving Parts ..... S-28
  - Stopping the Engine ..... 3-12
  - Storing the Machine ..... 10-1
  - Sub Meter ..... 1-61
  - Suction Filter Cleaning ..... 7-50
  - Support Machine Properly ..... S-27
  - Suspension Adjustment ..... 1-134, 1-136, 1-139
  - Swing Bearing ..... 7-30
  - Swing Internal Gear ..... 7-31
  - Swing Reduction Gear ..... 7-39
  - Switch Operation ..... 1-143
  - Switch Panel ..... 1-95
  - Switch Panel (for Optional Equipments) ..... 1-102
- T**
- TRANSPORTING ..... 6-1, 13-3
  - Temperature Control Switch/Mode Switch  
(Air Conditioner) ..... 1-96
  - Tightening and Retightening Torque of  
Nuts and Bolts ..... 7-114
  - Time Adjustment ..... 1-39
  - Tips for Optimal Air Conditioner Usage ..... 1-118
  - TONE Control ..... 1-122
  - Towing Machine a Short Distance ..... 4-5
  - Transmission ..... 7-38
  - Transport Safely ..... S-25
  - Transporting by Road ..... 6-1
  - Travel Alarm (Optional) ..... 4-3
  - Travel Alarm Deactivation Switch (Optional) ..... 1-103
  - Travel Levers and Pedals ..... 4-1
  - Travel Mode Switch ..... 1-98, 4-3
  - Travel Operation ..... 1-83
  - Travel Reduction Gear ..... 7-40
  - Traveling and Other Cautions ..... 13-2
  - Troubleshooting ..... 1-91, 11-1
  - Tuning Procedure ..... 1-119
-

## INDEX

---

### U

Understand Signal Words.....	S-1
Unit Selection .....	1-70
Unloading .....	6-5
Urea SCR System.....	7-137
Urea SCR System Remedy .....	1-23
Urea SCR System Troubleshooting.....	1-31
Use Handholds and Steps .....	S-6
Using Booster Batteries .....	3-10
Using Cigar Lighter .....	1-107
Using Pad Crawler Shoe .....	13-1

### W

Warming-Up Operation .....	5-3
Warn Others of Service Work .....	S-27
Wear Protective Clothing.....	S-3
When Windows Become Misty.....	1-118
Wiper/Washer Switch.....	1-100
Work Light Switch .....	1-99
Work Mode .....	1-35, 5-12
Working Ranges.....	12-18, 12-22, 13-11
ZX250LC-6N .....	12-18
ZX300LC-6N .....	12-22
ZX130-6N with Blade.....	13-11
Working Ranges (Grouser shoe).....	12-2, 12-6, 12-10, ..... 12-14, 12-26, 12-30
ZX130-6N .....	12-2
ZX160LC-6N .....	12-6
ZX180LC-6N .....	12-10
ZX210-6N, 210LC-6N.....	12-14
ZX350LC-6N .....	12-26
ZX380LC-6N .....	12-30

